

460ECBS-N2E Protocol Gateway

Product User Guide

Firmware Version 8.9.39



Trademarks

CompactLogix, ControlLogix, & PLC-5 are registered trademarks of Rockwell Automation, Inc. EtherNet/IP is a trademark of the ODVA. MicroLogix, RSLogix 500, and SLC are trademarks of Rockwell Automation, Inc. Microsoft, Windows, and Internet Explorer are registered trademarks of Microsoft Corporation. BACnet[®] is a registered trademark of American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE). All other trademarks and registered trademarks are the property of their holders.

Limited Warranty

Real Time Automation, Inc. warrants that this product is free from defects and functions properly.

EXCEPT AS SPECIFICALLY SET FORTH ABOVE, REAL TIME AUTOMATION, INC. DISCLAIMS ALL OTHER WARRANTIES, BOTH EXPRESSED AND IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR APPLICATION. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular application, Real Time Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams. Except as specifically set forth above, Real Time Automation and its distributors and dealers will in no event be liable for any damages whatsoever, either direct or indirect, including but not limited to loss of business profits, income, or use of data. Some states do not allow exclusion or limitation of incidental or consequential damages; therefore, the limitations set forth in this agreement may not apply to you.

No patent liability is assumed by Real Time Automation with respect to use of information, circuits, equipment, or software described in this manual.

Government End-Users

If this software is acquired by or on behalf of a unit or agency of the United States Government, this provision applies: The software (a) was developed at private expense, is existing computer software, and was not developed with government funds; (b) is a trade secret of Real Time Automation, Inc. for all purposes of the Freedom of Information Act; (c) is "restricted computer software" submitted with restricted rights in accordance with subparagraphs (a) through (d) of the Commercial "Computer Software-Restricted Rights" clause at 52.227-19 and its successors; (d) in all respects is proprietary data belonging solely to Real Time Automation, Inc.; (e) is unpublished and all rights are reserved under copyright laws of the United States. For units of the Department of Defense (DoD), this software is licensed only with "Restricted Rights": as that term is defined in the DoD Supplement of the Federal Acquisition Regulation 52.227-7013 (c) (1) (ii), rights in Technical Data and Computer Software and its successors, and: Use, duplication, or disclosures is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at 52.227-7013. If this software was acquired under GSA schedule, the U.S. Government has agreed to refrain from changing or removing any insignia or lettering from the Software or documentation that is provided or from producing copies of the manual or media. Real Time Automation, Inc.

© 2024 Real Time Automation, Inc. All rights reserved.



Revision History	5
Overview	7
Hardware Platforms	8
Hardware – N2E	9
Powering the Gateway	9
Mounting with a DIN Rail1	1
Installing1	1
Removing1	1
Accessing the Main Page1	2
Committing Changes to the Settings1	.4
Main Page1	.5
Device Configuration1	6
Network Configuration1	7
EtherNet/IP Scanner Configuration1	9
EtherNet/IP Scanner Device Configuration2	0
Configuring Input Instance	1
Configuring Output Instance2	2
BACnet/IP Server Configuration2	.3
BACnet/IP Server Configuration-Data Groups2	.4
BACnet/IP Server Configuration: Auto-Configure Mode (Default)2	5
BACnet/IP Server Configuration: Manual Configure Mode2	6
BACnet/IP Server Object Configuration – Analog Objects2	7
BACnet/IP Server Object Configuration – Binary Objects2	.8
BACnet/IP Server Object Configuration – CharacterString Value Objects	9
BACnet/IP Server Object Configuration – Group Names3	0
BACnet/IP Server Routing Configuration3	1
Mapping - Transferring Data Between Devices3	2
Display Mapping and Values	3
Display Data3	3
Display String3	6
Display String use case	8
Data and String Mapping – Auto-Configure3	9

3



Data Mapping – Explanation	40
Data Mapping – Adding Diagnostic Information	41
String Mapping – Explanation	46
Mapping – Auto-Configure Mode to Manual Configure Mode	47
Mapping – Manual Configure Mode to Auto-Configure Mode	48
View as Text	49
Data Mapping	49
String Mapping	49
Base Triggering – Data Validiation Triggering	50
Security Configuration	52
Security Configuration-Security Levels	53
Security - Log In	54
Security - Log Out	54
Email Configuration	55
Alarm Configuration	56
Diagnostics – Alarm Status	58
Alarms – Active	58
Alarms – Clear	59
Change of State (COS) Configuration	60
Diagnostics Info	61
Diagnostics Mapping	61
Diagnostics – EtherNet/IP Scanner	62
Diagnostics – BACnet/IP Server	66
LED Configuration	69
Configuration Files	70
Export Configuration	70
Import Configuration	70
Save and Replace Configuration Using SD Card	72
Saving Configuration Using SD Card	72
Replacing Configuration Using SD Card	72
Intelligent Reset Button	73
Utilities	74



Revision History

Version	Date	Notes
8.4.5	11/18/2019	 Features Added Released OPC UA Server (US) Protocol Ability to now Import/Export Template Files with out an FTP session Bug Fixes Updated Profinet Server (PS) on N34 hardware Platform Updated Wi-Fi software
8.6.0	2/28/20	Bug Fixes1. Omron Plc Communication fixes for EtherNet/IP2. Profinet GSDML Substitute values fix
8.7.4	9/1/20	 Features Added: 1. BMS, BM, DFM, DS, DM, TCP, USB, PBS have been ported to the latest base software 2. TCP,BMS,BM now Available on N2E and N2EW hardware Platform 3. New ASCII Mode Available on TCP/A/USB/WI protocols 4. User Guides updated with more examples Bug Fixes: 1. Improved Data Mapping and String Mapping performance 2. Improved functionality/performance on EC,ETC,ES,MC,MS,BS,BC, A,,WI,PS protocols
8.7.22	4/6/21	Features Added: 1. Support for RSLogix Versions 32 + with unsigned data type support 2. ETC now support Long integer files (L files) for MicroLogix PLCS that support them 3. SC now supports data block (DB) access
8.7.53	4/28/21	 Features Added: 5. Added support for the NNBU hardware platform 6. Improved RFIDeas scanner support 7. Updated MM and MRS to use Modbus RTU Client and Modbus RTU Server terminology



Version	Date	Notes
8.9.22	2/5/24	 Features Added: Added priority-based reads for client protocols Added improved diagnostic timers for client protocols Reduced minimum delay between messages to zero ms on client protocols Added support for USB serial connections Added support for multiple connections on EtherNet/IP Adapter Added 100ms and 1000ms heartbeat values for diagnostic use Added configurable data size to EtherNet/IP adapter and DeviceNet Slave Added support for TTL communications on N34, NNA1, NNA4, N2E, and N2EW hardware Added support for JSON payloads to MQTT Added Network Bitmap Status to ASCII, USB, and TCP protocols Bug Fixes: Fixed COV Subscription Issues on BACnet MS/TP Fixed timing issues affecting gateway performance Fixed a bug where the Run Idle Header on the output instance for EtherNet/IP scanner was not checked by default
8.9.29	4/1/24	 Features Added: 14. Added ability to do raw HEX byte copy when receiving data over ASCII, TCP, or USB. Bug Fixes: 15. Fixed bug where function code 15 did not work on MM/MC. 16. Fixed bug relating to writing zeros on start up on BS. 17. Fixed bug where MQTT client did not appear in display data page when MQTT was paired with BACnet
8.9.37	7/30/24	Bug Fixes: 18. EIP IO Communication fixes 19. Timing fixes 20. USB Fixes a. Inactivity Timeout b. Inactivity Timeout Logging c. Port Restart Logging d. Webpage fixes 21. ProfiNet Timing Fix 22. EIP PanelView Fixes a. Support for Explicit Messaging



Overview

The 460ECBS-N2E gateway Connects up to 32 EtherNet/IP adapters with a BACnet/IP client. By following this guide, you will be able to configure the 460ECBS-N2E gateway.

Number of ASCII devices is dependent on the Hardware and Product number of the 460 gateway.

For further customization and advanced use, please reference the appendices located online at: <u>http://www.rtautomation.com/product/460-gateway-support/</u>.

If at any time you need further assistance, do not hesitate to call Real Time Automation support. Support Hours are Monday-Friday 8am-5pm CST

Toll free: 1-800-249-1612 Email: support@rtautomation.com



Hardware Platforms

The 460 Product Line supports a number of different hardware platforms. There are differences in how they are powered, what serial settings are supported, and some diagnostic features supported (such as LEDs). For these sections, be sure to identify the hardware platform you are using.

To find which hardware platform you are using:

- 1) Look on the front or back label of the unit for the part number.
- On the webpage inside the gateway, navigate to the dropdown menu under Other and select Utilities. Click the Listing of Revisions button. The full part number is displayed here.

Once you have the full part number, the platform will be the number following the "-N":





Hardware – N2E



Powering the Gateway

The following steps will allow you to properly and safely power the gateway.



Warning: Improper wiring will cause unit failure! Use the Screw Terminal's power connection!

- 1) Connect a 12-24 VDC power source to the gateway, Red Wire = (+) Black Wire = (-).
 - a) The unit draws 8 VDC 900mA (7.2W) Max
 - b) The unit draws 35 VDC 900mA (31.5W) Max
 - c) The gateway has a voltage operating range from 8-35 VDC, 24 VDC is recommended.







Hazardous Environment Power & Installation Instructions

This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D, or non-hazardous locations only.

WARNING – EXPLOSION HAZARD - Do not disconnect equipment unless power has been removed or the area is known to be non-hazardous.

WARNING - EXPLOSION HAZARD - Substitution of components may impair suitability for Class I, Division 2.

THIS EQUIPMENT IS AN OPEN-TYPE DEVICE AND IS MEANT TO BE INSTALLED IN AN ENCLOSURE SUITABLE FOR THE ENVIRONMENT SUCH THAT THE EQUIPMENT IS ONLY ACCESSIBLE WITH THE USE OF A TOOL.

WARNING – POWER JACK (Screw Terminals, J7) IS FOR MAINTENANCE USE ONLY AND MAY ONLY BE USED WHILE THE AREA IS KNOWN TO BE FREE OF IGNITIBLE CONCENTRATIONS OF FLAMMABLE GASES OR VAPORS. IT IS NOT TO BE CONNECTED UNDER NORMAL OPERATION.

In Hazardous Environments the unit must be powered with between 8-35 VDC, 8 VDC @ 900 mA (7.2 W) max. Supervised. The unit is certified to be operated at -40°C to 50°C.

Instructions d'alimentation et d'installation pour environnement dangereux

Cet équipement est conçu pour être utilisé uniquement dans des lieux de classe I, division 2, groupes A, B, C et D, ou non dangereux.

AVERTISSEMENT - **RISQUE D'EXPLOSION** - Ne débranchez pas l'équipement à moins que le courant ne soit coupé ou que la zone ne présente aucun danger.

AVERTISSEMENT - **RISQUE D'EXPLOSION** - La substitution de composants peut compromettre l'adéquation à la classe I, division 2.

CET APPAREIL EST UN DISPOSITIF DE TYPE OUVERT ET IL FAUT L'INSTALLER DANS UN ENCEINTE ADAPTÉ À L'ENVIRONNEMENT TEL QU'IL N'EST ACCESSIBLE À L'UTILISATION D'UN OUTIL.

AVERTISSEMENT - LE POWER JACK (bornes à vis, J7) est destiné exclusivement à la maintenance et ne peut être utilisé que lorsque la zone est connue pour être exempte de concentrations inintéressantes de gaz ou de vapeurs inflammables. IL NE DOIT PAS ÊTRE CONNECTÉ SOUS UN FONCTIONNEMENT NORMAL.

Dans les environnements dangereux, l'unité doit être alimentée entre 8-35 VDC, 8 VDC @ 900 mA (7,2 W) max. Supervisé. L'appareil est certifié pour fonctionner entre -40 ° C et 50 ° C.



Mounting with a DIN Rail

Installing

Follow these steps to install your interface converter.

- 1) Mount your DIN Rail.
- 2) Hook the bottom mounting flange under the DIN Rail.
- 3) While pressing the 460ECBS-N2E against the rail, press up to engage the spring loaded lower clip and rotate the unit parallel to the DIN Rail.
- 4) Release upward pressure.



Removing

Follow these steps to remove your interface converter.

- 1) Press up on unit to engage the spring loaded lower clip.
- 2) Swing top of the unit away from DIN Rail.

11



Accessing the Main Page

The following steps will help you access the browser based configuration of the gateway. By default, DHCP is enabled. If the gateway fails to obtain an IP address over DHCP it will Auto IP with 169.254.X.Y. For more information on your Operating system network setting refer to the <u>Accessing Browser</u> <u>Configuration</u> document from our support web site.

1) Scan the QR code on the back of the unit or navigate to <u>www.rtautomation.com/460-gateway-support</u> and download IPSetup.exe.

NDK Settings IP	0.	0	. 0 .	0]	- Select a U	nit <u>XXYY</u> [00-03-F4-0A-D2-8	C] AutolP at 169.254.4
Network Mask	0.	0.	0.	0				
GateWay	0.	0.	0.	0	Set>			
DNS 🛛	0.	0.	0,	0				
							Search Again]
					-		1	1

- 2) Run the IPSetup.exe program.
- 3) Find unit under "Select a Unit".
 - a. Change Gateway's IP address to match that of your PC if DHCP has failed.
 - i. You will know DHCP has failed if the gateway's IP address is AutoIP at 169.254.X.Y.
 - ii. If successful, it will say DHCP'd at ex: 192.168.0.100 or however your DCHP Client is set up.
 - b. If you do not see the gateway in this tool, then your PC is most likely set up as a static IP.
 - i. Change your PC's network settings to be DHCP. If DHCP fails, then it will change to be on the 169.254.x.y network.
 - ii. Relaunch the IP Setup tool to see if gateway can be discovered now.
- 4) Click Launch Webpage. The Main page should appear.

Default setting is set to DHCP. If DHCP fails, default IP Address is 169.254.x.y



Error: Main Page Does Not Launch

If the Main Page does not launch, please verify the following:

- 1) Check that the PC is set for a valid IP Address
 - a. Open a MS-DOS Command Prompt
 - b. Type "ipconfig" and press enter
 - c. Note the PC's IP Address, Subnet, and Default Gateway
- The gateway must be on the same Network/Subnet as the PC whether it's setup for DHCP or Static. Once you have both devices on the same network, you should be able to ping the gateway using a MS-DOS Command Prompt.



The Screenshot above shows a gateway that is currently set to a static IP Address of 192.168.0.100.

If you are able to successfully ping your gateway, open a browser and try to view the main page of the gateway by entering the IP Address of the gateway as the URL.





Committing Changes to the Settings

All changes made to the settings of the gateway in Configuration Mode will not take effect until the gateway is restarted via the webpage. Changes will not be stored if the gateway's power is removed prior to a reboot.

NOTE: The gateway does not need to be restarted after every change. Multiple changes can be made before a restart, but they will not be committed until the gateway is restarted.

When all desired changes have been made, press the **Restart Now** button. The webpage will redirect to our rebooting page shown below:



The reboot can take up to 20 seconds.

If the IP address has not been modified, the gateway will automatically redirect to the main page. If the IP address was modified, a message will appear at the top of the page to instruct the user to manually open a new webpage at that new IP.



Main Page

The main page is where important information about your gateway and its connections are displayed. Mode (orange box below):

Running Mode:

- Protocol communications are enabled
- Configuration cannot be changed during Running Mode. If changes are needed, click the **Configuration Mode** button shown in the green box below

Configuring Mode:

- Protocol communication is stopped and no data is transmitted
- Configuration is allowed

Navigation (green box below):

You can easily switch between modes and navigate between pages (Configuration, Diagnostics, and Other pages) using the buttons on the left hand side.

RTA				www.rtaautomation.com
Real Time Auton	nation, Inc.			460ETCMC
Configuration Mode		Mai	n Page	
Main Page		Device Description: Applica	tion Description	
CONFIGURATION Network Configuration Allen-Bradley PLC		Save	Parameters	
Modbus TCP/IP Client Display Data	Network Status	Link Status	MAC Address	ID Address
DIAGNOSTICS -Select-	Ethernet Port	100Mbps, Full Duplex	00:03:F4:0A:43:CC	10.1.28.95
OTHER Select- ▼	Allen-Bradley PLC Statu Device Status: Last Read Error Code: Last Write Error Code:	IS Fatal Error: No Configurat	ion	
	LED Status:	Connection Status: No De	vices Configured / Enabled	
	Modbus TCP/IP Client S Device Status: Last Error Code: LED Status:	Status Fatal Error: No Configurat Connection Status: No De	ion vices Configured / Enabled	
	Data Mapping Status # Enabled: # of Errors: First Error:	0 of 0 0	-	



Device Configuration

The device configuration area is where you assign the device description parameter. Changes can only be made when the gateway is in Configuration Mode.

Main Page	
Device Description: Application Description	
Save Parameters	

Once you are done configuring the Description, click the **Save Parameters** button.



Network Configuration

The network configuration area is where you assign the IP address and other network parameters. Changes can only be made when the gateway is in Configuration Mode.

Once you are done configuring the Network Settings, click the **Save Parameters** button.

If you are changing the IP Address of the gateway, the change will not take effect until the unit has been rebooted. After reboot, you must enter the new IP Address into the URL.

Network Configuration		Help
Ethernet Switch Configuration		
Ethemet Switch Comgutation	Topology: Independent >	
	Topology. Independent	
Ethernet Port 1 Configuration		
Eth	ernet MAC Address: 00:03:F4:0A:C0:64	
	Ethernet Link: Auto-Negotiate	
	IP Setting: Static IP V	
	IP Address: 192.168.47.199	
	Subnet: 255.255.0	
	Default Gateway: 0.0.0.0	
	DNS Gateway: 0.0.0.0	
	Save Parameters	
Ethernet Port 2 Configuration	ornot MAC Addrose: 00:02:E4:0A:C0:C8	
Eu	Ethernet Link: Auto-Negotiate	
	IP Setting: Static IP V	
	IP Address: 10.1.28.105	
	Subnet: 255.255.0.0	
	Default Gateway: 0.0.0	
	DNS Gateway: 0.0.0.0	
	,,	
	Save Parameters	



Network Interface Options

The N2E hardware has two different Network Interface options, Independent and Switch Mode. Below, you can find the different use cases that each interface option allows for.

Independent Mode

- 1) Two Ethernet-based protocols on the same IP Network
 - a) Ethernet Port 1 used OR
 - b) Ethernet Port 2 used OR
 - c) Ethernet Port 1 & 2 used
- 2) Two Ethernet-based protocols on different IP Networks
 - a) Ethernet Port 1 used AND
 - b) Ethernet Port 2 used

Switch Mode – Only Ethernet Port 1 is used for protocol communication

- 3) One Ethernet-based protocol on the IP Network (layer-2 switch)
 - a) Ethernet Port 1 used for direct protocol communication
 - b) Ethernet Port 2 available for daisy chaining devices together
 - i) A Ring topology is NOT supported
- 4) Two Ethernet-based protocols on same IP Network
 - a) Ethernet Port 1 used for direct protocol communication with another switch, hub, or router
 - b) Ethernet Port 2 available for a daisy chaining devices together
 - i) A Ring topology is NOT supported
- 5) Two Ethernet-based protocols on different IP Networks
 - a) Not Possible must use Independent Mode

It is recommended to leave the DNS Gateway set to 0.0.0.0 and the Ethernet Link as Auto-Negotiate. If configuring the gateway to use E-mail, the DNS Gateway must be set.



EtherNet/IP Scanner Configuration

Click the **EIP Scanner** button to access the configuration page.

- 1) **Network Interface:** Select which network you wish to communicate with EtherNet/IP scanner. If using single port hardware, the Network Interface will default to Ethernet Port only.
- 2) **Delay Between Connect Attempts**: Enter the amount of time the gateway will delay between attempts to make a connection.
- 3) **Dependency Protocol**: If enabled, EtherNet/IP communication will stop if communication to the selected protocol is lost.

EtherNet/IP Scanner Configuration	Help
Network Interface. Switch Mode (10.1.16.49) *	
Delay Between Connect Attempts: 1000 1000-60000 ms	
Dependency Protocol: None	
Save Parameters	



EtherNet/IP Scanner Device Configuration

The bottom area of the EtherNet/IP Scanner Configuration page lets you configure up to 32 external EtherNet/IP adapter devices.

1) To add additional adapter connections, click the -Select- dropdown under EtherNet/IP Scanner Device List and select **Add Generic Adapter** option.

EtherNet/IP Scanner Device List	
-Select	- V Delete Adapter
	<< <u>1</u> >> 1-2

- a. If you are configuring multiple devices click << or >> to navigate to another device.
- b. To create a new adapter with the same parameters already configured from another adapter, click the -Select- dropdown and select the **Add from Adapter X** option (where X represents the adapter you wish to copy parameters from). Once created, you can make any additional changes needed to that new adapter.
- c. To remove a device, navigate to the adapter to delete using the << and >> buttons and click the **Delete Adapter** button.
- d. Click the **Save Parameters** button to save change before restarting or going to another configuration page.
- 2) The **Enable** check box should be selected for the device.
- 3) Enter a **Device Label** to identify the device within the gateway.
- 4) Enter the unique **IP Address** that matches the adapter. If this value doesn't match, the gateway will timeout.
- 5) Select the **TCP Mode** to use.
 - a. **Close**: This will force the TCP connection used to open the I/O connection to close immediately after the connection is established. This is the default value.
 - Dpen: This will keep the TCP connection open while the I/O connection is open. Use this mode if the adapter device does not remove the I/O UDP traffic versus TCP dependency

 this is possible with legacy devices.
- 6) Enter the **Configuration Instance** that matches the I/O adapter (if used). Many devices use 1 as a place holder when configuration isn't needed.
- 7) **Configuration Size**: Configuration data is not currently supported.

Enable	EtherNet/I	P Adapter 1
Device Label EC01		IP Address 0.0.0.0
	TCP Mode	Close V
Configuration Instance 0	0-65535	Configuration Size 0
View Input Instance		View Output Instance



Configuring Input Instance

Follow these steps to manually configure the Input Instance.

- 1) Select View Input Instance if not already selected.
- 2) **Run Idle Header**: Check this box if the I/O adapter's data contains information about the validity of the input data. Default value is unchecked since most devices don't use this.
- 3) **Request Packet Interval (RPI):** This is the amount of time between each read/write request to the adapter. If this value is faster than the adapter supports, an error will occur.
- 4) **Input Instance:** This is the input instance defined by the I/O adapter device. This must match for proper communication.
- 5) **Priority:** Select the appropriate value as defined by the I/O adapter. Default value is scheduled.
- 6) **Connection Type:** Select the type of TCP connection to the I/O adapter.
 - a. **Unicast:** This means the gateway will communicate directly to the I/O adapter's IP address. Set by default.
 - b. **Multicast:** This means the gateway will communicate using a class D IP address. This option requires IGMP snooping and managed switches for proper functionality.
- 7) Select a **Data Type** and enter the number of **Data Elements** that the instance allows for to make the data meaningful. The number of data elements must match the values set by the I/O adapter for the Input Instance requested. See data limits for the various data types below.

	Run Idle Head	er 🗆	RPI	100	50-60000 ms
	Input Instance 0	0-65535		Priority S	cheduled 🔻
		Connection T	ype Unicast	Y	
[Data Type Uint 1	6 🔻	Da	ata Element	s 0
ata Limit		Save F	arameters		
ata Limit	Da	Save F	Parameters	Length	Range
ata Limit	Bit Pack/	Save F ata Type 8 Bit Int/8 Bit Uin	Parameters	Length 4	n Range
)ata Limit	Bit Pack/ 16 Bit Pack/	Save F ata Type 8 Bit Int/8 Bit Uin 16 Bit Int/16 Bit U	earameters	Length 4 2	96 48
ata Limit	Da 8 Bit Pack/1 16 Bit Pack/1 32 Bit Pack/32 Bi	Save F ata Type 8 Bit Int/8 Bit Uin 16 Bit Int/16 Bit U t Int/32 Uint/32 B	earameters t int it Float	Length 4 2 1	1 Range 96 48 24



Configuring Output Instance

Follow these steps to manually configure the Output Instance.

- 1) Select **View Output Instance** if not already selected.
- 2) **Run Idle Header**: Check this box if the I/O adapter's data contains information about the validity of the output data. Default value is checked since most devices use this.
- 3) **Request Packet Interval (RPI):** This is the amount of time between each read/write request to the adapter. If this value is faster than the adapter supports, an error will occur.
- 4) **Output Instance:** This is the output instance defined by the I/O adapter device. This must match for proper communication.
- 5) **Priority:** Select the appropriate value as defined by the I/O adapter. Default value is scheduled.
- 6) **Connection Type:** Select the type of TCP connection to the I/O adapter.
 - a. **Unicast:** This means the gateway will communicate directly to the I/O adapter's IP address. Set by default.
 - b. **Multicast:** Not supported for this direction.
- 7) Select a **Data Type** and enter the number of **Data Elements** that the instance allows for to make the data meaningful. The number of data elements must match the values set by the I/O adapter for the Output Instance requested. See data limits for the various data types below.

Output Inst	ance (460ECMM	to Ethe	rNet/IP Adap	oter)			
		Run Idle Header 🔽				RPI 100	50-60000 ms	
	Out	ut Instance 0 0-65535 Priority Scheduled ~						
		Connection Type Unicast V						
		Data Type Uint 16 V Data Elements 0						
Data Limit	Save Parameters							
		Data Type Length Range						
		8 Bit Pack/8 Bit Int/8 Bit Uint 496						
		16 Bit Pack/16 Bit Int/16 Bit Uint 248]
		32 Bit Pack	/32 Bit Int	t/32 Uint/32 Bit	Float	1:	24	
		64 Bit I	nt/64 Bit	Uint/64 Bit Floa	at	6	2	1



BACnet/IP Server Configuration

Click the **BACnet/IP Server** button to access the primary configuration page for this device.

- 1) Select which **Network Interface** to use for this BACnet/IP connection. If using single port hardware, the Network Interface will default to Ethernet Port only.
- 2) Enter a **Device Label**. This is an internal device alias used during data mapping.
- 3) Enter the decimal value of the **UDP Port** that the gateway will communicate on. Default is 47808 (0xBAC0)
- 4) Enter a unique **Instance** identifier for the gateway. This value must be unique on the BACnet/IP network.
- 5) **Inactivity Timeout:** Enter the amount of time, in milliseconds, the gateway should wait before a timeout state is declared. If the BACnet/IP Client does not initiate communication within this time frame the BACnet/IP LED will flash red and the timeout counter will increment. Enter zero to disable this feature.
- 6) Enter a **Name**, **Description**, and **Location** for the gateway. These are used to identify the gateway on the BACnet/IP network.
- 7) **Bit Pack:** Select the formatting of the binary input/output. Automap will use this packing size to map binary objects to/from the other protocol.

BACnet/IP Server Configuration			Help
Network Interface:	Ethernet	1 (192.168.47.206) 🔻	
Device Label:	BS01		
UDP Port:	47808	1-65535 (Recommend 47808	-47823)
Instance:	50	0-4194302	
Inactivity Timeout:	3000	0-Disable; 1000-65000 ms	
Name:	Gateway	Name	
Description:	Gateway	Description	
Location:	Gateway	Location	
Bit Pack:	1 Bit ▼	Binary Input/Output Only	
Save Pa	rameters]	



BACnet/IP Server Configuration-Data Groups

The bottom area of the BACnet/IP Server-Configuration page lets you configure multiple objects for read and write groups.

There are two ways to configure this protocol:

- 1) Auto-Configure Group by Data Type (Default)
- 2) Manual Configure Mode

NOTE: You may go back and forth between modes, but when reverting from Manual Configure Mode to Auto-Configure Mode, all changes made in Manual Mode will be discarded.

		Auto-Configure Group by	y Data Type ▼	
Data Groups	(460 to	BACnet/IP)		
Data	Group	Object Type	Starting Object	# of Objects
	1	Analog Input (32 Bit Float)	1	1
	2	Binary Input	1	8
	3	CharacterString Value	1	0
	-			
Data Groups	Group	Object Type	Starting Object	# of Objects
Data Groups	Group	Object Type Analog Output (32 Bit Float)	Starting Object	# of Objects
Data Groups	Group	Object Type Analog Output (32 Bit Float) Binary Output	Starting Object	# of Objects 500 0

The setup in the example above will give you the following result:

- 1 AI is created with the address of AI1
- 8 Bis are created with the addresses BI1 through BI8
- 500 AOs are created with the addresses AO1 through AO500
- 1 CSV is created with the address of CSV51

Object Type # of Objects Analog Input / Analog Output 1200 Binary Input / Binary Output 1600

CharacterString Value

50



BACnet/IP Server Configuration: Auto-Configure Mode (Default)

While in Auto-Configure Mode, no fields under the data groups cn be edited. Auto-Configure Mode looks at the other protocol and then configures the data groups below to match. BACnet/IP points will be defined after the other protocol is configured.

Within the BACnet/IP server, the data will automatically be configured according to the following rules:

- Any 8 Bit Signed/Unsigned, 16 Bit Signed/Unsigned, 32 Bit Signed/Unsigned, 64 Bit Signed/Unsigned, 32 Bit Float, and 64 Bit Float data will be mapped as Analog Objects.
- 2) Any Coils or 1/8/16/32 Bit Bianry Packs will be mapped as **Binary Objects**.
- 3) Any String Data Types will be mapped as **CharacterString Value Objects**.
- 4) The Input or output object direction depends on whether it is configured as a read or write on the other protocol.
- 5) If the other protocol exceeds the number of analog, binary, or Character String value objects the BACnet/IP server supports (see limits on webpage), then nothing will be mapped. You will see the # of Objects column remain at 0 and the main page will display the following error:

ERROR bs 460 Re-initialization (Auto-Config Failed -9)

 To fix this error, simple decrease the amount of data you configured on the other protocol so that the max number of BACnet/IP objects is not exceeded or call customer support to increase the limits.



BACnet/IP Server Configuration: Manual Configure Mode

- 1) To transition from Auto-Configure Mode to Manual Configure Mode, click the dropdown in the middle of the BACnet/IP Server Configuration page and select Manual Configure.
 - a. When prompted, click **OK** to confirm mode change or **Cancel** to remain in Auto-Configure Mode.



b. Once OK is clicked, there are two options for how to proceed.



- i. To keep the current data groups and object properties (includes any default object names, units and COV) that are already configured, press **OK**.
 - You would want this option if you are adding additional data groups or you want to modify the data group(s) that already exist.
- ii. To delete the current data groups and object properties (includes any default object names, units and COV) that are already configured, press **Cancel**.
- 2) For each object type in the read and write data groups sections, select the number of objects that the server will support.
- 3) Each object has its starting object number sequentially identified at one. The field may be modified.
- 4) When done, click the **Save Parameters** button.



BACnet/IP Server Object Configuration – Analog Objects

Click the **Set Up BACnet Names, Units, and COV** button at the bottom of the BACnet/IP Server Configuration page to access the Object Configuration page.

When in Auto-Configure Mode, these fields are not configurable.

BACr	et/IP Server O	bject Configuration			
Analog	Input	~	<	1 >>	
Object	Group	Name	Unit Category	Unit	COV
1	G01 🗸	Load IA	Electrical 🗸	A: (amperes)	1.000000
2	G01 🗸	Load IB	Electrical 🗸	A: (amperes) 🗸	1.000000
3	G01 🗸	Load IC	Electrical 🗸	A: (amperes)	1.000000
4	G01 🗸	Total Active Power	Power 🗸	W: (watts) 🗸	1.000000
5	G01 🗸	Fuel Level	Other 🗸	per: (percent) 🗸	1.000000

Follow these steps to customize the analog inputs or outputs in Manual Configure Mode:

- 1) Select **Analog Input** or **Analog Output** from the upper left dropdown menu.
- 2) Select a Group to use.
 - a. These group names are defined on this page under the "Group Name" dropdown menu.
 - b. Use case example: if there are multiple server/slave devices the RTA gateway is monitoring and sending over to the Building Automation System (BAS) to monitor, you can configure the group to represent each device. The image above displays 1 device, if there are 5 total deices then you can call Group 1 "Basement, Group 2 "1st Floor", Group 3 "Roof Top" etc.
- 3) Enter a **Name** to identify this object on the network.
- 4) The combination of **Group** and **Name** should be unique for each point in the gateway.
- 5) Select the **Unit Category** corresponding to the units you want this object to be identified with (optional). Then select the **Unit** from the dropdown menu.
- 6) Set the **COV** (Change of Value) for this object.
- 7) If the BACnet/IP client issues a COV Subscription, the gateway will issue a COV Notification when the Present Value changes by more than the given COV-Value. This value shift can be in a positive or negative direction.



BACnet/IP Server Object Configuration - Binary Objects

Click the **Set Up BACnet Names Units and COV** button at the bottom of the BACnet/IP Server Configuration page to access the Object Configuration page for this device.

Binary Ir	nput	~	<*	1 >>
Objec	t Grou	ıp	1	lame
1	G01	~	BI1	
2	G01	×	BI2	
3	G01	\sim	BI3	
4	G01	~	BI4	
5	G01	×	BI5	
6	G01	×	BIG	
7	G01	\sim	BI7	
8	G01	~	BI8	

When in Auto Configure Mode, These fields are not configurable.

Follow these steps to configure binary inputs or outputs in Manual Configure Mode.

- 1) Select **Binary Input** or **Binary Output** from the upper left dropdown menu.
- 2) Select a **Group** to use.
 - These group names ar defined on this page under the "Group Name" dropdown menu.
- 3) Enter a **Name** to identify this object on the network.
 - The combination of **Group** and **Name** should be unique for each point in the gateway.



BACnet/IP Server Object Configuration – CharacterString Value Objects

Click the **Set Up BACnet Names, Units, and COV** button at the bottom of the BACnet/IP Server Configuration pageto access the Object Configuration page for this device.

When in Auto-Configure Mode, these fields are not configurable.

Characte	erString Value Write 💌	· < 51 >>
Object	Group	Name
51	G01 👻	CSV_W51

Follow these steps to configure CharacterString Value reads or writes in Manual Configure Mode:

- 1) Select **CharacterString Value Read or CharacterString Value Write** from the upper left dropdown menu.
- 2) Select a **Group** to use.
 - a. These group names ar defined on this page under the "Group Name" dropdown menu.
- 3) Enter a **Name** to identify this object on the network.
 - a. The combination of **Group** and **Name** should be unique for each point in the gateway.



BACnet/IP Server Object Configuration – Group Names

Click the **Set Up BACnet Names, Units, and COV** button at the bottom of the BACnet/IP Server Configuration pageto access the Object Configuration page for this device.

When in Auto-Configure Mode, these fields are not configurable.

The **Group Name** is designed to be used when there are multiple BACnet/IP objects that have the same name. This is useful when you have multiple, identical devices connected on the other protocol.

Grou	p Name	*
G	oup # Gro	oup Name
	1 G01	
	2 G02	
	3 G03	
	4 G04	
	5 G05	
	6 G06	
	7 G07	
	8 G08	
	9 G09	
	10 G10	

Follow these steps to configure the Group Names in Manual Configure Mode:

- 1) Select **Group Name** from the upper left dropdown menu.
- 2) For each **Group Name** used in the previous setup, change the name to your desired text. Any names not used do not need to be changed or configured.



BACnet/IP Server Routing Configuration

Click the **Foreign Device Registration** button at the bottom of the BACnet/IP Server Configuration page to access the BACnet Routing Configuration page for this device.

These settings are used when connecting to a BACnet/IP client on a different subnet.

 Foreign Device Registration (recommended): This option can be used ONLY when the BACnet/IP Broadcast Management Device (BBMD) on the other subnet (often integrated into client devices) supports Foreign Device Registration. To use, enter the IP Address of the BBMD device into the gateway and select a Time-To-Live (TTL), the TTL defines how often the gateway should send a message to the BBMD device alerting them of the gateway's presence.

BACnet Routing Configuration		
Foreign Device Registration		
	IP Address: 0.0.0.0 Time-To-Live: 1	0.0.0.0 to Disable 1-3600 s
	Save Parameters	



Mapping - Transferring Data Between Devices

There are 5 ways to move data from one protocol to the other. You can combine any of the following options to customize your gateway as needed.

Option 1 – Data Auto-Configure Mappings: The gateway will automatically take the data type (excluding strings) from one protocol and look for the same data type defined in the other protocol. If there isn't a matching data type, the gateway will map the data to the largest available data type. See Data Auto-Configure section for more details.

Option 2 – String Auto-Configure: The gateway will automatically take the string data type from one protocol and map it into the other. See String Auto-Configure section for more details.

Option 3 – Manual Configure Mappings: If you don't want to use the Auto-Configure Mappings function, you must use the manual mapping feature to configure translations.

Option 4 – Manipulation/Scaling: You can customize your data by using math operations, scaling, or bit manipulation. See Data Mapping-Explanation section for more details.

Option 5 – Move Diagnostic Information: You can manually move diagnostic information from the gateway to either protocol. Diagnostic information is not mapped in Auto-Configure Mappings Mode. See Diagnostic Info section for more details.

Going from Manual Mapping to Auto-Mapping will delete ALL mappings and manipulations configured.



Display Mapping and Values

The Display Data and Display String pages are where you can view the actual data for each mapping that is set up.

Display Data

Click the **Display Data** button to view how the data is mapped and what the values of each mapping are.



Here you will see how each data point (excluding strings) is mapped. To view, select the device from the dropdown menu and click **View** to generate the information regarding that device. Then select either the **Protocol 1 to Protocol 2** or **Protocol 2 to Protocol 1** button, correlating to the direction you wish to see the data.

Display Data	Edit Mapping View as Text
Select a Device Modbus TCP Server IP Address: 0.0.0.0 View	
Protocol 1 to Protocol 2	Protocol 2 to Protocol 1



This page is very useful when verifying that all data is mapped somehow from one protocol to another. If a data point is not mapped, it will display on this page in a yellow highlighted box. The Display Data page will display up to 200 mappings per page, simply navigate to the next page for the additional mapping to display.

Mod	lbus RTU to BACr	iet/IP			BACnet/IP to Modb	us RTU
		I	< 1 > Displaying 1-201 of 3	> 300		
	Modbus RTU	I	460MMBS →→		BACnet/IP	
Name	Valu	ue (Hex)	Manipulation	Name	Value	e (Hex)
400001			> >	AI1		
400002			→→	AI2	Mapping Dis	abled for Point
400003			>>	AI3		

In the above example, we see the following:

- Modbus register 400001 from Slave 1 is being mapped to Al1 on BACnet
- Nothing is being moved from Modbus register 400002 to AI2 on BACnet because the mapping is disabled
- Modbus register 400003 from Slave 1 is being mapped to AI3 on BACnet

NOTE: If a data point is mapped twice, only the first instance of it will show here. EX: If Modbus 400001 & 400040 from Slave 1 are both mapped to Al1, only 400001 will show as being mapped to Al1.

If there are values of "--" on this page, it indicates that the source has not yet been validated and no data is being sent to the destination.

The example below reflects the Modbus to PLC flow of data. The Modbus (left side) is the source and the PLC (right side) is the destination.

- The 460 gateway has received valid responses from Modbus registers 400001- 400005 and therefore can pass the data on to the PLC tag called MC2PLC_INT.
- The 460 gateway has NOT received valid responses from Modbus register 400011 & 400012. As
 a result, the data cannot be passed to the PLC tag ETC01_GN0_INT2 and indicates so by using "- "in the value column of the table.



Display Data	a					Edit Mapping View as Text
Select a Devic	e Modbus T	CP Server IP Addres	s: 10.1.16.16	View		
	Modbus TCP/	P to PLC			PLC to Modbus	TCP/IP
			<< Displayin	1 >> ng 1-7 of 7		
	Modbus	TCP/IP	460E	тсмс	PLC	
Name		Value (Hex)	Manip	ulation Name	Valu	ie (Hex)
400001	15	0x000F	→→	ETC01 MC2PLC_INT[0]	15	0x000F
400002	1495	0x05D7	→ →	ETC01 MC2PLC_INT[1]	1495	0x05D7
400003	1	0x0001	→ →	ETC01 MC2PLC_INT[2]	1	0x0001
400004	23	0x0017	→ →	ETC01 MC2PLC_INT[3]	23	0x0017
400005	3	0x0003	→ →	ETC01 MC2PLC_INT[4]	3	0x0003
400011			→ →	ETC01 ETC01_G2N0_INT[0]		
400012			→ →	ETC01 ETC01_G2N0_INT[1]		

To view the actual data mappings, click the **Edit Mapping** button. For more details, see the Data Mapping-Explanation section.

To view the data mappings purely as text, click the **View as Text** button. For more details, see the View Data Mapping as Text section.



Display String

Click the **Display String** button to view what the values of each Parsing and/or Concatenating strings are, you can also click on the Edit Mapping to view the mapping of each string.

	Main Page
CON	FIGURATION
	Network Configuration
	Port Configuration
	ASCII
	Allen-Bradley PLC
_	Display Data
I Г	Display String
	Restart Now
DIAG	NOSTICS
	-Select-
отн	ER -Select-

To view the source or destination groups from a string, click the dropdown menu to generate the information regarding that device. The string data will be displayed in both Hex and ASCII (only the ASCII data is sent). The example below shows data that is coming from the source device. A group will be displayed for each Parsing/Concatenating String field that is configured.

Dis	play S	tring	g												Edit Mapping View as Text
Sele	ct a Gro	oup [Src:	Lin	e 1	Bai	COC	le S	can	ner		~	and a String Barcode Scanner ~	(11 bytes)	
	0000:	68	65	6C	6C	6F	20	77	6F	72	6C	64	hello world		

In the Group drop down, "Line1" is defined on the ASCII Device configuration page and "Barcode Scanner" is defined in the ASCII Parsing configuration.

Enable	nable ASCII Device 1							
Port	Port 1 (DB9) 🗸		Device Label Line1					
LED Inactivity	0 0-60000 s	Opera	ation Mode Mark Data New	on New Mess	age 🗸			

Field	Start Location	Length	Data Type	Internal Tag Nam	ne
1:	1	0	String 🗸	Barcode Scanner	


If there are values of "Data Not Valid "on this page, it indicates that the source has not been validated yet and no data is being sent to the destination.

Display String	Edit Mapping
	View as Text
Select a Group Src: Line 1 Barcode Scanner and a String Barcode Scanner (0 bytes)	
Data Not Valid	

NOTE: You can view the whole string data by clicking on **Diagnostics Info** drop down and navigating to ASCII Diagnostics page. You will also have to select the port you want to view in the dropdown below ASCII.

Diagnostics		
ASCII	View	
Port 1 (DB9) V	View	

To view the string mappings, click the **Edit Mapping** button. For more details see the **String Mapping-Explanation** section.

Display String	Edit Mapping
	view as Text
Select a Group Src: Line 1 Barcode Scanner v and a String Barcode Scanner v (11 byte	es)
0000: 68 65 6C 6C 6F 20 77 6F 72 6C 64 hello world	

NOTE: Only String data types can be mapped to another String data type.

String Mapping Configuration		Help	
Manual Configure # of Mappings to Configure: Description Description Description Description Description Description Description Description Description Description Description Description Description Descripti			
C Enable Mapping 1			
Source Destination			
Group: Line 1 Barcode Scanner	• • 🔶 • •	Group: ETC01 ETC01_G2N0_STRIN V String: ETC01_G2N0_STRING V	

To view the string mappings purely as text, click the **View as Text** button. For more details see the **View String Mapping** as Text section.

Real Time Automation, Inc.



Display String use case

Sending a message of "RTA,Support,Rocks" from an ASCII device to the RTA unit. The ASCII Parsing Configuration would look like my example below. There are more detailed examples of what all the fields represent in the ASCII Parsing section.

	ASCII Device 1 (Line1)				
Max	Number of Fields	Is: 3 1-50 Min Number of Fields: 1 1-50			
		Parsing D	Delimiter:	, 44 0x2c	~
	Update Fields				
Field	Start Location	Length	Dat	ta Type	Internal Tag Name
1:	1	0	String	~	Header 1
2:	1	0	String	~	Header 2
3:	1	0	String	~	Header 3

The message is broken up into 3 "Groups" or Parsing fields.

Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 1 ~	and a String Header 1 V (3 bytes)	
0000: 52 54 41	RTA	
Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 2	and a String Header 2 V (7 bytes)	
0000: 53 75 70 70 6F 72 74	Support	
Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 3	and a String Header 3 V (5 bytes)	
0000: 52 6F 63 6B 73	Rocks	

To view the Entire message, click on the Diagnostic drop down, select Diagnostics Info. Select ASCII, click view, select your Port. Whole data will be in the Last Message Sent Diagnostic box.

Diagnostica	Last Message Sent (17 bytes)	
Diagnostics	0000: 52 54 41 2C 53 75 70 70	6F 72 74 2C 52 6F 63 6B RTA,Support,Rock
ASCII View Port 1 (DB9) View	0010; 75	5

Real Time Automation, Inc.



Data and String Mapping – Auto-Configure

The Auto-Configure function looks at both protocols and will map the data between the two protocols as best as it can so that all data is mapped. Inputs of like data types will map to outputs of the other protocols like data types first. If a matching data type cannot be found, then the largest available data type will be used. Only when there is no other option is data truncated and mapped into a smaller data type.

If the Auto-Configure function does not map the data as you want or you want to add/modify the mappings, you may do so by going into Manual Configure mode.

The following are examples of the Auto-Configure function.

1) This example shows a common valid setup.



- a. Both Source values were able to be mapped to a corresponding Destination value.
- 2) This example shows how Auto-Configure will make its best guess.

Source	Destination
8-bit Sint	8-bit Sint
16-bit Int	16-bit Int
32-bit Uint	32-bit Uint
32-bit Float	32-bit Uint

 a. The 32-bit Float from the Source location could not find a matching Destination data-type. After all other like data types were mapped, the only data type available was the 2nd 32-bit Uint data type. Auto-Configure was completed even though the data in the Float will be truncated.



Data Mapping – Explanation

Below are the different parts that can be modified to make up a data mapping.



- 1) Enable (red box above): Check to enable mapping. If not checked, this mapping is skipped.
- 2) Source Field (yellow box above):
 - a) Group Select the data group you set up in the protocol config to use for this mapping.
 - b) Start This is the starting point for this mapping.
 - c) End This is the final point to be included for this mapping.
- 3) Manipulation Area (green box above):
 - a) Enable the Data Manipulation. This can be enabled for any mapping.
 - b) Click Add Math Operation for each operation needed. Up to 3 are allowed unless you are using the Scale, Set Bit, or Invert Bit functions. If using Scale, Set Bit, or Invert Bit, then only 1 operation is allowed.
 - c) Select the Operation(s) to perform.
 - i) Math Operations are performed in the order they are selected.
 - ii) If more than one point is selected on the source, the Math Operations will be performed on every point.
 - d) Enter the value(s) for the operation.



Example of Add (similar for Subtract, Multiple, Divide, and MOD). This will add a value of 10 to the source field before it is written to the destination field.

	Enable	Manip	ulation
	Scale		*
Src 🛛	1	to [10
Dst	1	to	100

Example of Scale. This will scale the source values from 1-10 into 1-100 for the destination.

Enable Manipulation		
Set B	Bit 💌	
Src	Dst	
0	5	
(0-15)	(0-15)	

Example of Set Bit (similar to Invert Bit). This will take the value of the Oth source bit and copy it into the value of the 5th destination bit.

- 4) Destination Field (blue box above):
 - a) Group Select the data group you set up in the protocol config to use for this mapping.
 - b) Start This is the starting point for where the data is being stored.
 - c) End The End point is derived from the length of the source and cannot be modified.
 - Real Time Automation, Inc.

1-800-249-1612



Data Mapping – Adding Diagnostic Information

Data Mapping offers 5 different types of information in addition to any scan lines specified for each protocol.

IMPORTANT NOTE: Only add Diagnostic Information **AFTER** both sides of the gateway have been configured. If changes to either protocol are made after diagnostic information has been added to the mapping table, it is necessary to verify all mappings. Remapping may be necessary.

1) Temporary Ram (Int64)

- a) This offers five levels of 64bit Integer space to assist in multiple stages of math operations. For example, you may wish to scale and then add 5. You can set up a single translation to scale with the destination as the temporary ram. Then another translation to add 5 with the source as the temporary ram.
- b) The gateway will automatically convert the Source to fit the Destination, so there is no need for Int 8, 16, 32 since the 64 may be used for any case.

I Enable	Mapping 1		
Source	Enable Manipulation	Destination	
Group: Temporary Ram0 (Int64) 💌 Start: Ram0 💌 End: Ram0 🔍	Scale Image: Scale Src 1 to 10 Dst 1 to 100	Group: Temporary Ram0 (Int64) 💙 Start: Ram1 💌 End: Ram1	
I Enable	Mapping 2		
Source	Enable Manipulation	Destination	
Group: Temporary Ram0 (Int64)		Group: Temporary Ram0 (Int64)	

In this example, Ram0 is scaled into Ram1. Ram1 is then increased by 5 and stored into Ram2. Ram0 and Ram2 could be considered a source or destination group.

2) Temporary Ram (Double)

a) This is like the Temporary Ram (Int 64), except manipulations will be conducted against the 64bit floating point to allow for large data.

3) Ticks Per Second

a) The gateway operates at 200 ticks per second. This equates to one tick every 5ms. Thus, mapping this to a destination will give easy confirmation of data flow without involving one of the two protocols. If data stops on the destination end, then the RTA is offline.

Enable Mapping 1			
Source	Enable Manipulation	Destination	
Group: Ticks Since Powerup (Uint32) Start: Since Powerup End: Since Powerup	• • -> • •	Group: BS01 Al1 (Float) Start: Al1 Contemporation Al1	

Real Time Automation, Inc.



4) Heartbeat 100ms Update

a) The Heartbeat 100ms Update variable can be used as a heartbeat that updates once every 100ms. The variable starts at 0 on gateway startup and increments by 1 every 100ms. This can be mapped into a destination on one of the available protocols to monitor the gateways connection status. If the value stops updating every 100ms the gateway is offline.

Enable Mapping 1						
Source	Source Enable Manipulation Destination					
Group: Heartbeat 100ms Update (Uir ~) Start: 100ms Update ~) End: 100ms Update ~)	• • • • •	Group: ETC01 Heartbeat (Int32) v Start: Heartbeat v End: Heartbeat				

5) Heartbeat 1000ms Update

a) The Heartbeat 1000ms Update variable can be used as a heartbeat that updates once every 1000ms. The variable starts at 0 on gateway startup and increments by 1 every 1000ms. This can be mapped into a destination on one of the available protocols to monitor the gateways connection status. If the value stops updating every 1000ms the gateway is offline.

Enable Mapping 1						
Source	Source Enable Manipulation					
Group: Heartbeat 1000ms Update (Ui 🗸			Group: ETC01 Heartbeat (Int32)			
Start: 1000ms Update V	0	$\circ \longrightarrow \circ \circ$	Start: Heartbeat			
End: 1000ms Update V			End: Heartbeat			

6) XY_NetBmpStat

a) If a protocol is a Client/Master, there is a Network Bitmap Status that is provided on the Diagnostics Info page under the Variables section.

Modbus RTU Master	
Device Status Connected and Running	
LED Status Connection Status:	Connected
Variables	
Network Bitmap Status:	0x0000001f

- b) Since a Client/Master may be trying to communicate with multiple devices on the network, it may be beneficial to know if a Server/Slave device is down. By using this Network Bitmap Status, you can expose the connection statuses of individual devices. Values shown are in HEX.
 - i) 0x0000002 shows that only device 2 is connected
 - ii) 0x00000003 shows that only devices 1 and 2 are connected
 - iii) 0x0000001f shows that all 5 devices are connected (shown in image above)

42



c) There are multiple ways to map the NetBmpStat.

Option 1: Map the whole 32bit value to a destination. Example below shows the NetBmpStat is going to an Analog BACnet object. Using a connection of 5 Modbus Slave devices Al1 will show a value of 31.0000. Open a calculator with programmer mode and type in 31, this will represent bits 0 - 4 are on. This mean all 5 devices are connected and running.

If using an AB PLC with a Tag defined as a Dint, then expand the tag within your RSlogix software to expose the bit level and define each bit as a description such as device1, device2, etc.

Enable Mapping 1						
Source Enable Manipulation Destination						
Group: MM NetBmpStat (Uint32) Start: NetBmpStat ContempStat Contemp	•	• -> • •	Group: BS01 Al1 (Float) Start: Al1 Contemporation Al1			

Option 2: You can extract individual bits from the NetBmpStat by using the Set Bit Manipulation and map those to a destination. You'll need a mapping for each device you want to monitor. Example below shows Modbus device 2 (out of 5) is being monitor to a BACnet Binary Object. You can define the object in the BACnet Name configuration.

Senable Mapping 1						
Source	Enable Manipulation	Destination				
Group: MM NetBmpStat (Uint32) Start: NetBmpStat End: NetBmpStat	Set Bit V Src Dst 1 0 (0-31) (0)	Group: BS01 BI1 (Bit1) Start: BI1 End: BI1				



7) Status_XY

a) There are two Statuses provided, one for each protocol. This gives access to the overall status of that Protocol. Each Bit has its own meaning as follows:

Commo	on Status:	0x000000FF	(bit 0-7)1 st byte
Hex:	Bit Position:	Decimal:	Explanation:
0x00 0x01 0x02	0 0 1	0 1 2	if we are a Slave/Server if we are a Master/Client connected (0 not connected)
0x02 0x04 0x08	2	4	first time scan idle (usually added to connected)
0x10 0x20 0x40 0x80	4 5 6 7	16 32 64 128	running (usually added to connected) bit not used recoverable fault
0x80	7	128	nonrecoverable fault

For this example, the ETC Status is mapped to a PLC tag called PLC_Status

	Modbus TCP/IP to PLC		
460ETCMC €€	Modbus TCP/IP		
) Manipulation Na	me Value (Hex)		
00000013 ET Sta	C 19 0x0000013		
013 (19 decimal), here is t	he break down		
mal Explanat	on		
if we are a N	laster/Client		
connected (0	not connected)		
running (usua	lly added to connected)		
0x0000FF00	(bit 8-15)2 nd byte		
ecimal: <u>Explanat</u>	ion:		
0 local o	control		
256 remotel	y idle		
512 remotel	y faulted		
1,024 idle du	le to dependency		
2,040 Iduited	due to dependency		
0x00FF0000 (bit 1	6-23)3 rd byte		
ecimal: Explanat			
	ion:		
65,536 recover	<u>ion:</u> able fault - timed out		
	460ETCMC ▲ ▲ ▲ ▲ ET 00000013 ▲ ▲ ▲ ET 0013 (19 decimal), here is to b ET State 0013 (19 decimal), here is to Explanati if we are a M Connected (0 running (usual 0x0000FF00 0 connected (0 running (usual 0 connected (0 running (usual 0x0000FF00 0 connected (0 running (usual 0 connected (0 running (usual 0x0000FF00 0 connected (0 running (usual 0 connected (0 running (usual 0x0000FF00 0 connected (0 running (usual 0 connected (0 running (usual 0x0000FF00 0 local co connected (0 running (usual 0 0 10cal co remotel connected (0 running (usual 0 0 10cal co remotel connected (0 running (usual 0 0 10cal co remotel connected (0 running (usual 0 0 10cal co remotel connected (0 running (usual 0 0 10cal co remotel connected (0 runnin		

Real Time Automation, Inc.

1-800-249-1612



Non-Recoverable Faults 0xFF000000 (bit 24-31)4th byte

Hex:	Bit Position:	Decimal:	Explanation:
0x01	24	16,777,216	nonrecoverable fault - task fatal err
0x02	25	33,554,432	nonrecoverable fault - config missing
0x04	26	67,108,864	nonrecoverable fault - bad hardware port
0x08	27	134,217,728	nonrecoverable fault - config err
0x10 0x20	28 29	268,435,456 536,870,912	Configuration Mode No Ethernet Cable Plugged In

For this example, the MC Status is mapped to a PLC tag called MC_Status

	PLC to Modbus TC	P/IP			Modbus TCP/IF	P to PLC
	PLC		460ETCMC		Modbus TC	P/IP
Name	Valu	ie (Hex)	Manipulation	Name	Val	ue (Hex)
MC_Status	65601	0x00010041	44	MC Status	65601	0x00010041

Example: MC Status is 0x00010041 (65601 decimal), here is the break down, we know that bytes 1 and 3 are being used, so here is the break down,

Commo	n Status	:	
Hex:	<u>Bit:</u>	Decimal:	Explanation:
0x01	0(on)	1	if we are a Master/Client
0x40	6(on)	64	recoverable fault
Recov <u>Hex:</u> 0x01	erable F <u>Bit:</u> 16	aults: Decimal: 65,536	<u>Explanation:</u> recoverable fault – timed
0x0100	41	65 601	

Total:



String Mapping – Explanation

Below are the different parts that can be modified to make up a string mapping.

String data types can only be mapped to other string data types. There is no manipulation that can be done on the string.

Z E	nable			Mappir	ig 1	3.
	Source					Destination
Grou String	p: Line 1 Barcode Scanner j: Barcode Scanner	>	•	• 🔶 •	•	Group: ETC01 ETC01_G2N0_STRIN♥ String: ETC01_G2N0_STRING ♥

- 1) Enable (red box above): Check to enable mapping. If not checked, this mapping is skipped.
- 2) Source Field (yellow box above):
 - a) Group Select the string data group you set up in the protocol config to use for this mapping.
 - b) String This is the string used for this mapping.
- 3) Destination Field (green box above):
 - a) Group Select the string data group you set up in the protocol config to use for this mapping.
 - b) String This is the string where the data is being stored.



Mapping - Auto-Configure Mode to Manual Configure Mode

To transition from Auto-Configure Mapping Mode to Manual Configure Mode, click the dropdown at the top of the Mapping Configuration page and select Manual Configure.

After you click this button, you will be prompted to confirm if this is really what you want to do.



Click **OK** to proceed to Manual Configure Mode or click **Cancel** to remain in Auto-Configure Mappings Mode.

Once OK is clicked, there are 2 options on how to proceed from here.

Message from webpage	×
Press OK to keep the current Mapping Press Cancel to Delete all Mappings.	s.
OK	cel

- 1) To keep the mappings that are already configured press **OK**.
 - a) You would want this option if you are adding additional mappings or you want to modify the mapping(s) that already exist.
- 2) To delete the mappings that are already there and start over press **Cancel**.

To modify the number of mappings, enter a number in the text field next to **# of Mappings to Configure** and click the **Set Max # of Mappings** button. You can always add more mappings if needed.



Mapping - Manual Configure Mode to Auto-Configure Mode

To transition from Manual Configure Mode to Auto-Configure Mapping Mode, click the dropdown menu at the top of the Mapping Configuration page and select Auto-Configure Mappings.

Message fr	rom webpage
?	Press OK to delete the current Mappings and go back to Auto-Configure Mappings mode. Press Cancel to keep Mappings and remain in current Mode.
	OK Cancel

Click **OK** to proceed to delete all current mappings and go back to Auto-Configure Mappings Mode. Click **Cancel** to keep all mappings and remain in Manual Configure Mode.

NOTE: Once you revert to Auto-Configure Mapping Mode there is no way to recover the mappings you lost. Any mappings you previously have added will be deleted as well.



View as Text

Data Mapping

The View as Text page displays the point to point mapping(s) you set up in the Data Mapping section. This will also display any manipulation(s) that are configured.

Each line on this page will read as follows:

Mapping *number*: *source point* **Len**: *Number of points mapped* -> *manipulation* (*if blank then no manipulation*) -> *destination point*

If you are looking for a specific point to see if it is mapped, you can do a find in this text box for your point in question. Example: you defined 20 Registers starting at register 1 and want to see if 400011 is mapped. If it is not in this text box, then it is not mapped, and no data will be transferred.

This is the text display for the example shown under the *Data Mapping- Adding Diagnostic Information* section.

				Da	ita I	Mapping					
Mapping 1: Mapping 2:	Temporary Temporary	Ram0 Ram1	Len: Len:	1 1	-> ->	1:10 Scale t Add 5 ->	0	1:100 -> Temporary Ram2	Temporary	Ram1	

String Mapping

The View as Text page displays the string mapping(s) you set up in the String Mapping section.

Each line on this page will read as follows:

Mapping number: source point -> Copy -> destination point

If you are looking for a specific point to see if it is mapped, you can do a find in this text box for your point in question. Example: you defined 20 String Tags in the PLC and want to see if "Test_String" in the Logix PLC is mapped. If it is not in this text box, then it is not mapped, and no data will be transferred.

		String Mapping		
Mapping 1:	Logix Test_String	-> Copy ->	MCO2 400001	

Real Time Automation, Inc.



Base Triggering – Data Validiation Triggering

With Base Triggering, you will be marking data as "Invalid" and force RTA Master/Controller/Client protocols to read all the read data points sources until ALL source protocols data is valid. You will be able to utilize the Handshake to map over to Technology Trigger and/or back over to your source protocol for reference.

How does this work?

- 1) Map the Triggering Variable (Source) over to Trigger # (Dest).
- 2) If Trigger # value changes states mark all Trigger # protocols read data as "Invalid".
- 3) Read all source read data points until ALL source read data is valid.
- 4) Handshake # value is set equal to Trigger # value.
- 5) Map Handshake # to reference data point. Note: # is an internal reference to the Server/Slave number you are settings up. ex. RTA Server/Slave products can only be Trigger 1 and Handshake 1 since we are only 1 device. If RTA is a Master/Client, then you can have a Trigger# for each server/slave connected too.

How do you set this up?

In this example I'm using a 460MCBS. My Building Automation System wants to verify that all data read from Modbus TCP/IP Server is valid.

1) Add an extra Analog Output for your Trigger. This tells the RTA to mark all data invalid.

Nrite Data	Groups (BACn	et/IP to 460MCBS)		
	Data Group	Object Type	Starting Object	# of Objects
	1	Analog Output (32 Bit Float)	1	21
	2	Binary Output	1	0
	3	CharacterString Value	51	0

a) You can define AI21 as your validation name in the Setup BACnet Names Configuration.

		Setup BACn	et Names, Units, and	1 COV		
21	G01 🗸	Data Validation Trigger	Other 🗸	no-units	~	1.000000

2) Add another Analog Input as reference for when data has been validated. When you write from AO21 to validate data, the RTA will reply to AI40 saying "validation complete".

Data Group	Object Type	Starting Object	# of Objects
1	Analog Input (32 Bit Float)	1	40
2	Binary Input	1	0
3	CharacterString Value	1	0



40	G01 🗸	Data Validation Result	Other 🗸	no-units	✔ 1.000000

- 3) Within the Data Mapping page manually add 2 additional mappings.
- 4) The first mapping is going to be the Data Validation Triggering. AO21 will write to the RTA, MC Trigger 1 will mark data invalid.

C Enable			Mapping	g 2		
Source			Enable Manipulat	ion	Destination	
Group: BS01 AO1 (Float)	~				Group: MC Trigger 0 (Uint16)	~
Start: A021	~	0	• <> •	•	Start: Trigger 1	~
End: AO21	~				End: Trigger 1	

5) The second mapping, the MC Handshake will increment that all data is validated and write to Al21 "all data is validated". The value of Al40 and AO21 should be the same.

C Enable			Mapping	3	
Source		Enable N	Manipulat	ion	Destination
Group: MC Handshake 0 (Uint16) 🗸		(Group: BS01 Al1 (Float)
Start: Handshake 1 🗸	•	0	\Rightarrow •	•	Start: AI40 🗸
End: Handshake 1 🗸		(End: AI40



Security Configuration

To setup security on the 460 gateway, navigate to **Other->Security Configuration**. You can configure Security for 3 administrators, 5 users, and 1 guest.

THIS IS NOT A TOTAL SECURITY FEATURE

The security feature offers a way to password protect access to diagnostics and configuration on the network. The security feature does not protect against "Air Gap" threats. If the gateway can be physically accessed, security can be reset. All security can be disabled if physical contact can be made. From the login page, click the Reset Password button twice. You will be forced to do a hard reboot (power down) on the gateway within 15 minutes of clicking the button. This process should be used in the event a password is forgotten.

Note: Only Admins have configuration access to all web pages.

- Log Out Timer: The system will automatically log inactive users off after this period of time.
 NOTE: A time of 0 means that the user will not be automatically logged off. Instead, they must manually click the Logout button.
- 2) Username: Enter a username, max of 32 characters.
- 3) Password: Enter a password for the username, max of 32 characters, case sensitive.
 - a. Re-enter the Password
- 4) E-mail: In case the password was forgotten, a user can have their password e-mailed to them if e-mail was configured.
- 5) Hint: A helpful reminder of what the password is.

min Co	nfiguration				
Admin	Username	Password	Re-enter Password	Email	Hint
1				Not Configured	
2				Not Configured	
3				Not Configured	
ser Con	figuration	Admi	in Contact Information	on	
ser Con User	figuration Username	Adm	in Contact Information Re-enter Password	Email	Hint
ser Con User	figuration Username	Adm	in Contact Information Re-enter Password	Email Not Configured	Hint
Ser Con User 1 [2]	figuration Username	Adm Password	Re-enter Password	Email Not Configured Not Configured	Hint
Ser Con User 1 [2 [3]	figuration Username	Adm Password	Re-enter Password	Email Not Configured Not Configured Not Configured	Hint
Ser Con User 1 [2 [3 [4]	figuration	Adm Password	Re-enter Password	Email Not Configured Not Configured Not Configured Not Configured Not Configured Not Configured	Hint

Real Time Automation, Inc.



Security Configuration-Security Levels

Each webpage in the gateway can have a separate security level associated with it for each user.

Security Levels:

- 1) **Full Access**: Capability to view and configure a web page.
- 2) View Access: Capability to view a web page, but cannot configure parameters.
- 3) **No Access**: No capability of viewing the web page and page will be removed from Navigation.

2: Web Page	Security
4: All Web Pages	No Access 🖌 Set
5: t	
Web Page	Security
Main Page	Full Access 💙
Device Configuration	Full Access 💙
Port Configuration	Full Access 💙
BACnet/IP Server	Full Access 💙
Modbus RTU Master	Full Access 🗸
View Mapping	Full Access 🗸
Mapping	Full Access 💙
Setup LED's	Full Access 💙
Diagnostic Info	Full Access 💌
Logging	Full Access 🗸
Display Data	Full Access 💌
Export Configuration	Full Access 💌
Import Configuration	Full Access 💌
Save As Template	Full Access 💌
Load From Template	Full Access 💌
Utilities	Full Access 😽
Email Configuration	Full Access 💌
Alarm Configuration	Full Access 🗸
String Mapping	Full Access 🗸
View String Mapping	Full Access 🗸
Display String	Full Access V



Security - Log In

Username: Name of the user to login.

Password: Password of the user to login.

Log In: If login is successful, the user will be redirected to the Main Page.

Send Password to Email: Sends the specified User's Password to the email configured for that user.

Display Hint: Displays the hint specified for the User if one was set up.

Reset Password: This is used to reset security settings. Confirm reset password must be selected to confirm this action. Once confirmed, there is a 15 minute window to do a hard reset of the gateway by physically removing and restoring power from the gateway. Once power is restored, you may navigate to the IP address of the gateway as normal.

Applic	ation Description
Username:	Admin
Password:	
Display Hint	Log In Reset Password

Security - Log Out

Once a user is done with a session they may click **logout** at the top of any page. The user may also be logged out for inactivity based off of the Log Out Timer specified during the configuration.



Closing the browser is not sufficient to log out.



Email Configuration

To setup e-mails on the 460 gateway, navigate to **Other->Email Configuration**.

You can configure up to 10 email addresses.

- 1) SMTP Mail Username: The email address that the SMTP server has set up to use.
- 2) SMTP Mail Password: If authentication is required, enter the SMTP Server's password (Optional).
- 3) SMTP Server: Enter the Name of the SMTP Server or the IP Address of the Server.
- 4) From E-mail: Enter the e-mail that will show up as the sender.
- 5) To E-mail: Enter the e-mail that is to receive the e-mail.
- 6) E-mail Group: Choose a group for the user. This is used in other web pages.

Click the **Save Parameters** button to commit the changes and reboot the gateway.

Email Configuration Help						
Number of Emails to Configure: 1 0-10 Setup Email(s)						
User	SMTP Mail Username	SMTP Mail Password	SMTP Server	From Email	To Email	Email Group
1						Group A 👻
			Save Parameter	ers		
			Send Test Ema	il(s)		



Alarm Configuration

To setup alarms on the 460 gateway, navigate to **Other->Alarm Configuration**.

1) Alarm Delay upon Powerup: At Powerup, the gateway will have values of '0' stored for all data. This may cause alarms to trigger before these values are updated by the mating protocols. Set this field to provide needed time to update fields before considering values for alarms.

Alarm Configuration				Help
	Alarm Delay u	upon Powerup:	0 0-3600 s	
	# of Alarm:	s to Configure: Set Max # Ala	1 0-100	
		< <u>1</u>		
🗹 Enable		ŀ	Alarm 1	
Data Point	Set Error	Clear Error	Alarm Name	Email
Data Point Ticks Since Powerup (Uint32) Ticks Since Powerup	Set Error >= 1000	Clear Error	Alarm Name Gateway_test	Group A
Data Point Ticks Since Powerup (Uint32) Ticks Since Powerup	Set Error >= 1000	Clear Error	Alarm Name Gateway_test	Group A

- 2) Enter the number of alarms to configure and click **Set Max # Alarms** to generate those lines.
- 3) In the Data Point Section:
 - a. Top dropdown: select the Data Group. This dropdown menu will contain all groups that go from the gateway to the network.
 - b. Lower dropdown: select the Data Point's Specific Point. This is used to select which point in the group will be monitored for alarms.
- 4) In the Set Error Section:
 - a. Select the Set Error Operation in the top dropdown menu. Available options are <, >, <=, >=,
 !=, ==, and Change of State (COS). This is the operation that will be used to compare the
 Data Point value against the Error Value to determine if the alarm needs to be set.
 - Select the Set Error Value. This value is used as: 'Data Point's Value' 'Operation' 'Value.' Ex: Ticks Since Powerup >= 1000. This will set the alarm after 1000 ticks have elapsed since the unit powered up.



- 5) In the Clear Error Section:
 - a. Select the Clear Error Operation. Available options are <, >, <=, >=, !=, ==, and Change of State (COS). This is the operation that will be used to compare the Data Point value against the Error Value to determine if the alarm needs to be cleared.
 - b. Select the Clear Error Value.
 -Ex: Ticks Since Powerup >= 5000. This will clear the alarm after 5000 ticks have elapsed since the unit powered up.
- 6) Enter an Alarm Name. This will make the alarm unique and will be available in the Alarm Status page as well as in the email generated by the alarm.
- 7) Select an email to associate this alarm with. When an alarm is set, it sends an email. When an alarm is cleared, it will also send an email.

Click the **Save Parameters** button to commit the changes to memory and reboot the gateway.



Diagnostics – Alarm Status

Alarm Status will only display under the Diagnostic menu tab if at least 1 Alarm is enabled.

- 1) # Alarms Enabled: This is a count of enabled alarms.
- 2) # Alarms Active: This is how many alarms are presently active (set).
- 3) Last Active Alarm: This is the last alarm that the gateway detected.
- 4) Clear # of Times Active: This will reset all alarms '# of Times Active' to 0.
- 5) Alarm #: The reference number to the given alarm on the alarm setup page.
- 6) Name: The name of the alarm.
- 7) Status: The current status of the alarm, either OK or ALARM.
- 8) # of Times Active: This count represents the number of times this alarm has become active. If an alarm is triggered, this count will increment.

Alarm Statu	IS			
# Alarms En	abled:	1		
# Alarms Ac	tive:	0		
Last Active	Alarm:			
			Clea	ar # of Times Active
	Alarm#	Name	Status	# of Times Active
	1	Alarm Example	ОК	0

Alarms - Active

While one or more alarms are active, every page will display 'Alarms Active' at the top of the page. This will no longer be displayed if all active alarms have been cleared.



When an alarm is activated, the following will occur:

- 1) A one-time notification will be sent out to the email associated with the alarm.
- 2) For duplicate emails to occur, the alarm must be cleared and then become active again.
- 3) # Alarms Active and # of Times Active will be incremented.
- 4) Status of the Individual Alarm will be set to *Alarm*.
- 5) *Last Active Alarm* field will be populated with details on what triggered the alarm. Real Time Automation, Inc. 58 1-800-249-1612



d:	1			
# Alarms Active: 1				
n:	Alarm 1 is Set: Actual: 0 < Limit: 20			
		Cle	ear # of Times Active	
Alarm#	Name	Status	# of Times Active	
1	Alarm Example	Alarm	1	
	d: n: Alarm# 1	d: 1 1 n: Alarm 1 is Set: Actual: (Alarm# Name 1 Alarm Example	d: 1 1 n: Alarm 1 is Set: Actual: 0 < Limit: 20 Ca Alarm# Name Status 1 Alarm Example Alarm	

Alarms – Clear

When an alarm is cleared, the following will occur:

- 1) A one-time notification will be sent to the email associated with the alarm.
 - a. For duplicate emails to occur, the alarm must become active and then be cleared again.
- 2) Total # Alarms Active will decrement. Last Active Alarm will not be changed.
- 3) Status of the Individual Alarm will be reset to OK.



Change of State (COS) Configuration

To access the configuration files in the 460 gateway, navigate to dropdown **Other->COS Configuration**. The gateway, by default only writes when data has changed. The gateway also waits to write any data to the destination until the source protocol is successfully connected.

Default values should fit most applications. Change these values with caution as they affect performance.

1	1) Stale Data Timer: If the data has not changed within the time allocated in this Stale Data Timer,
	the data will be marked as stale within the gateway and will force a write request to occur. This
	timer is to be used to force cyclic updates in the gateway, since data will only be written if it has
	changed by default. There is a separate timer per data mapping.
	Gateway behavior:
	 If time = 0s => (DEFAULT) The gateway will write out new values on a Change of State basis.
	 If time > 0s => The gateway will write out new values whenever the timer expires to force cyclic updates (write every x seconds).
2	2) Production Inhibit Timer: Amount of time after a Change of State write request has occurred
	before allowing a new Change of State to be written. This is to be used to prevent jitter. Default
	value is 0ms. This timer takes priority over the Stale Data Timer. There is a separate timer per
	data mapping. This timer is active only after the first write goes out and the first COS event
	occurs.
3	3) Writes Before Reads: If multiple writes are queued, execute # of Writes Before Reads before th
	next read occurs. Default is 10 and should fit most applications.
	Warning: A value of 0 here may starve reads if a lot of writes are queued. This may be useful in
	applications where a burst of writes may occur and you want to guarantee they all go out befor
	the next set of reads begin.
2	4) Reads Before Writes: If multiple writes are queued, the # of Writes Before Reads will occur
	before starting the # of Reads Before Writes. Once the # of Reads Before Writes has occurred,
	the counter for both reads and write will be reset. Default is 1 and should fit most applications.
5	b) Enable Data Integrity: If enabled, do not execute any write requests to the destination until the
,	source data point is connected and communicating. This prevents writes of 0 upon power up.
t	data element within the scan line or data group to be new
ſ	Change of State Configuration
	Stale Data Timer: 0 0-3600 s
	Production Inhibit Timer: 0 0-60000 ms
	Writes Before Reads: 10 0-255
	Reads Before Writes: 1 1-255
	Enable Data Integrity: 🔽
	Enable Mark Whole Entry New:
	Save Parameters

Click the **Save Parameters** button to commit the changes to memory and reboot the gateway.



Diagnostics Info

The Diagnostics page is where you can view both protocols' diagnostics information, # of Data Mappings, # of String Mapping and # Alarm Mappings.

DIAG	SNOSTICS	
	-Select-	~
	-Select-	
OTH	Diagnostic Info	
	Logging	

For protocol specific diagnostic information, refer to the next few pages.

Diagnostics Mapping

This section displays the number of mappings that are enabled, Data Mapping and String Mapping will show the # of Errors and First Errors. Alarms will show # active and Last Alarm that was active.

Common Errors:

- Destination or Source Point does not exist

 a) Solution: Re-map the mapping
- 2) Source or Destination Pointer too small
 - a) There is not enough space on either the Source, or the Destination for the data you want to copy. This is typically seen when the Destination is smaller than the amount of data being transferred to it.
- 3) Range Discard, Min or Max Value
 - a) The actual data value is outside of the defined range
- 4) Math Error
 - a) Operation value cannot be 0
- 5) Scaling Error
 - a) Source Min must be smaller than Source Max
 - b) Destination Min must be smaller than Destination Max

Data Mapping # Enabled: # of Errors: First Error:	5 of 5 0
String Mapping # Enabled: # of Errors: First Error:	2 of 2 0
Alarms # Enabled: # Active: Last Active:	3 0

Note: you can also view this information on the Main Page.



Diagnostics – EtherNet/IP Scanner

Select the EtherNet/IP Scanner in the dropdown menu on the Diagnostics Page to view a breakdown of the diagnostics and common strings that are displayed on the page. You may also view individual adapter counters by selecting the device in the *All Adapters* dropdown and clicking **View**. Additional diagnostic information can be found by clicking the **Help** button.

Diagnostics	
EtherNet/IP Scanner View	Clear All Values
All Adapter's View	
All Adapter's	
EC01 192.168.0.100	Help
EC01 192.168.0.101 way Restart Needed	
EC01 192.168.0.102	

NOTE: This page will auto-refresh every five seconds with the latest data.

Clear All Values - This will only affect displayed values.

1) This will reset all displayed values back to zero and clear the Status Strings.

Example: If viewing EtherNet/IP adapter Address 10.1.54.40, this will only clear the values for that specific device. This will reduce the overall values indirectly, otherwise select All Servers to clear all devices.

Diagnostics (MAC: 00:03:F4	:06:18:FD)		Diagnostics (MAC: 00:03:F	4:06:18:FD)
Ethernet/IP Scanner View All Adapter's View		Clear All Values	Ethernet/IP Scanner View EC01 10.1.54.40 View	
Device Status Connected and Running LED Status Connection Status: Variables	Connected	Help	LED Status Connection Status: Variables	Connected
Vetwork Bitmap Status: I/O Messages Sent: I/O Messages Received: I/O Adapter Timeouts: I/O Allocation Attempts: Successful I/O Allocation: Error I/O Allocation:	0x0000001 7833 7833 0 1 1 0		Network Bitmap Status: I/O Messages Sent: I/O Adapter Timeouts: I/O Adlocation Attempts: Successful I/O Allocation: Error I/O Allocation:	0x0000001 8315 8315 0 1 1 0
Status Strings Last I/O Allocation Error: Vendor ID: Device Type: Product Code: Revision: Serial Number: Product Name: (RTA debug):	See Device Level See Device Level See Device Level See Device Level See Device Level See Device Level See Device Level		Status Strings Last I/O Allocation Error: Vendor ID: Device Type: Product Code: Revision: Serial Number: Product Name: (RTA debug):	170 (0x00aa) 11 (0x000b) 1 (0x0001) 1.019 305419896 (0x12345678) EIPScan Test Tool Proc:0x05 UCMM:0x00 IO:0x01



Device Status - This will only display when viewing *All Adapters*.

EtherNet/IP Sc	anner 🗸 🛛 View
All Adapter's	View

- 1) Connected and Running The gateway is connected to all the EtherNet/IP adapters that are enabled and configured.
- 2) Connected and Idle The gateway is connected to all the EtherNet/IP adapters that are enabled and configured but the configured outputs are not yet valid.
- 3) Error: Timeout One or more enabled EtherNet/IP adapters have timeouts.
- 4) Fatal Error: No Configuration No EtherNet/IP adapter devices are configured or devices that are configured are not enabled.
- 5) Unknown: First Scan Not Complete I/O Parameters have been configured for an EtherNet/IP adapter, but a connection has not been established yet.
- *6)* Dependency Protocol Faulted The dependent protocol is missing causing the communication to go inactive.

LED Status - This is the Status for *All Adapters* or the specific Adapter selected.

LED Status	
Connection Status:	Configuration Mode

- 1) Solid Green (Connected) The gateway is connected to all the EtherNet/IP adapters that are configured and enabled.
- 2) Solid Green (Connected(Idle)) –The gateway is connected to all the EtherNet/IP adapters that are configured and enabled, but the configured outputs are not yet valid.
- 3) Flashing Green (Not Connected/First Time Scan) The gateway has never been connected to an EtherNet/IP adapter that is configured and enabled.
 - a) Make sure there are no error codes being returned.
 - b) Make sure the adapter device is configured and online.
- 4) Flashing Red (Empty Scan List) No EtherNet/IP adapters are configured/enabled.
- 5) Flashing Red (Connection Timeout) One or more enabled EtherNet/IP adapters are timed out or missing.
 - a) Verify that the IP address of each EtherNet/IP adapter is valid and is on the same network as the gateway.
 - b) Verify EtherNet/IP settings and ensure that the *Enable* checkbox is checked for the appropriate device(s).
 - c) Verify the Instance numbers are valid for each EtherNet/IP adapter.
- 6) Flashing Red (Dependency Error) The dependent protocol is missing or has errors causing the communication to go inactive.
 - a) The other protocol must be *Connected*.
- 7) Off No Ethernet cable plugged in.



Variables - These are the values for *All Adapters* or the specific adapter selected.

Variables	
Network Bitmap Status:	0x00000000
I/O Messages Sent:	0
I/O Messages Received:	0
I/O Adapter Timeouts:	0
I/O Allocation Attempts:	0
Successful I/O Allocation:	0
Error I/O Allocation:	0

- 1) Network Bitmap Status (Displayed in Hex):
 - a) Each bit corresponds to an adapter. If the bit is set, the adapter is connected, otherwise the bit is 0.
 - b) Bit 0 corresponds to Adapter 1 and Bit 4 is for Adapter 5 and so on.
- 2) I/O Messages Sent Total number of messages sent to the adapter device(s).
- 3) I/O Messages Received Total number of messages received from the adapter device(s).
- 4) I/O Adapter Timeouts Number of times an I/O Connection has timed out.
- 5) I/O Allocation Attempts Number of times the gateway has attempted to allocate a connection.
- 6) Successful I/O Allocation Total number of established connections.
- 7) Error I/O Allocation Total number of refused connections.

Status Strings - These are the values for All Adapters, or the specific adapter selected.

Status Strings
Last I/O Allocation Error:
Vendor ID:
Device Type:
Product Code:
Revision:
Serial Number:
Product Name:
(RTA debug):

- Last I/O Allocation Error Displays the last error code received from a ForwardOpen request. See Error Code Breakdown section for information about more common errors.
- Vendor ID (Device Level only) Displays value from the selected adapter's Identity Object, Attribute

 I.
- 3) Device Type (Device Level only) Displays value from the selected adapter's Identity Object, Attribute 2.
- 4) Product Code (Device Level only) Displays value from the selected adapter's Identity Object, Attribute 3.
- 5) Revision Major/Minor (Device Level only) Displays value from the selected adapter's Identity Object, Attribute 4.
- 6) Serial Number (Device Level only) Displays value from the selected adapter's Identity Object, Attribute 6.
- 7) Product Name (Device Level only) Displays value from the selected adapter's Identity Object, Attribute 7.



Error Code Breakdown:

- 1) Common Allocation Error Codes The gateway is sending an error message due to the listed explanation:
- 2) "Connection already in use" The gateway tried to open a connection using the supplied parameters but failed since an existing connection was already opened.
- 3) "More than one guy configuring" The gateway is not the only device trying to open a connection to the adapter.
- 4) "Connection size mismatch" One of the assembly sizes configured in the gateway does not match that adapter device.
- 5) "RPI Values(s) not acceptable" The gateway is trying to access the adapter too quickly. Increase the RPI value in the gateway.
- 6) "Unsupportable RPI" The value configured in the gateway for the RPI is not supported in the adapter device. Most likely try a larger value.
- 7) "Nonexistent instance number" The assembly instance configured in the gateway is not valid for the adapter.
- 8) "Invalid Configuration Path" The configuration assembly instance and/or size doesn't match the adapter.
- 9) "Invalid O2T Size" The output assembly size doesn't match the adapter.
- 10) "Invalid T2O Size" The input assembly size doesn't match the adapter.
- 11) "Invalid O2T/Consume Path" The output assembly instance and/or size doesn't match the adapter.
- 12) "Invalid T2O/Produce Path" The input assembly instance and/or size doesn't match the adapter.



Diagnostics – BACnet/IP Server

Select the **BACnet/IP Server** in the drop-down menu on the Diagnostics Page. Additional diagnostic information can be found by clicking the **Help** button.

Diagnostics	
BACnet/IP Server ~ View	Clear All Values
✓ View	
Device Status	Help
Configuration Mode Gateway Restart Needed	

NOTE: This page will auto-refresh every five seconds with the latest data.

Clear All Values - This will only affect displayed values.

- 1) This will reset all displayed values back to zero and clear the Status Strings.
- 2) If viewing BACnet/IP Server, this will only clear the values for the BACnet/IP Server section of the gateway.

Device Status:

Device Status Configuration Mode... Gateway Restart Needed

- 1) Connected The gateway is connected to a BACnet/IP client.
- 2) Not Connected The gateway is not connected to a BACnet/IP client.
- 3) Error: Timeout –The gateway has not received a read/write request in the amount of time specified by the Inactivity Timeout.

LED Status:



- 1) Good Communication (Solid Green) Connected to a BACnet/IP client.
- 2) Never Connected (Blink Green) Gateway has never been connected to a BACnet/IP client.
- 3) Connection Timeout (Blink Red) –The gateway has not received a read/write request in the amount of time specified by the inactivity timeout.



Variables:

Variables	
Total Msg Request Count:	0
Read Prop Request Rcvd:	0
Read Mult Prop Request Rcvd:	0
Write Prop Request Rcvd:	0
Write Mult Prop Request Rcvd:	0
Total Msg Response Count:	0
Read Prop Response Sent:	0
Read Mult Prop Response Sent:	0
Write Prop Response Sent:	0
Write Mult Prop Response Sent:	0
Error Response Count:	0
TMO Response Count:	0
COV Success Count:	0
COV Error Count:	0
Status Strings	
Last Error Code:	

- 1) Total Msg Request Count Total number of messages received from the BACnet/IP client.
- 2) Read Property Request Received Number of Read Property requests received from the BACnet/IP client.
- 3) Read Multiple Property Request Received Number of Read Property Multiple requests received from the BACnet/IP client.
- 4) Write Property Request Received Number of Write Property requests received from the BACnet/IP client.
- 5) Write Property Multiple Request Received Number of Write Property Multiple requests received from the BACnet/IP client.
- 6) Total Msg Response Count Total number of messages sent to the BACnet/IP client.
- 7) Read Property Response Sent Number of Read Property Responses sent to the BACnet/IP client.
- 8) Read Multiple Property Response Sent Number of Read Property Multiple responses sent to the BACnet/IP client.
- 9) Write Property Response Sent Number of Write Property responses sent to the BACnet/IP client.
- 10) Write Multiple Property Response Sent Number of Write Property Multiple responses sent to the BACnet/IP client.
- 11) Error Response Count Total number of read/write errors received.
- 12) Timeout Response Count Total number of read/write timeouts.
- 13) COV Success Count Total number of successful COV messages.
- 14) COV Error Count Total number of COV error messages.

Common Error Strings:

- 1) BS: UNHANDLED_MSG_TYPE The gateway received a BACnet/IP message that it doesn't know how to process.
- 2) BS: Message Abort The gateway aborted a message due to one of the common reasons below:
 Real Time Automation, Inc.
 67
 1-800-249-1612



- a) "Buffer Overflow" The BACnet/IP client is asking for too much information in a single message.
- b) "Invalid ADPU" The gateway is not able to process the message, try again later.
- c) "Preempted by Higher Priority" The BACnet/IP client message has aborted due to a higher priority task, try again later.
- d) "Segmentation Not Supported" The gateway does not support segmentation. Break up the client request into multiple requests.
- 3) BS: Message Reject The gateway rejected a message due to one of the common reasons below:
 - a) "Buffer Overflow" The BACnet/IP client is asking for too much information in a single message.
 - b) "Invalid Parameter Data Type" This BACnet/IP data type is not supported.
 - c) "Invalid Tag" BACnet/IP message is not how the gateway expects the message.
 - d) "Parameter Out of Range" The BACnet/IP client is asking for information outside of the gateway's defined range.
- 4) BS: Message Error "XXXXX" The gateway is sending an error a message due to the listed explanation:
 - a) "Inconsistent parameters"
 - i) BACnet/IP client tried to write a priority that was out of range or reserved (Priority 6) and was rejected.
 - ii) BACnet/IP client tried to write to ALL, REQUIRED, or OPTIONAL object property.
 - b) "Invalid Data Type" BACnet/IP client tried to use a data type with an object that is not supported.
 - c) "Service request denied" BACnet/IP request cannot be processed because the BACnet/IP connection is not established.
 - d) "Read access denied" BACnet/IP read request cannot be processed.
 - e) "Unknown object" BACnet/IP client tried to access an object our gateway does not support.
 - f) "Unknown property" BACnet/IP client tried to access a property our gateway does not support for that object type.
 - g) "Unsupported object type" BACnet/IP client tried to access an object type our gateway does not support.
 - h) "Value out of range" BACnet/IP message could not be completed because the passed value was not in the valid range.
 - i) "Write access denied" BACnet/IP client tried to write a non-writeable property in our gateway.
 - j) "Invalid array index"
 - i) BACnet/IP client tried to write a priority that was out of range or reserved (Priority 6) and was rejected.
 - ii) BACnet/IP client tried to write an array for an object or property that doesn't have an array index.
 - k) "Unknown device" Gateway is trying to send a message to a device we have not had previous communication with on the network.
 - I) "Timeout" BACnet/IP message timed out.
 - m) "Resources busy" BACnet/IP message cannot be processed right now.
 - n) "Segmentation not supported" BACnet/IP message is too large to send in one message.
 - o) "Service not supported" BACnet/IP client tried to perform a service that the gateway does not support.
 - p) "Abort Other" BACnet/IP message is aborted for an unknown reason.
 - q) "Invalid Tag" BACnet/IP message is not how we expect.
 - r) "Unknown" BACnet/IP message error for an unknown reason.



LED Configuration

To modify the behavior of the LEDs on the 460 gateway, navigate to **Other->Setup LEDs**.

OTH	ER	
	-Select-	~
	-Select-	
	Setup LED's	

Each LED may be set to Disabled, Protocol 1, or Protocol 2. If either protocol is a master/client, you may set the LED to represent either all slaves/servers configured in the gateway or a slave/server device.

To select a slave/server device:

- 1) Select the protocol in the left dropdown menu.
- 2) Click **Save Parameters** to generate the second dropdown menu.
- 3) Select the individual slave/server in the right dropdown menu.

Click the **Save Parameters** button to commit the changes and reboot the gateway.

LED Configuration	
	LED 1 Modbus RTU Master: Connection Status V All Slave's V LED 2 BACnet/IP Server: Connection Status V
	Save Parameters



Configuration Files

To access the configuration file in the 460 gateway, select the dropdown **Other->Export/Import Config**.

отн	ER	
	-Select-	
	-Select-	
	Setup LED's	
	Export / Import Config 📐	
	Export / Import Template	
	Utilities	

Export Configuration

Export Configuration		
	Save Configuration to File	

The Export Configuration allows you to save your configuration file for backup or to be imported into another gateway. This file is named *rta_cfg.rtax* by default.

Upon clicking the **Save Configuration to File** button, you will be prompted to select a location to save the file. Different web browsers will yield different looks.

What do you want to do with the afer they?					
From: 10.1.16.106	Open	Save	^	Cancel	×

Import Configuration

You can import a previously exported configuration file or a configuration file from another device into the 460 gateway, whenever it is in Configuration Mode.

Upon clicking the **Choose File** button, you will be prompted to select a location from which to load the saved file. Once the location is selected, you can choose the **Import Network Settings** checkbox if you want to load the network settings of the configuration file or just load the configuration without the network setting.

If you choose to Import Network Settings, this will override your current gateway's network setting with the settings in the configuration file. After you click on the Load Configuration button, a banner will display your gateway's new IP address.

Network Settings have changed. Manually enter IP Address of X.X.X.X in the URL.

If the configuration has successfully loaded, the gateway will indicate that it was successful, and a message will appear under the Load Configuration button indicating Restart Needed.

Real Time Automation, Inc.



Import Configuration		
	Choose File No file chosen	
	Import Network Settings	
	Load Configuration	

If it encountered an error while trying to load the saved configuration, the gateway will indicate the first error it found and a brief description about it under the Load Configuration button. Contact RTA Support with a screenshot of this error to further troubleshoot.



Save and Replace Configuration Using SD Card

Saving Configuration Using SD Card

This function saves the gateway's configuration automatically to an SD Card each time the gateway is rebooted via the **Restart Now** button on the web page. If this unit should fail in the future, the last configuration stored on the SD card and can be used for a new gateway to get the application back up and running quickly.

This SD Card replaces every configurable field in the gateway, **EXCEPT** for IP Address, Subnet Mask, and Default Gateway.

Replacing Configuration Using SD Card

To replace a configuration in a gateway using the SD Card, a specific sequence of events must be followed for the replacement to happen correctly:

- 1) Extract SD Card from gateway you wish to copy the configuration from.
- 2) Power up the gateway you wish to copy the configuration to. DO NOT INSERT SD CARD YET.
- 3) Navigate to the webpage inside the unit.
- 4) Navigate to the dropdown **Other->Utilities**.
- 5) If you are not currently in *Mode: Configuration*, go into Configuration Mode by clicking the **Configuration Mode** button at the top left-hand side of the screen.
- 6) Press the **Revert to Manufacturing Defaults** button on the Utilities Page. The Configuration will ONLY be replaced by the SD Card if the gateway does not have a configuration already in it.
- 7) When the unit comes back in *Mode: Running,* insert the SD Card.
- 8) Do a hard power cycle to the unit by unplugging power. DO NOT RESET POWER VIA WEB PAGES.
 - a. It will take an additional 30 seconds for the unit to power up while it is transferring the configuration. During this time, the gateway cannot be accessed via the web page.
- 9) When the unit comes back up, the configuration should be exactly what was on the SD Card.


Intelligent Reset Button

If the IP Address of the gateway is forgotten or is unknown, there is an easy way to recover the IP Address using a reset button on the hardware.



- 1) On the front of the gateway below the Power LED, there is a small pinhole. Using a paperclip, press the button through this pinhole and hold the button for at least 5 seconds.
- 2) After 5 seconds, the unit will acknowledge the command and LED 1 and LED 2 will start an alternate Blink Green quickly pattern.
- 3) Release the button and the gateway will reset both Ethernet ports to default IP settings (DHCP).



Utilities

To access the Utilities page in the 460 gateway, navigate to **Other->Utilities**. The Utilities screen displays information about the gateway including Operation Time, File System Usage, Memory Usage, and Memory Block Usage.

OTHER

	-Select-
	-Select-
	Setup LED's
	Export / Import Config
	Export / Import Template
	Utilities
	Time Configuration
	Email Configuration
1	Security Configuration
	Alarm Configuration
	COS Configuration

Here you can also:

- View the full revision of the software.
- View all the files stored in the Flash File System within the gateway.
- Identify your device by clicking the **Start Flashing LEDs** button. By clicking this button, the two diagnostic LEDs will flash red and green. Once you have identified which device you are working with, click the button again to put the LEDs back into running mode.
- Configure the size of the log through the Log Configuration.
- Bring the device back to its last power up settings.
- Bring the device back to its original manufacturing defaults.
- Remove the Configuration File and Flash Files within the gateway.

Revisions	
	Listing of Revisions
File List	
	File List
Identify Device	
	Start Flashing LED's
Set Up Log	
	Log Configuration
Revert To Last Powerup	
	Revert to Last Powerup
Revert All	
	Revert to Manufacturing Defaults
Reformat Flash	
	Reformat Flash

Real Time Automation, Inc.