

460PSUSB-NNCU Protocol Gateway

Product User Guide

Firmware Version 8.9.37



Trademarks

CompactLogix, ControlLogix, & PLC-5 are registered trademarks of Rockwell Automation, Inc. EtherNet/IP is a trademark of the ODVA. MicroLogix, RSLogix 500, and SLC are trademarks of Rockwell Automation, Inc. Microsoft, Windows, and Internet Explorer are registered trademarks of Microsoft Corporation. BACnet[®] is a registered trademark of American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE). All other trademarks and registered trademarks are the property of their holders.

Limited Warranty

Real Time Automation, Inc. warrants that this product is free from defects and functions properly.

EXCEPT AS SPECIFICALLY SET FORTH ABOVE, REAL TIME AUTOMATION, INC. DISCLAIMS ALL OTHER WARRANTIES, BOTH EXPRESSED AND IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR APPLICATION. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular application, Real Time Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams. Except as specifically set forth above, Real Time Automation and its distributors and dealers will in no event be liable for any damages whatsoever, either direct or indirect, including but not limited to loss of business profits, income, or use of data. Some states do not allow exclusion or limitation of incidental or consequential damages; therefore, the limitations set forth in this agreement may not apply to you.

No patent liability is assumed by Real Time Automation with respect to use of information, circuits, equipment, or software described in this manual.

Government End-Users

If this software is acquired by or on behalf of a unit or agency of the United States Government, this provision applies: The software (a) was developed at private expense, is existing computer software, and was not developed with government funds; (b) is a trade secret of Real Time Automation, Inc. for all purposes of the Freedom of Information Act; (c) is "restricted computer software" submitted with restricted rights in accordance with subparagraphs (a) through (d) of the Commercial "Computer Software-Restricted Rights" clause at 52.227-19 and its successors; (d) in all respects is proprietary data belonging solely to Real Time Automation, Inc.; (e) is unpublished and all rights are reserved under copyright laws of the United States. For units of the Department of Defense (DoD), this software is licensed only with "Restricted Rights": as that term is defined in the DoD Supplement of the Federal Acquisition Regulation 52.227-7013 (c) (1) (ii), rights in Technical Data and Computer Software and its successors, and: Use, duplication, or disclosures is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at 52.227-7013. If this software was acquired under GSA schedule, the U.S. Government has agreed to refrain from changing or removing any insignia or lettering from the Software or documentation that is provided or from producing copies of the manual or media. Real Time Automation, Inc.

© 2024 Real Time Automation, Inc. All rights reserved.



Revision History	6
Overview	8
Hardware Platforms	9
Hardware – NNCU	
Powering the Gateway	
Mounting with a DIN Rail	11
Installing	11
Removing	11
Accessing the Main Page	12
Committing Changes to the Settings	14
Main Page	15
Device Configuration	16
Network Configuration	17
PROFINET IO Server Configuration	
PROFINET IO Server Slot Configuration	20
PROFINET IO Server Slot Configuration: Auto-Configure	21
Auto-Configure Group by Device vs. Auto-Configure Group by Data Type	22
Group by Device (Default Method)	22
Group by Data Type	22
PROFINET IO Server Slot Configuration: Manual Mode	23
Setting up the PLC- Example Using Simatic Classic Step 7	24
Setting up the PLC- Example Using TIA Portal	
Virtual Com Config	
ASCII Configuration	
Receive Data	
Receive Data – Operation Mode	40
Transmit Data	42
Transmit Data – Triggering Methods	43
ASCII Configuration – Technology Triggering Method	45
ASCII Configuration – ASCII Parsing	
ASCII Configuration – ASCII Parsing Examples	49
ASCII Configuration – ASCII Concatenating	51
Real Time Automation, Inc. 3	1-800-249-1612



ASCII Configuration – ASCII Concatenating Examples	53
ASCII Configuration – ASCII Message Counter	55
Printer Port Status	56
Mapping - Transferring Data Between Devices	57
Display Mapping and Values	58
Display Data	58
Display String	61
Display String use case	63
Data and String Mapping – Auto-Configure	64
Data Mapping – Explanation	65
Data Mapping – Adding Diagnostic Information	66
String Mapping – Explanation	71
Mapping – Auto-Configure Mode to Manual Configure Mode	72
Mapping – Manual Configure Mode to Auto-Configure Mode	73
View as Text	74
Data Mapping	74
String Mapping	74
Base Triggering – Data Validiation Triggering	75
Security Configuration	77
Security Configuration-Security Levels	
Security - Log In	79
Security - Log Out	79
Email Configuration	80
Alarm Configuration	
Diagnostics – Alarm Status	
Alarms – Active	
Alarms – Clear	
Change of State (COS) Configuration	
Diagnostics Info	
Diagnostics Mapping	
Diagnostics – PROFINET IO Server	
Diagnostics – ASCII	
LED Configuration	
Configuration Files	
Real Time Automation, Inc. 4	1-800-249-1612



Export Configuration	96
Import Configuration	96
Save and Replace Configuration Using SD Card	98
Saving Configuration Using SD Card	98
Replacing Configuration Using SD Card	98
Utilities	99



Revision History

Version	Date	Notes
8.4.5	11/18/2019	 Features Added Released OPC UA Server (US) Protocol Ability to now Import/Export Template Files with out an FTP session Bug Fixes Updated Profinet Server (PS) on N34 hardware Platform Updated Wi-Fi software
8.6.0	2/28/20	Bug Fixes1. Omron Plc Communication fixes for EtherNet/IP2. Profinet GSDML Substitute values fix
8.7.4	9/1/20	 Features Added: 1. BMS, BM, DFM, DS, DM, TCP, USB, PBS have been ported to the latest base software 2. TCP,BMS,BM now Available on N2E and N2EW hardware Platform 3. New ASCII Mode Available on TCP/A/USB/WI protocols 4. User Guides updated with more examples Bug Fixes: 1. Improved Data Mapping and String Mapping performance 2. Improved functionality/performance on EC,ETC,ES,MC,MS,BS,BC, A,,WI,PS protocols
8.7.22	4/6/21	Features Added: 1. Support for RSLogix Versions 32 + with unsigned data type support 2. ETC now support Long integer files (L files) for MicroLogix PLCS that support them 3. SC now supports data block (DB) access
8.7.53	4/28/21	 Features Added: 5. Added support for the NNBU hardware platform 6. Improved RFIDeas scanner support 7. Updated MM and MRS to use Modbus RTU Client and Modbus RTU Server terminology



Version	Date	Notes
8.9.22	2/5/24	 Features Added: 1. Added priority-based reads for client protocols 2. Added improved diagnostic timers for client protocols 3. Reduced minimum delay between messages to zero ms on client protocols 4. Added support for USB serial connections 5. Added support for multiple connections on EtherNet/IP Adapter 6. Added 100ms and 1000ms heartbeat values for diagnostic use 7. Added configurable data size to EtherNet/IP adapter and DeviceNet Slave 8. Added support for TTL communications on N34, NNA1, NNA4, N2E, and N2EW hardware 9. Added support for JSON payloads to MQTT 10. Added Network Bitmap Status to ASCII, USB, and TCP protocols Bug Fixes: 11. Fixed COV Subscription Issues on BACnet MS/TP 12. Fixed timing issues affecting gateway performance 13. Fixed a bug where the Run Idle Header on the output instance for EtherNet/IP Scanner was not checked by default
8.9.29	4/1/24	 Features Added: 14. Added ability to do raw HEX byte copy when receiving data over ASCII, TCP, or USB. Bug Fixes: 15. Fixed bug where function code 15 did not work on MM/MC. 16. Fixed bug relating to writing zeros on start up on BS. 17. Fixed bug where MQTT client did not appear in display data page when MQTT was paired with BACnet
8.9.37	7/30/24	Bug Fixes: 18. EIP IO Communication fixes 19. Timing fixes 20. USB Fixes a. Inactivity Timeout b. Inactivity Timeout Logging c. Port Restart Logging d. Webpage fixes 21. ProfiNet Timing Fix 22. EIP PanelView Fixes a. Support for Explicit Messaging



Overview

The 460PSUSB-NNCU gateway Connects a PROFINET IO Controller with up to two USB devices. By following this guide, you will be able to configure the 460PSUSB-NNCU gateway.

Number of ASCII devices is dependent on the Hardware and Product number of the 460 gateway.

For further customization and advanced use, please reference the appendices located online at: <u>http://www.rtautomation.com/product/460-gateway-support/</u>.

If at any time you need further assistance, do not hesitate to call Real Time Automation support. Support Hours are Monday-Friday 8am-5pm CST

Toll free: 1-800-249-1612 Email: support@rtautomation.com



Hardware Platforms

The 460 Product Line supports a number of different hardware platforms. There are differences in how they are powered, what serial settings are supported, and some diagnostic features supported (such as LEDs). For these sections, be sure to identify the hardware platform you are using.

To find which hardware platform you are using:

- 1) Look on the front or back label of the unit for the part number.
- On the webpage inside the gateway, navigate to the dropdown menu under Other and select Utilities. Click the Listing of Revisions button. The full part number is displayed here.

Once you have the full part number, the platform will be the number following the "-N":





Hardware – NNCU



Powering the Gateway

- 1. The gateway requires an 8-24 VDC power source Red Wire = (+) Black Wire = (-).
 - a. The unit draws 175mA @ 12V.





Mounting with a DIN Rail

Installing

Follow these steps to install your interface converter.

- 1) Mount your DIN Rail.
- 2) Hook the bottom mounting flange under the DIN Rail.
- 3) While pressing the 460PSUSB-NNCU against the rail, press up to engage the spring loaded lower clip and rotate the unit parallel to the DIN Rail.
- 4) Release upward pressure.



Removing

Follow these steps to remove your interface converter.

- 1) Press up on unit to engage the spring loaded lower clip.
- 2) Swing top of the unit away from DIN Rail.

11



Accessing the Main Page

The following steps will help you access the browser based configuration of the gateway. By default, DHCP is enabled. If the gateway fails to obtain an IP address over DHCP it will Auto IP with 169.254.X.Y. For more information on your Operating system network setting refer to the <u>Accessing Browser</u> <u>Configuration</u> document from our support web site.

1) Scan the QR code on the back of the unit or navigate to <u>www.rtautomation.com/460-gateway-support</u> and download IPSetup.exe.

NDK Settings IP	0.	0	. 0 .	0]	- Select a U	nit <u>XXYY</u> [00-03-F4-0A-D2-8	C] AutolP at 169.254.4
Network Mask	0.	0.	0.	0				
GateWay	0.	0.	0.	0	Set>			
DNS 🛛	0.	0.	0,	0				
							Search Again]
					-		1	1

- 2) Run the IPSetup.exe program.
- 3) Find unit under "Select a Unit".
 - a. Change Gateway's IP address to match that of your PC if DHCP has failed.
 - i. You will know DHCP has failed if the gateway's IP address is AutoIP at 169.254.X.Y.
 - ii. If successful, it will say DHCP'd at ex: 192.168.0.100 or however your DCHP Client is set up.
 - b. If you do not see the gateway in this tool, then your PC is most likely set up as a static IP.
 - i. Change your PC's network settings to be DHCP. If DHCP fails, then it will change to be on the 169.254.x.y network.
 - ii. Relaunch the IP Setup tool to see if gateway can be discovered now.
- 4) Click Launch Webpage. The Main page should appear.

Default setting is set to DHCP. If DHCP fails, default IP Address is 169.254.x.y



Error: Main Page Does Not Launch

If the Main Page does not launch, please verify the following:

- 1) Check that the PC is set for a valid IP Address
 - a. Open a MS-DOS Command Prompt
 - b. Type "ipconfig" and press enter
 - c. Note the PC's IP Address, Subnet, and Default Gateway
- The gateway must be on the same Network/Subnet as the PC whether it's setup for DHCP or Static. Once you have both devices on the same network, you should be able to ping the gateway using a MS-DOS Command Prompt.



The Screenshot above shows a gateway that is currently set to a static IP Address of 192.168.0.100.

If you are able to successfully ping your gateway, open a browser and try to view the main page of the gateway by entering the IP Address of the gateway as the URL.





Committing Changes to the Settings

All changes made to the settings of the gateway in Configuration Mode will not take effect until the gateway is restarted via the webpage. Changes will not be stored if the gateway's power is removed prior to a reboot.

NOTE: The gateway does not need to be restarted after every change. Multiple changes can be made before a restart, but they will not be committed until the gateway is restarted.

When all desired changes have been made, press the **Restart Now** button. The webpage will redirect to our rebooting page shown below:



The reboot can take up to 20 seconds.

If the IP address has not been modified, the gateway will automatically redirect to the main page. If the IP address was modified, a message will appear at the top of the page to instruct the user to manually open a new webpage at that new IP.



Main Page

The main page is where important information about your gateway and its connections are displayed. Mode (orange box below):

Running Mode:

- Protocol communications are enabled
- Configuration cannot be changed during Running Mode. If changes are needed, click the **Configuration Mode** button shown in the green box below

Configuring Mode:

- Protocol communication is stopped and no data is transmitted
- Configuration is allowed

Navigation (green box below):

You can easily switch between modes and navigate between pages (Configuration, Diagnostics, and Other pages) using the buttons on the left hand side.

RTA				www.rtaautomation.com
Real Time Auton	nation, Inc.			460ETCMC
Configuration Mode		Mai	n Page	
Main Page		Device Description: Applica	tion Description	
CONFIGURATION Network Configuration Allen-Bradley PLC		Save	Parameters	
Modbus TCP/IP Client Display Data	Network Status	Link Status	MAC Address	ID Address
DIAGNOSTICS -Select-	Ethernet Port	100Mbps, Full Duplex	00:03:F4:0A:43:CC	10.1.28.95
OTHER Select- ▼	Allen-Bradley PLC Statu Device Status: Last Read Error Code: Last Write Error Code:	JS Fatal Error: No Configurat	ion	
	LED Status:	Connection Status: No De	vices Configured / Enabled	
	Modbus TCP/IP Client S Device Status: Last Error Code: LED Status:	Status Fatal Error: No Configurat Connection Status: No De	ion vices Configured / Enabled	
	Data Mapping Status # Enabled: # of Errors: First Error:	0 of 0 0	-	



Device Configuration

The device configuration area is where you assign the device description parameter. Changes can only be made when the gateway is in Configuration Mode.

Main Page	
Device Description: Application Description	
Save Parameters	

Once you are done configuring the Description, click the **Save Parameters** button.



Network Configuration

The network configuration area is where you assign the IP address and other network parameters. Changes can only be made when the gateway is in Configuration Mode.

Once you are done configuring the Network Settings, click the **Save Parameters** button.

If you are changing the IP Address of the gateway, the change will not take effect until the unit has been rebooted. After reboot, you must enter the new IP Address into the URL.

Network Configuration	Help
Ethernet Configuration	
Ethernet MAC Address:	00:03:F4:0B:C3:02
Ethernet Link:	Auto-Negotiate 🔻
IP Setting:	Static IP V
IP Address:	10.1.16.40
Subnet:	255.255.0.0
Default Gateway:	0.0.0.0
DNS Gateway:	0.0.0.0
Save Par	rameters

It is recommended to leave the DNS Gateway set to 0.0.0.0 and the Ethernet Link as Auto-Negotiate. If configuring the gateway to use E-mail, the DNS Gateway must be set.



PROFINET IO Server Configuration

Click the **PROFINET IO Server** button to display the configuration page.



- 1) Select which **Network Interface** to use for this PROFINET IO connection. If using single port hardware, the Network Interface will default to Ethernet Port only.
- 2) **Device Name**: This is the PROFINET name that is assigned by TIA Portal or Classic STEP 7.
- 3) To enable data swapping, select the required **Swap Indicator**. If the bytes appear in the wrong order, enable swapping to change the data. This swapping does *NOT* change Booleans and their ordering inside the Bit Pack.
- 4) VLAN Network ID: Enter the PROFINET VLAN Network ID to be Used for communication. This should match the VLAN configured on the PROFINET Client, or a Default Gateway should be configured.

	Device Name:			
	Swap Indicator:	Swap Nor	ne	\sim
	VLAN Network ID:	0	0-4095	
	Save Par	ameters		
C (C) (1)				
finet Slot List		1		
	Auto-Configure Grou	up by Dev	ice Y	
nput Slots (460ETCPS t	o Profinet IO)	Outpu	t Slots (Profin	et IO to 460ETCPS)
Slot Data Size (Bytes)	Data Format	Slot	Data Size (Bytes)	Data Format
1 Disabled v 1	.6 Bit Int 🗸 🗸	11	Disabled V	16 Bit Int 🗸 🗸
2 Disabled ~ 1	.6 Bit Int 🗸 🗸	12	Disabled ~	16 Bit Int 🗸 🗸
3 Disabled ~ 1	.6 Bit Int 🗸	13	Disabled ~	16 Bit Int 🗸 🗸
4 Disabled v 1	6 Bit Int 🗸	14	Disabled ~	16 Bit Int 🗸 🗸
5 Disabled v 1	.6 Bit Int 🗸	15	Disabled ~	16 Bit Int 🗸 🗸
6 Disabled v 1	6 Bit Int 🗸	16	Disabled ~	16 Bit Int 🗸 🗸
7 Disabled v 1	6 Bit Int 🗸	17	Disabled ~	16 Bit Int 🗸 🗸
8 Disabled v 1	6 Bit Int 🗸	18	Disabled v	16 Bit Int 🗸 🗸
9 Disabled v 1	.6 Bit Int 🗸	19	Disabled ~	16 Bit Int 🗸 🗸
10 Disabled v 1	6 Bit Int 🗸	20	Disabled ~	16 Bit Int 🗸 🗸
	Save Par	ameters		
	Save Fai	ameters		



Note: To properly set communication to the PROFINET controller, you will need to install the GSD file that is downloadable on the configuration web page or on the CD that was shipped with the unit. For instructions on how to do this, please see the <u>Setting up the PLC- Example Using Simatic Step 7 software</u> and <u>Setting up the PLC- Example Using TIA Portal sections</u>.

WARNING:

This gateway does not support the assignment of the IP address via the IO controller function. This function must be disabled for the system to function properly.



PROFINET IO Server Slot Configuration

The bottom area of the PROFINET IO Server Configuration page lets you configure multiple input and output slots.

- 1) Profinet server supports 1248 Input bytes and 1248 Output bytes.
- 2) Data Size is configurable. Options include: 8, 16, 32, 64, and 128 Bytes.
- 3) Data Format sets the formatting of the data. Automap will use this packing size to map data to/from the other protocol.

There are three ways to configure this protocol:

- 1) Auto-Configure Group by Device (Default)
- 2) Auto-Configure Group by Data Type
- 3) Manual Mode

NOTE: You may go back and forth between modes, but when reverting from Manual Mode to either of the two Auto-Configure Modes, all changes made in Manual Mode will be discarded.

Slot	Data Size (Bytes)	Data Format	Slot	Data Size (Bytes)	Data Format
1	Disabled 💌	16 Bit Int 👻	11	Disabled 💌	16 Bit Int 🔹
2	Disabled 💌	16 Bit Int 🔹	12	Disabled 🔻	16 Bit Int 🔹
3	Disabled 🔻	16 Bit Int 💌	13	Disabled 💌	16 Bit Int 💌
4	Disabled 💌	16 Bit Int 👻	14	Disabled 💌	16 Bit Int 👻
5	Disabled 💌	16 Bit Int 👻	15	Disabled 💌	16 Bit Int 💌
6	Disabled 🔻	16 Bit Int 💌	16	Disabled 💌	16 Bit Int 💌
7	Disabled 🔻	16 Bit Int 👻	17	Disabled 👻	16 Bit Int 💌
8	Disabled 👻	16 Bit Int 👻	18	Disabled 🔻	16 Bit Int 🔹
9	Disabled 💌	16 Bit Int 👻	19	Disabled 💌	16 Bit Int 💌
10	Disabled 👻	16 Bit Int 🔫	20	Disabled -	16 Bit Int 👻



PROFINET IO Server Slot Configuration: Auto-Configure

While in either of the two Auto-Configure Modes, the data slots themselves cannot be edited. Auto-Configure Mode looks at the other protocol and then configures the data slots to match. The Data formats will be defined after the other protocol is configured.

The data will be configured according to the following rules:

- 1) Any 8 Bit Signed/Unsigned data will be mapped as **8 Bit Int or 8 Bit Uint**, matching signs whenever possible.
- 2) Any 16 Bit Signed/Unsigned data will be mapped as **16 Bit Int or 16 Bit Uint**, matching signs whenever possible.
- 3) Any 32 Bit Signed/Unsigned data will be mapped as **32 Bit Int or 32 Bit Uint**, matching signs whenever possible.
- 4) Any 64 Bit Signed/Unsigned data will be mapped as **64 Bit Int or 64 Bit Uint**, matching signs whenever possible.
- 5) Any 32 Bit Float will be mapped as **32 Bit Float**.
- 6) Any 64 Bit Float will be mapped as **64 Bit Float**.
- 7) Any Strings will be mapped as **Short String**.

NOTE: When using a String Data Type, the 1st byte of each slot is reserved for the Length field. The remaining bytes will be used for the actual data.

- 8) Any Coils or 1/8/16/32 Bit Binary Packs will be mapped as **Binary 8 Bit Pack/Binary 16 Bit Pack/Binary 32 Bit Pack**, matching bit sizes whenever possible.
- 9) The input or output direction depends on whether it is configured as an input/read or output/write on the other protocol.
- 10) If the other protocol exceeds the number of data size supported, then nothing will be mapped. You will see all the data size values remain disabled and the main page will display the following error:

ERROR XX_460 Re-initialization (Auto-Config Failed -9)

a) To fix this error, simply decrease the amount of data you configured on the other protocol so that the max data size is not exceeded or call customer support to increase the limits.

To edit slot data sizes or formats you will need to go into Manual Configure Mode.



Auto-Configure Group by Device vs. Auto-Configure Group by Data Type

There are two different methods for Auto-Configure: Group by Device or Group by Data Type.

There are a couple of rules to keep in mind when using Auto-Configure Mode:

1) If the other protocol inside the gateway is a server, slave, or adapter protocol, then there are no differences between the Auto-Configure Modes.

Group by Device (Default Method)

Group by Device goes through the other protocol on the gateway and auto-configures the data groups on the PROFINET server for all the data points on the other protocol's first device. After it finishes with the first device, it will auto-configure all the points for the second device (if one is configured), and so on.

The data in this method is not optimized- there could potentially be a lot of wasted/unused data space, but it will be organized more logically from the master/client's point of view.

Group by Data Type

Group by Data Type goes through the other protocol on the gateway and auto-configures the data groups on the PROFINET server for all the data points within the other protocol.

Another way to view this option is to say that the data points allocated are packed together so there is very little wasted data space. The data is packed or optimized.

Example: Protocol A is a master/client protocol that has 2 devices with the same setup:

Device_1 has 1 integer scan line, 1 float scan line, 1 integer scan line- each for 1 point of data Device_2 has 1 integer scan line, 1 float scan line, 1 integer scan line- each for 1 point of data

Protocol B is a server/slave/adapter protocol that can be mapped as follows:

Group by Device - Protocol B will have 4 scan lines that will look like the following: Scan Line 1 and 2 will represent Device_1 and Scan Line 3 and 4 will represent Device_2.

Scan Line 1 => Type Integer, length of 2 Scan Line 2 => Type Float, length of 1 Scan Line 3 => Type Integer, length of 2 Scan Line 4 => Type Float, length of 1

Group by Data Type - Protocol B will have 2 scan lines that will look like the following: All like data types from Device_1 and Device_2 will be combined.

Scan Line 1 => Type Integer, length of 4 Scan Line 2 => Type Float, length of 2



PROFINET IO Server Slot Configuration: Manual Mode

- 1) To transition from either of the two Auto-Configure Modes to Manual Configure Mode, click the dropdown at the top of the PROFINET IO Server Configuration page and select Manual Configure.
- 2) When prompted, click **OK** to confirm mode change or **Cancel** to remain in Auto-Configure Mode.



Me	ess <mark>age</mark> fr	om webpage		X
	?	Press OK to r Press Cancel	nodify the current to Delete all Data I	Data Points. Points.
			ОК	Cancel

- 4) To keep the data slots that are already configured, press **OK**.
 - i) You would want this option if you are adding additional data slots or you want to modify the data slot(s) that already exist.
- 5) To delete the data slots that are already there and start over, press **Cancel**.
- 6) Input Slots: Select the data size, in bytes, to move data from the gateway to the controller. Then select the data format for that slot.
- 7) Output Slots: Select the data size, in bytes, to move data from the controller to the gateway. Then select the data format for that slot.



Setting up the PLC- Example Using Simatic Classic Step 7

This is how you would set up the following example in your controller.

Input	Slots (460PS	SMC to Profinet IO)	Output Slots (Profinet IO to 460PSMC)		
Slot	Data Size (Bytes)	Data Size (Bytes) Data Format Slot (Bytes)		Data Format	
1	128 🗸	8 Bit Int 🗸	11	128 🗸	8 Bit Int 🗸

1) In your project, click the CPU and you should see the hardware option in the right pane. Double click on the Hardware icon.

BY PSMC_Project_Test C:VP	emens\Step7\s7proj\PSMC_P-1		
PSMC_Project_Test Imm SIMATIC 300 Station	00 Hardware	CPU315-2 PN/DP(1)	

2) IF YOU HAVE ALREADY INSTALLED THE GSD FILE, SKIP TO STEP 9. OTHERWISE - Under Options, select **Install GSD Files**.

		Install GSD Files			
≥(0) UR		Install GSD Files:	from the directory	•	
2 CPU315-2 PN/DP(1) X1 MPL/DP	-	C:\Users\Engineer\Desktop\P	New GSD Files		Browse
X2 PN-10 X2 P1 Pot 1 X2 P2 Pot 2 3		File GSDML-V2.34-RTA-460PSxx-2	Release 0190219.xml 02/19/2019 12:00:00 AM	Version Languages V2.34 English	
(1) rta-460ps					
Slot Module Or	der number				
X1 Interface	07"5%	Install Sho	v Log Select All D	eselect All	
1 128-Byte Input 128	-Byte Input	· · · · · ·			-

3) On the PROFINET IO Server configuration page, download the zip file



- 4) Browse to folder containing the GSD file.
- 5) Select the GSD file from the box and click Install.
- 6) When prompted to confirm installation because it cannot be undone, click **Yes**.

Real Time Automation, Inc.



Confirm installation of GSD fi	les 🛛 🔀
CAUTION: Installation OF GSD files continue the action?	cannot be undone. Do you still want to
Yes	No

7) Click **OK** acknowledging that the install was successful.

Install GSD File	X	
install	ation was completed successfully.	
ОК		

8) If you navigate to the right-hand side, you will see the RTA profile under: PROFINET IO->Additional Field Devices->Gateway->460PSxx

Profile:	Standard
⊡ 📅	PROFIBUS DP
	PROFIBUS-PA
<u>⊨</u> ₩ F	PROFINET IO
<u> </u>	Additional Field Devices
	≒⊶🧰 Gateway
	🖻 💼 460PS 🗙
	🗄 📲 460PSxx 1-port
	🗄 🚡 460PSxx 2-port
	±- 🧰 1/0
	📄 Gateway

- 9) IF YOU HAVE ALREADY CONFIGURED THE PROFINET I/O CONTROLLER, SKIP TO STEP 11. OTHERWISE - Right-click on the PN-IO block and select **Insert PROFINET IO System**.
- 10) In the properties window, set the IP Address to match that of the PROFINET I/O controller and press **New** and **OK**.



Properties - Ethernet interface PN-10 (R0/S2.2)	
General Parameters	ed, Idresses are suggested.
IP address: 192.168.0.1 Gateway Subnet mask: 255.255.255.0 C Use router Address:	ter
Subnet:	New
	Properties
	Delete
ОК	Cancel Help

11) Find the RTA device in the I/O tree. It will be under PROFINET IO->Additional Field Devices-> Gateway->460PSxx->460PSxx 1-port.



12) Once found, drag the Standard icon into the network line.



X1 MPI/DP X2 PN-IO X2 P1 Post 1 X2 P2 Post 2 3	(100)
--	-------

13) Double-click the gateway icon to open the properties window. If not already done, uncheck the **Assign IP Address via IO controller option** (some versions already do this) and press **OK**.

Properties - ps01		X
General Identification		
Short description:	ps01	
	460PSxx 10 Gateway	~ ~
Order No./ firmware:	6GK1 953-0CA00 / Z1.0	
Family:	460PSxx	
Device name:	ps01	
GSD file: ┌─Node in PROFINET II	GSDML-V2.2-RTA-460PSxx-20140317.xml Change Release Number	
Device number:	1 PROFINET-IO-System (100)	
IP address:	Ethernet	
☐ Assign IP address	s via ID controller	
Comment:		
		K. 2
ОК	Cancel He	elp



14) To Assign the RTA gateway a Device Name click on the RTA device, click on the *PLC* tab, select *Ethernet*, then *Assign Device Name*.

🖳 HW Config - SIMATIC 300 Station								
Station Edit Insert PLC View Options Window Help								
D 🚅 📽 📓 🖏 	Download Upload	Ctrl+L						
	Download Module Identification Upload Module Identification to PG Faulty Modules							
2 X1 X2 X2 P1 <u>X2 P2</u> <u>3</u>	Module Information Operating Mode Clear/Reset Set Time of Day Monitor/Modify Update Firmware Save Device Name to Memory Card	Ctrl+D Ctrl+I	PROFINET-IO-System (100)					
	Ethernet	•	Edit Ethernet Node					
(1)	Save Service Data	•	Assign Device Name					

15) Click the **Assign name** button to give the RTA gateway a name. This name will appear on the RTA PROFINET configuration page. If you would like to assign your own name simple right click on the RTA device and select the objects properties.

Assign device r	iame					×
Device name:	rta-460ps		•	Device	460PSxx	
Available devic	es:				,	
IP address	MAC address	Device type	Device name		Assign name	
192.168.0.101	00-03-F4-09-8C-49	460PSxx	rta-460ps		– Node flashing test –	
					Duration (seconds):	3 🔻
					Flashing on	-lashing off
		_				
Show only o	devices of the same ty	pe 🔲 Display	only devices withou	ut names		
Update	. Exp	Jort				
Close]					Help



16) Expand the Standard node on the right panel to show the available modules to insert (Refer to the picture in Step 11).

Input	Slots (460PS	SMC to Profinet IO)	Output Slots (Profinet IO to 460PSMC)			
Slot	Data Size (Bytes)	Data Format	Slot	Data Size (Bytes)	Data Format	
1	128 🗸	8 Bit Int 🗸	11	128 🗸	8 Bit Int 🗸	

To match the above configuration in the 460 gateway, add one 128-byte input module to slot 1, and one 128-byte output module to slot 11.

Siemens PLC Configuration:

(≯	(1) ps01					
Slot		Module	Order number	I address	Q address	Diagnostic address:	Comment
0	i 📩	ps01	66K1 953-0CAU			2042*	
-87		Interface				2041*	
F1		RI45 10/100				2040*	
1		128 bytes I		0127			
2							
3							
4							
5							
6							
7							
8							
9							
10							
11		128 bytes O			0127		
12							
13							

17) When finished, click the Save and Compile button and then the Download to PLC button.



NOTE: When using a Short String Data Type, the 1st byte of each slot is reserved for the Length field. The remaining bytes will be used for the actual data.

Terminology Note and Example: I addresses refer to input, Q addresses refer to output, %B refers to bytes and %W refers to words. So in this case, %IB0 would be used to represent how many bytes to read starting from %IB1 up to %IB127. Likewise, %QB0 would be used to represent how many bytes of information to write starting from %QB1 up to %QB127.

Real Time Automation, Inc.



Setting up the PLC- Example Using TIA Portal

This is how you would set up the following example in your controller.

Input	Slots (460PS	SMC to Profinet IO)	Outpu	Output Slots (Profinet IO to 460PSMC)				
Slot	Data Size (Bytes)	Data Format	Slot	Data Size (Bytes)	Data Format			
1	8 🗸	16 Bit Uint 🗸	11	32 🗸	32 Bit Int 🗸			
2	128 🗸	32 Bit Uint 🗸	12	Disabled V	16 Bit Int 🗸			

1) In your project, click the Device View tab and select your PLC.



2) IF YOU HAVE ALREADY INSTALLED THE GSD FILE, SKIP TO STEP 9.

OTHERWISE - Under Options, select Manage general station description file (GSD).





3) On the RTA PROFINET IO Server configuration page, download the zip file

GSDML and Graphic Files

GSDML-V2.35-RTA-460PS-20190930.zip

- 4) Browse to folder containing the GSD file.
- 5) Check the box to the left of the imported path and click **Install**.

Manage gener	al station description files				×
Source path:	C:\Users\engineering\Desktop				
Content of in	nported path				
File		Version	Language	Status	
GSDML-V2.3	34-RTA-460PS	V2.34	English	Already installed	

6) Click **Close** when it was installed successfully.

IS	tallation result	
	Message	
•	Installation was completed successfully.	



7) Click the Network View tab in your project.



9) Drag the 460PSxx 1-port next to the PLC, click on the Not Assigned and select the PLC to connect to.

PLC_1	rta-460ps
CPU 1212C	460PSxx 1-port
	Not ass Select IO controller
	PLC_1.PROFINET interface_1

10) Once the RTA device is in the network click the Device view tab.

📱 Topology view	🔒 Network view	Device view	
-----------------	----------------	-------------	--

11) From the dropdown menu select rta-460ps. Right click on the RTA device to select Properties.

d+	rta-460ps	- E	
	<select device=""></select>	1	~
	rta-460ps		=

- 12) Go down to the Ethernet addresses.
- 13) Be sure that the "*IP address is set directly at the device*" option is selected and **uncheck** the "Generate PROFINET device name automatically."

Real Time Automation, Inc.



- a. *The **PROFINET Device Name** field is the name to assign to the RTA gateway
- b. *Make sure the PROFINET device and the gateway are on the same network.

rta-460ps [Module]							
General IO tags Sys	tem constants Texts						
▼ General Catalog information	Ethernet addresses						
▼ PROFINET interface [×1]	Interface networked with						
General Ethernet addresses	Subnet:	PN/IE_3					
Advanced options		Add new subnet					
Real time settings	IP protocol						
IO cycle RI45 10/100 MBit/s [X1 P1]							
Hardware identifier	Use IP protocol	Set IP address in the project					
Identification & Maintenance Hardware identifier		IP address: 10 . 1 . 0 . 1					
		Subnet mask: 255 . 255 . 0 . 0					
		Use router					
		Router address: 0 . 0 . 0 . 0					
		0					
	PROFINET						
		Generate PROFINET device name automatically					
	PROFINET device name	rta-460ps					
	Converted name: Device number:	rta-460ps					
		L.					

14) Right click on the RTA device and select the Assign device name.





15) Select the RTA device and click the **Assign name** button to give the RTA a valid name on the network. Once the RTA gateway is in run mode this name will appear on the PROFINET web page.

	ce name.								
	Configured PROFINET device								
		PROFINET devic	PROFINET device name: rta-460ps						
		Device type: 460PSxx 1-port							
	Online access								
		Type of the PG/PC i	nterface:	PN/IE	•	•			
	PG/PC interface: 🛛 🗰 ASIX AX88772 USB2.0 to Fast Ethernet Adapt 💌 🐨 🧕								
6		Device filter							
8	Device filter								
	Only show devices of the same type								
		Only show	devices with	bad parameter settings					
	Onlyshow devices without names								
		_ only show	actices with	ouchanics					
	Accessible dev	ices in the network:							
	IP address	MAC address	Device type	PROFINET device name	Status				
	IP address 10.1.16.40	MAC address 00-03-F4-0B-C3-02	Device type RTA	PROFINET device name rta-460ps	Status				
	IP address 10.1.16.40	MAC address 00-03-F4-08-C3-02	Device type RTA	PROFINET device name rta-460ps	Status				
	IP address 10.1.16.40	MAC address 00-03-F4-0B-C3-02	Device type RTA	PROFINET device name rta-460ps	Status				
	IP address 10.1.16.40	MAC address 00-03-F4-08-C3-02	Device type RTA	PROFINET device name rta-460ps	Status				
Flesh LED	IP address 10.1.16.40	MAC address 00-03-F4-08-C3-02	Device type RTA	PROFINET device name rta-460ps	Status OK				
Fløsh LED	IP address 10.1.16.40	MAC address 00-03-F4-08-C3-02	RTA	PROFINET device name rta-460ps	Status OK				

16) To match the above configuration in the 460 gateway, add one 8-byte input module to slot 1, one 128-byte input module to slot 2, and one 32-byte output module to slot 11.

nput	Slots (460PS	SMC to Profinet IO)	Output Slots (Profinet IO to 460PSMC)				
Slot	Data Size (Bytes)	Data Format	Slot	Data Size (Bytes)	Data Format		
1	8 🗸	16 Bit Uint 🗸	11	32 🗸	32 Bit Int 🗸		
2	128 🗸	32 Bit Uint 🗸	12	Disabled V	16 Bit Int 🗸		



17) Expand the Module list under the catalog on the right panel to show the available modules to insert into the device overview slots.

_Test_Setup → PLC_1 [CPU 1212C AC/D	C/Rly] → Distr	ibuted VO → PROFIN	IET IO-System ((100): P	N/IE_1 → p	os01	_ 🗗 i	×	Hardware catalog
			🛃 Topology v	iew (🔒 Network	c view	📑 Device view	/	Options
ps01	📑 🗌 Devic	e overview							
none an and a second se	▲	. Module	Rack	Slot	I address	Q addr	Туре		✓ Catalog
		▼ ps01	0	0			Standard	~	<search></search>
		Interface	0	0 ×1			ps01		🖾 Filter
ai		8 bytes I_1	0	1	18		8 bytes l		Head module
Q2		128 bytes I_1	0	2	68195		128 bytes I		
			0	з					128 bytes I
			0	4				=	128 bytes 0
			0	5					16 bytes I
			0	6					16 bytes O
			0	7					32 bytes l
			0	8					32 bytes O
	•		0	9				1000	64 bytes l
			0	10					64 bytes O
		32 bytes O_1	0	11		132	32 bytes O		🚺 8 bytes I
			0	12					🚺 8 bytes O
			0	13					
			0	14					
			0	15					

To insert a module, double click to add it to the next available slot.

Terminology Note and Example: I addresses refer to input, Q addresses refer to output, %B refers to bytes and %W refers to words. So in this case, you would use %IB1-8, %IB68-195 and %QB1-32 to access the data to/from the gateway in the PLC.

18) the Network view tab, click the port of PLC, click the Compile button and Download to Device button (in red).

📑 📑 🔚 Save project	🔳 X	🗎 📋 🗙 🍤 t (*	🖥 🛄 🖸 🖳	RT 💋	Go online 📓 Go offline
--------------------	-----	--------------	---------	------	------------------------

19) Once everything is downloaded to the PLC there will be a green check box on both devices, then click **Go Online** (see red box).

📑 📑 🔒 Save project 昌 🐰 🗐 😭 🗙	🎝 ± (레 ± 🖪 🔃 🖬 !	🖳 🔛 💋 Go onl	ine 💆 Go offline
	Д IO s	system: PLC_1.PROF	NET IO-System (100)
PLC_1 CPU 1212C	PS01 Standard PLC_1 NET IO-Syste		

NOTE: When using a Short String Data Type, the 1st byte of each slot is reserved for the Length field. The remaining bytes will be used for the actual data.

Real Time Automation, Inc.



Virtual Com Config

The Virtual Com Port Configuration page is used to configure serial settings when utilizing a serial connection over USB. This connection would be enabled by a device equipped with something such as the FT232R chipset from FTDI. If a USB serial connection is not being utilized, the settings on this page will not affect communication in any way.

Virtual Com Port Configuration			
Serial Port 1 Baud Rate:	19200 🗸	Serial Port 2 Baud Rate: 19200 v	
Parity:	None v	Parity: None V	
Data Bits:	8 ~	Data Bits: 8 🗸	
Stop Bits:	1 ~	Stop Bits: 1 v	
Flow Control:	None v	Flow Control: None V	
Inactivity Reconnect:	0	Inactivity Reconnect: 0	
Version Number 5		Version Number 5	
		Save Parameters	

NOTE: If the Version Numbers shown under each port do not match, or one of both of them are blank, please contact RTA for support.

How to Know if a Device is Using Serial over USB

This would typically be called out in a devices documentation, if the documentation lists settings for baud rate, data bits, stop bits, or parity under the USB section, it is likely using serial over USB. This can be verified by sending data to a terminal program running on a PC. Some examples of terminal programs are TerraTerm, Putty, or RealTerm.

How to Check Chipset Type

The 460 gateways USB serial connection will only work with chipsets from the manufacturer FTDI. To ensure a USB serial device will work it is recommended to verify that it is using an FTDI chipset. To verify this:

- 1. Plug the USB serial device into a Windows PC.
- 2. Open Device Manager.
- 3. Find your USB serial device in Device Manager. (Likely under the Ports section)

Real Time Automation, Inc.


4. Right Click your device and select "Properties"

🗄 Device Manager		-	×
File Action View Help			
⊨ ⇒ 🖬 🔟 🔡 🖬 😽 !			
> 👝 Disk drives			
> 🏣 Display adapters			
> 🎽 Firmware			
> 🕅 Human Interface Devices			
> 🔤 Keyboards			
> Memory technology device	5		
> II Mice and other pointing de	vices		
> 🛄 Monitors			
> 🕎 Network adapters			
V Ports (COM & LPT)			
🗍 Intel(R) Active Manager	nent Technology - SOL (COM3)		
RS-485 Isolated Port (CC	IM4)		
USB Serial Port (COM6)			
> 🚍 Print queues	Update driver		
> 🗃 Printers	Disable device		
> Processors	Uninstall device		
> Security devices			
> 🔚 Sensors	Scan for hardware changes		
> SIMATIC NET	Properties		
> Software components	Toperties		
Software devices	1		
> iii Sound, video and game col	trollers		
Storage controllers			
System devices			
Universal Serial Bus control	ers		
S III THINKING SATSPIAL BUC HEVICES	le attent		

5. In the properties window ensure the manufacturer is FTDI. If the manufacturer is not FTDI the USB serial connection likely will not work with the 460 gateway.

USB Seria	al Port (COM6) Pr	operties	×
General	Port Settings Dr	iver Details Events	
	USB Serial Port (COM6)	
	Device type:	Ports (COM & LPT)	
	Manufacturer:	FTDI	
	Location:	on USB Serial Converter	
– Devic [This	e status device is working p	property.	
		×	
		OK Can	cel

Inactivity Reconnect

The USB Inactivity Reconnect configuration allows the configuration of an idle timeout of 1-60 minutes for the connected USB device. If a new message from the connected HID device is not received in the configured interval, the gateway will reset the USB connection to ensure the device is still connected. The default value of 0 will disable this feature.



ASCII Configuration



1) To add an ASCII device or additional ASCII devices, click the -Select- dropdown menu under ASCII Configuration and select **Add Generic ASCII** option.



- a) To remove a device, navigate to the ASCII device to delete using the << and >> buttons and click the **Delete ASCII Device** button.
- b) To create a new ASCII device with the same parameters already configured from another ASCII device, click the -Select- dropdown menu and select the **Add from ASCII X** option (where X represents the ASCII device you wish to copy parameters from).
- c) Once created, you can make any additional changes needed to that new ASCII device.
- 2) The **Enable** check box should be selected for the device.
- 3) **Port**: Select which port is being used for communication. This port must be configured on the Port/USB or TCP/IP (depending on your product) Configuration page. If it has not yet been configured, it will not display in this dropdown.
- 4) Enter a **Device Label** to identify the device within the gateway.
- 5) **LED Inactivity Timeout**: Enter the amount of time, in seconds, to wait before flashing the LED red indicating that no messages have been received or transmitted during this time.
- 6) Operation Mode:
 - a. Mark Data New on Change of State: Send data to the mating technology, on a per point basis, upon a change of state. For more explanation see the <u>Receive Data Operation Mode</u> section below.
 - b. Mark Data New on New Message: Send data to the mating technology for all data points, no matter change of state or not. For more explanation see the <u>Receive Data Operation Mode</u> section below.

Enable				
Port -Select- V			Device Label ASCII0	1
LED Inactivity 0 0-60000 s			Operation Mode Mark Data New	on Change of State 🗸



Receive Data

This side is configured to receive data from the ASCII device into the gateway.

Receive Data (ASCII to 460ETCTCP) Enable:							
Max Message Length: 1	1-1024 chars						
Receive Character Timeout: 0	0-60000 ms						
Delimitore	,						
Start 0 ~ [NUL] 0 0x00 ~	[NUL] 0 0x00 V						
End 0 v [NUL] 0 0x00 v	[NUL] 0 0x00 v						
Remove Delimiters from ASCI	l Message: 🔲						
ASCII Parsing (Option	nal)						
ASCII Conversion: None	~						
Gateway Hold Msg Timeout: 0 0-60000 ms							
Queue Full Behavior: Discard	Old 🗸						
Queue Size: 5	1-20 messages						

Use the following fields to determine when a message has been received.

- 1) **Enable**: Check this box to configure the Receive Data section.
- 2) Max Message Length: Enter the max number of characters that can be received by the gateway.

Example: Max Message Length is set to 5 and the message of "helloworld" was sent by the ASCII device. This will be sent to the other protocol as "hello" followed by "world" as two messages.

3) **Receive Character Timeout:** Enter the max amount of time (in ms) between characters that the gateway will wait before issuing a timeout and calling the message complete.

Example: If Max Message Length varies in size, then use a timeout to call the message complete rather than message length. You can also use End Delimiters (below) to call a message complete.

- 4) **Number of Start Delimiters:** Select the number of delimiters that the gateway should look for before the gateway processes the data.
- 5) Select Start Delimiters: Select the Start Delimiters that the gateway should look for.
- 6) **Number of End Delimiters:** Select the number of delimiters that the gateway should look for to call a message complete.
- 7) Select End Delimiters: Select the End Delimiters that the gateway should look for.
- 8) **Remove Delimiters from ASCII Message:** If checked, the gateway will remove all delimiters that have been configured before sending it to the other protocol.
- 9) **ASCII Parsing (Optional):** Additional parsing can be performed on the string before being passed to the other protocol. See the <u>ASCII Configuration ASCII Parsing</u> section for more information.



10) ASCII Conversion

- a. None received string is treated as is
- b. ASCII Hex received string must be Hex Digits 0 F in ASCII
- c. ASCII Raw: received string will be mapped (memory copy) to the byte of data configured
- 11) Gateway Hold Msg Timeout: Enter the amount of time (in ms) to wait before sending a new message to the other protocol.
- 12) **Queue Full Behavior**: Select which message to discard when the queue is full. Once the queue is full, the gateway will discard either the oldest or newest message (Only used if Gateway Hold Msg Timeout is non-zero).
- 13) **Queue Size**: Select how many complete messages the gateway will hold before starting to discard (Only used if Gateway Hold Msg Timeout is non-zero).

Receive Data – Operation Mode

Mark Data New on Change of State (COS)

When data comes into the RTA gateway, it will be sent over to the matting protocol only if the data has a different value.

Operation Mode Mark Data New on Change of State 🗸

Example for 460ETCA

Operator scans "HelloWorld" with a barcode scanner. That data is gathered in the ASCII side of the RTA gateway, and is then processed and sent over to the ETC side and written over to the Allen-Bradley PLC. The next time the operator scans the same barcode "HelloWorld", the ASCII side gathers the data, but the data didn't change so it will not be sent over to the ETC portion of the RTA gateway. If the operator scans "1234567890" with the barcode scanner, the ASCII side of the RTA gateway will process the data and since the data has changed it will be sent over to ETC and sent over to the PLC.

Mark Data New on New Message

When data comes into the RTA gateway, it will be sent over to the matting protocol regardless if it's the same data. This allows you to send the same data again to the mating protocol.

Operation Mode Mark Data New on New Message

Example ETCA

Operator scans "HelloWorld" with a barcode scanner. That data is gathered in the ASCII side of the RTA gateway, and is then processed and sent over to the ETC side and written over to the Allen-Bradley PLC. The next time the operator scans the same barcode "HelloWorld", the ASCII side gathers the data, it gets processed then sent over to the ETC portion of the RTA gateway to be sent out. If the



operator scans "1234567890" the ASCII side of the RTA gateway will process the data and send it over to ETC side and then the PLC.



Transmit Data

This side is configured to transmit data from the gateway into the ASCII device.

Transmit Data (460ETCTCP to Enable:	ASCII)
Max Message Length: 1	1-1024 chars
Transmit Timeout: 0	0-60000 ms
Delay Between Messages: 0	0-60000 ms
Add Delimiters to ASCII Message Start 0 v [NUL] 0 0x00 v End 0 v [NUL] 0 0x00 v	[NUL] 0 0x00 v
ASCII Concatenating (Op	ptional)

Use the following setup fields to help the 460 transmit an ASCII message.

- 1) **Enable**: Check this box to configure the Transmit Data section.
- 2) Max Message Length: Enter the max number of characters that can be transmitted by the gateway.
- 3) **Transmit Timeout:** Enter the amount of time (in ms) that the gateway waits before sending an ASCII message (0 Sends Immediately). If the data has changed before the time expires, the gateway immediately sends the message to the ASCII device.
- 4) **Delay Between Messages:** Enter the amount of time (in ms) that the gateway waits before verifying a Change of State of the ASCII message OR will start the Transmit Timeout.
- 5) **Number of Start Delimiters:** Select the number of delimiters that will be added onto the beginning of the ASCII string.
- 6) Select Start Delimiters: Select the Start Delimiters that should be added to the ASCII string.
- 7) **Number of End Delimiters:** Select the number of delimiters that will be added onto the end of the ASCII string.
- 8) Select End Delimiters: Select the End Delimiters that should be added to the ASCII string.
- ASCII Concatenating (Optional): Additional concatenating can be performed on the string before being written to the ASCII device. See the <u>ASCII Configuration - ASCII Concatenating</u> section for more information.
- 10) ASCII Conversion:
 - **a.** None transmit string is treated as is.

b. ASCII Raw - transmit string will be mapped (memory copy) from the byte of data configured.Real Time Automation, Inc.421-800-249-1612



Transmit Data – Triggering Methods

There are 3 methods that determine when the message is ready to be transmitted to your ASCII device:

- 1) **Cyclic** This means that every *x* ms a new ASCII message will be transmitted, regardless of whether the data has changed or not.
- 2) **Triggering** This means that a trigger event determines when a new ASCII message will be transmitted.

Some methods can co-exist with others. Here are the optional rules:

a) **Option 1:** Change-Of-State is defaulted, so this method is chosen if the Transmit Timeout field is left at 0 and **ALL** data is new.

Example 1: Send a message of "hello" from the PLC to the RTA gateway. The ASCII device see's "hello". Send "hello' again and nothing will happen because of the RTA Change-of-State Rule.

Transmit Data (460 to ASCII)
Enable: 🗹
Max Message Length: 82 0-1024 chars
Transmit Timeout: 0 0-60000 ms
Delay Between Messages: 0 0-60000 ms
Add Delimiters to ASCII Message Start 0 • [NUL] 0 0x00 • [NUL] 0 0x00 • End 0 • [NUL] 0 0x00 • [NUL] 0 0x00 • ASCII Concatenating (Optional)

b) Option 2: Technology Triggering (A/USB/TCP/WI). This method is chosen if the Transmit Timeout field is left at 0 and the Trigger Variables (as described in <u>ASCII Configuration –</u> <u>Technology Triggering Method</u> section of this manual) are mapped. This will disable Change-of-State. This method is recommended if your product in **NOT** an 460ETC product.

NOTE: If you have an 460ETC it's high recommended you use the Optimization Triggering.

Example 2: Using the Technology Triggering Mappings (shown below in the Technology Triggering Method section), you can make the data new only with a trigger. If you want to send the same/new message of based on a trigger and NOT cyclically, keep the Transmit Timeout at 0 **AND** use the 2 Trigger Mappings. *See below for more examples in the <u>ASCII Configuration – Technology Triggering Method.</u>*



c. **Option 3:** Cyclic and Trigger can co-exist. For this to happen, the Transmit Timeout field needs be to nonzero and the Trigger Variables (as described in <u>ASCII Configuration – ASCII Message</u> <u>Triggering Method</u> section of this manual) are also mapped.

Example 3: Send a message of "hello" from the PLC. Based on whatever is triggered first (the 3000ms Timeout or the Trigger data point), the ASCII device will get updated. If the trigger data point is not updated, the then the RTA gateway will send the data every x ms to the ASCII device. See below for more examples in the <u>ASCII Configuration – Technology Triggering Method.</u>

Transmit Data (460 to ASCII) Enable:
Max Message Length 82 0-1024 chars
Transmit Timeout: 3000 -60000 ms
Delay Between Messages: 0 0-60000 ms
Add Delimiters to ASCII Message Start 0 • [NUL] 0 0x00 • [NUL] 0 0x00 • End 0 • [NUL] 0 0x00 • [NUL] 0 0x00 • ASCII Concatenating (Optional)



ASCII Configuration – Technology Triggering Method

This method allows the other protocol to signal when to send the next message using data handshakes. These "signals" are controlled using data variables (TransTrigger and TransHandshake) already in the mapping. Then Method will send the new/old data when triggered.

NOTE: These two data variables will need to be mapped manually on the Data Mapping webpage since it will not be mapped using Auto-Map.

While these two data variables are mapped, the Change-of-State method is disabled but messages can still be sent via the cyclic method, if configured. For more information on the ASCII triggering methods, please see the <u>Transmit Data – Triggering Methods</u> section of this user guide.

C Enable	Mapping 1								
Source	Enable Manipulation	Destination							
Group: [rta-ps OUT_Slot12[0] (Int8) Start: [OUT_Slot12[0] End: [OUT_Slot12[0]	• • -> • •	Group: ASCII01 TransTrigger (Uint16 V) Start: TransTrigger V End: TransTrigger							
Enable Mapping 2									
C Enable	Mapping 2								
Source	Mapping 2	Destination							

How the triggering method works: The example shown below is our 460PS* (*A/TCP/USB)

- 1) The mating protocol sends a numbered value to the ASCII TransTrigger diagnostic variable. This value must be different from the previous value for a new message to be triggered. The following example is Slot 12[0] as the trigger for the PLC to update everything in Slot 11[0] which is the data.
- 2) Depending on the TransTigger value in the Display Data page, one of 4 things will occur:
 - a) If TransTrigger = 65535, then the triggering method is disabled. Usually on powerup.

RTA460 Disp	lay Data Exc	ample:				
	ASCII		460PSA	L	Profinet I	0
Name	Valu	le (Hex)	Manipulati	on Name	Val	ue (Hex)
TransTrigger	65535	0xFFFF	*	OUT_Slot12[0]	-1	0xFF



b) If TransTrigger = 0, then the triggering method is enabled, but no message will transmit. RTA460 Display Data Example:

ASCII		460PSA € €		Profinet IO		
Name	Va	lue (Hex)	Manipulati	on Name	Val	ue (Hex)
TransTrigger	0	0x0000	**	OUT_Slot12[0]	0	0x00
Trans_Field01	11	0x000B	*	OUT_Slot11[0]	11	0x0B

TIA Portal Example: The data will still go to the RTA gateway, however the RTA gateway will NOT transmit the data to the ASCII device until the Slot12[0] triggers the TransTrigger.

* · · · · · · · · · · · · · · · · · · ·								
	i	Name	Address	Display for	Monitor	Modify va	4	Comment
1			%QB80	DEC+/-		11	🗹 🔺	Data to RTA ASCII
2			%QB88	DEC+/-		0	A	Trigger data to RTA

c) If TransTrigger is between 1-65534 AND the value IS equal to the TransHandshake diagnostic variable, then no new message will transmit, until Slot 12[0] triggers again.

KI A400 Dispit	iy Dulu Exu	inpie.				
	ASCII		460PSA		Profinet IC)
Name	Value	(Hex)	Manipulatior	n Name	Valu	ıe (Hex)
TransTrigger	1	0x0001	*	OUT_Slot12[0]	1	0x01
	ASCII		460PSA →→		Profinet IC)
Name	Value	e (Hex)	Manipulation	Name	Valu	e (Hex)
TransHandshake	1	0x0001	$\rightarrow \rightarrow$	IN_Slot2[0]	1	0x01

PTAA60 Display Data Example:

TIA Portal Example:

Ý	2	🗲 🇓 🐬 1 1	6 🌮 '	∋on oon ⊳ 1									
	i	Name Ad	dress	Display for	mat	Monitor va	alue	Modify valu	e	9		Comment	
1		%0	B80	DEC+/-				11				Data to RTA AS	BCII
2		%Q	B88	DEC+/-				1		$\mathbf{\sim}$	1	Trigger data t	o RTA
	*	🥐 📴 🕹	1 H	2	5 1								
		Address	Displa	y format	Moni	tor value	Mod	lify value	9		Co	mment	
	1	%IB92	DEC+	-	0						De	ita From RTA	
	2	%IB100	DEC+	-	1						RT/	A Handshake	



d) If TransTrigger is between 1-65534 **AND** the value **IS NOT** equal to the TransHandshake diagnostic variable, then a new message will be transmitted. The value in TransTrigger will then be moved to TransHandshake.

TIA Portal Example: Once the Slot12[0] increments (data is sent from the PLC to the ASCI device) then the Slot2[0] will get updated with the handshake



ASCII Configuration – ASCII Parsing

The ASCII Parsing feature allows you to break apart an incoming ASCII string by delimiter or character offset into multiple data fields. You can then apply a data type to the fields and deliver them to user defined locations in the mating protocol. Click the **ASCII Parsing (Optional)** button at the bottom of the ACII Configuration page to access the ASCII Parsing Configuration page for this device.

Il Parsir	ig Configurat	ion			Help			
		[<< <u>1</u> >> 1-1					
		ASCII	Device 1 (ASCII01))				
Max	Max Number of Fields: 1 1-50 Min Number of Fields: 1 1-50							
	Parsing Delimiter: UNUSED							
-			Update Fields					
Field	Start Location	Length	Data Type	Internal	Tag Name			
1:	1	0	String V	Recv_Field01				
Same			Save Parameters	1	Show Posults			
Field			Pacult		Show Results			
1.	Number of Field	s Invalid	Result					
1923		e in traine						

- 1) Max Number of Fields: This indicates the max number of fields the ASCII data will be parsed into (up to 50 values per message).
- 2) Min Number of Fields: This indicates the min number of fields that must be present in an ASCII string for the message to be considered valid. An error will be flagged if the actual number of fields is less than this value.
- 3) **Parsing Delimiter:** This defines the delimiter that will be used to parse an ASCII message. If delimiters are not present, select UNUSED and use the length fields to parse the message.
- 4) Start Location & Length:
 - a. If a Parsing Delimiter is used, the **Start Location** will be the first character of the data field. The **Length** will be the number of characters from the Start Location. If the **Length** is 0, the gateway will read the entire field.
 - b. If the Parsing Delimiter is unused, then the Start Location will be the first character of the string. The Length will be the number of characters from the Start Location. If the Length is 0, the gateway will read the entire message from the Start Location to the end of the ASCII string.
- 5) **Data Type:** Select the data type of the parsed value.
- 6) **Internal Tag Name:** Enter a name to reference this tag within the gateway's display and mapping pages.



ASCII Configuration – ASCII Parsing Examples

Example #1 - Parsing a message using the Parsing Delimiter option:

In this example, we are separating the string "12.25,SP100,temp setpoint" by a comma delimiter. The first value is being parsed into a float data type, the second and third values are being parsed into a string data type. Since the Min Number of Fields is 3, all 3 fields must be present for the message to be considered valid and processed. The output is seen below:

		ASCII	Devic	e 1 (ASC	CIIO1)		
Max	Number of Fields	: 3 1-	-50	Min N	lumbe	r of Fields: 3	1-50
		Parsing De	elimiter:	. 44 0x	c2c	~	
			Update	e Fields			
Field	Field Start Location Length Data Type Internal Tag Name						Fag Name
1:	1	0	32 Bit	Float	~	Recv_Field01	
2:	1	0	String 🗸		Recv_Field02		
3:	1	0	String	8	~	Recv_Field03	
2			Save Pa	rameters			
Samp	ole/Test Data: 12.2	25,SP100,temp setp	oint				Show Results
Field				Result			
1:	12.25						
2:	SP100						
3:	temp setpoint						
	00- 1	* The length of rea	sult is g	reater that	n 64 c	haracters	50

Example #2 - Parsing a message without the Parsing Delimiter option:

In this example, we are separating the fields in the string "12.25,SP100,temp setpoint" using the start and length parameters. The first value is being parsed from the 1st character for a length of 5 and stored into a float data type. The second value is being parsed from the 7th character for a length of 5 characters and stored into a string data type. The third value is being parsed starting from the 13th character for the rest of the remaining characters and stored into a string. The fourth value contains the entire ASCII message and is stored into a string. Only the first field needs to be present for the data to be considered valid and will be processed. If less than field 1 is present, the message will not be parsed and will be flagged an error. The output is seen below:



		ASCI	Devic	e 1 (ASCIII	01))		
Max	k Number of Fields	: 4	1-50	Min Nur	nbe	er of Fields: 1 1-50		
		Parsing E	Delimiter:	UNUSED		 ✓ 		
			Update	e Fields				
Field Start Location Length Data Type Internal Tag Name								
1:	1	5	32 Bit	Float N	~	Recv_Field01		
2:	7	5	String	•	~	Recv_Field02		
3:	13	0	String		~	Recv_Field03		
4:	1	0	String		~	Recv_Field04		
Sampl	e/Test Data: 12.25	,SP100,temp setpo	Save Pai	ameters)		Show Results		
Field				Result				
1:	12.25							
2:	SP100							
3:	temp setpoint							
4:	12.25,SP100,tem	o setpoint						

Example #3 - Parsing a message using the Parsing Delimiter option and Start Location and Length: In this example, we are separating the fields in the string "12.25,SP100,temp setpoint" using the comma delimiter, the start, and length fields. The first value is being parsed from the 1st character for a length of 2 and stored into an integer data type. The second value is being parsed from the 3rd character of the second comma-parsed field for the remainder of that field and stored into an integer data type. The third value is being parsed starting from the 1st character of the third comma-parsed field for that entire field and stored into a string. All 3 fields need to be present for the message to be valid. The output is seen below:

		ASCII	Devic	e 1 (ASCII01)	1				
Max	Number of Fields	: 3 1	-50	Min Numbe	er of Fields: 3	1-50			
		Parsing D	elimiter:	. 44 0x2c	~				
			Update	Fields					
Field	Field Start Location Length Data Type Internal Tag Name								
1:	1	2	16 Bit	Int V	Recv_Field01				
2:	3	0	16 Bit	Int 🗸	Recv_Field02				
3:	1	0	String	~	Recv_Field03				
			Save Pa	rameters					
Samp	le/Test Data: 12.2	25.SP100.temp setp	oint			Show Results			
Field				Result					
1:	12								
2:	100								
3:	temp setpoint								
		* The length of re	sult is g	reater than 64 c	haracters				



ASCII Configuration – ASCII Concatenating

The ASCII Concatenating feature allows you to combine multiple data points and locations, in the mating protocol, into a single ASCII string. Click the **ASCII Concatenating (Optional)** button at the bottom of the ACII Configuration page to access the ASCII Concatenating Configuration page for this device.

ASCII	Concatenating Co	onfiguration			F	lelp			
	<< <u>1</u> >> 1-1								
ASCII Device 1 (ASCII01)									
	Number of Fields: 1 1-50 Concatenating Delimiter: UNUSED V								
			Update Fields						
Field	Data Type	Internal Tag Name or Constant Name	Data Format	Max Characters	Padding	Add Delim			
1:	String V	Trans_Field01	N/A 🗸	0	None V				
		Sa	ave Parameters						
		Sa	ample Result						
			XXXXXXXXXX						
		* The length of resu	It is greater than 64	characters					

- 1) **Number of Fields:** This indicates how many values will be concatenated together to form a single ASCII message (up to 50 values per message).
- 2) **Concatenating Delimiter:** This adds a delimiter between data fields in the ASCII string. If a delimiter should not appear between each of the fields, select UNUSED.
- 3) **Data Type:** Select the data type of the parsed value.
 - a. Signed and Unsigned 8/16/32/64 Bit Integers
 - b. 32/64 Bit Floating Points
 - c. String in order to use, a String data type must be selected in the other protocol. Cannot concatenate an Integer to a String.
 - d. Constant String
- 4) Internal Tag Name/Constant Name:
 - a. If Data Type other than Constant String is selected, this will be the name to reference this tag within the gateway. This value is used on the display page and the mapping page.
 - b. If Data Type Constant String is selected, then this is the string value that will send.

5) Data Format:

- a. %d used for Signed Integers
- b. %u used for Unsigned Integers
- c. %If used for Floating Points with no set decimal precision
- d. %.1lf...%.6lf used for Floating Points to show the offset of the decimal point value

1-800-249-1612



- i. EX: 123.456789 set as %.3lf will display as 123.456
- e. %e used for Exponential Notation
- f. %x used to represent Hexadecimal values for Signed/Unsigned Integers or Floating points
- g. String and Constant String Data Types do not use this field
- 6) **Max Characters:** This is the Max Number of Characters that can be transmitted for a single field. <u>Special Cases</u>
 - a. If set to 0, the entire field is transmitted.
 - b. If the length of the value is less than the Max Characters, then the Padding Character will be used (if set).
 - c. If the length of the value is greater than the Max Characters, then the value will be truncated.
- 7) **Padding:** If the length of the value is less than the Max Characters padding Zeroes, Spaces, or Nothing to the remaining character placeholders, the padding will occur to the left of the value.
- 8) Add Delim: Used when a Concatenating Delimiter is selected. Check to add the Concatenating Delimiter to the end of that field.
- 9) **Sample Result:** This will display an example of how the data will output. This will not display live data. It provides an example of the string structure.

NOTE: Sample Result field will only show the first 64 characters of the message.

- a. String data and Constant data types will display as x's.
- b. Any other data type will display as *i*'s.

NOTE: For display purposes, if Max Characters is set to 0, only 10 characters will display for that field in the Sample Result section. The true value, if larger, will be processed correctly.

EX: Field 1 is set for a String data type and Max Characters is set to 0, only 10 x's will display in the sample result even though the max character length is set to 50.



ASCII Configuration – ASCII Concatenating Examples

Example #1 - Concatenating a message using the Concatenating Delimiter option:

In this example, the comma is selected as the Concatenating Delimiter. Let's look at each field closer:

- Field 1 –8 bit int represented as Trans_Field01 in the gateway. It will output as an integer with a max of 10 characters. No padding is used and a comma will be added to the end of the value.
 EX: "34,"
- 2) Field 2 –16 bit int represented as Trans_Field02. It will output in Hexadecimal with a max of 10 characters, padded with zeros and no comma will be added to the end of the value.
 o EX: "00000000A0"
- 3) Field 3 –32 bit int represented as Trans_Field03. It will output as an integer with a max of 10 characters, padded with spaces and a comma will be added to the end of the value.
 - EX: "____123456," (shown with _'s to see spaces)
- 4) Field 4 –32 bit float represented as Trans_Field04. It will output as a float with 2 decimal places with a max of 10 characters, padded with zeros and a comma will be added to the end of the value.
 - EX: "00001234.56,"
- 5) Field 5 –String represented as Trans_Field05 in the gateway. It will output as string with a max of 10 characters, padded with spaces and a comma will be added to the end of the value.
 - EX: "____testing," (shown with _'s to see spaces)
- 6) Field 6 Constant String will output as "RTA_MSG" with a max of 10 characters. No padding is used and no comma will be added to the end (though checked) since it is the last field.
 EX: "RTA_MSG"

ASCII C	oncatenating C	onfiguration				Help		
		<	< <u>1</u> >> 1-1					
		ASCII DO	evice 1 (ASCIIO	1)				
Number of Fields: 6 1-50 Concatenating Delimiter: . 44 0x2c ✓								
Update Fields								
Field	Data Type	Internal Tag Name or Constant Name	Data Format	Max Characters	Padding	Add Delim		
1:	8 Bit Int 🗸 🗸	Trans_Field01	%d 🗸	10	None 🗸	~		
2:	16 Bit Int 🗸	Trans_Field02	%x ∨	10	Zero 🗸			
3:	32 Bit Int 💙	Trans_Field03	%d 🗸	10	Space 🗸	~		
4:	32 Bit Float 🗡	Trans_Field04	%.2lf 💙	10	Zero 🗸	~		
5:	String V	Trans_Field05	N/A ¥	10	Space 🗸	~		
6:	Constant 🗸	RTA_MSG	N/A 🗸	10	None 🗸	\checkmark		
		Sa	ve Parameters					
		Sa	mple Result					
		innini,innini,innini,in	iiiiiiiiii,xxxxxxxxxx,RT	FA_MSG				
		* The length of resul	It is greater than 64	characters				



The sample belows shows the Transmit Data set up with the following delimiters.

	Max M	lessage Length	n: 82	0-1024 chars		
	Tra	ansmit Timeou	t: 1000	0-60000 ms		
Del	ay Betw	een Message	s: 0	0-60000 ms		
Add D	elimiter	s to ASCII Mes	sage			
Add D Start	elimiter	s to ASCII Mes	sage	% 37 0x25 ∨		

Example 1 Sample Result: This use case is sending data via 5 PLC tags. Using the concatenating setup example and the transmit example, the ASCII data will be display within your ASCII device shown as the example below.



ASCII Configuration – ASCII Message Counter

There is an additional ASCII variable that is very useful to access within the gateway's mating protocol. This data variable will need to be added manually since it will not be mapped using Auto-Map.

RecvCount- indicates how many ASCII messages have been successfully read by the gateway for that device. A successful incoming message means that at least one of our three end cases (Max Length, Timeout or Delimiters) has been met. This will match the Diagnostic Variable Successful Receive Count for each ASCII device.

This variable can be mapped to the mating protocol using the Data Mapping webpage. It is mapped just like the Status_XY variable described in the <u>Data Mapping- Adding Diagnostic Information</u> section of this user guide.

Example: For this example, the other protocol in the gateway is the Allen-Bradley PLC. As you can see from the picture below, the RecvCount for ASCII Device 1 is mapped to the first index of a PLC tag array called test_cnt. The data type of this tag is an Int32 to match the data type of RecvCount. The tag test_cnt[0] will now hold the number of successfully read messages from ASCII Device 1.

- Enable	Mapping 1			
Source	Enable Manipulation	Destination		
Group: ASCII01 RecvCount (Uint32) V	0	Group: ETC01 test_cnt[0] (Int32) V		
Start: RecvCount V	0 0 0 0 0	Start: test_cnt[0] V		
End: RecvCount ~		End: test_cnt[0]		

Application Use: This is particularly useful for applications connecting devices like barcode scanners and weigh scales. The gateway will cyclically update the mating protocol with the last ASCII message sent. A change in the RecvCount is the only way to identify a new message if the messages are identical.



Printer Port Status

UsbStatus - Indicates if there are any printer errors like paper empty when dealing with USB printer devices (Class 7 only). This Status will match the USB Port 0/1 Status on the diagnostics page and main page for each USB device connected to a printer.

ASCII Status	
Device Status:	Connected and Running
Queued Messages:	See Device Level
Last Parsed Error:	
USB Port 0 Status:	Printer: No Error, Selected, Paper Available
USB Port 1 Status:	Not Connected
LED Status:	Connection Status: Connected

The UsbStatus is a diagnostics variable already defined in the 460 gateway. For this example, the other protocol in the gateway is the Allen-Bradley PLC. As you can see from the picture below, the UsbStatus for ASCII Device 1 is mapped to a PLC tag called USB_Status. The data type of this tag is an Int32 to match the data type of UsbStatus. The tag USB_Status will now hold the printer status of ASCII Device 1.

Enable	Enable Mapping						
Source	Enable Manipulation	Destination					
Group: ASCII01 UsbStatus (Uint16) Start: UsbStatus End: UsbStatus	• • • • •	Group: ETC01 USB_Status (Int32) Start: USB_Status End: USB_Status					

Application Use: This is particularly useful if you wish to see the printer status from the other protocol connected to the gateway. Description of value is listed below:

- 24 = Printer: No Error, Selected, Paper Available
- 16 = Printer: Error Check Printer, Selected, Paper Available
- 56 = Printer: No Error, Selected, No Paper

Note: Some USB printers may not always be able to determine this information. In this case, they should return benign status of "Paper Not Empty", "Selected", and "No Error".



Mapping - Transferring Data Between Devices

There are 5 ways to move data from one protocol to the other. You can combine any of the following options to customize your gateway as needed.

Option 1 – Data Auto-Configure Mappings: The gateway will automatically take the data type (excluding strings) from one protocol and look for the same data type defined in the other protocol. If there isn't a matching data type, the gateway will map the data to the largest available data type. See Data Auto-Configure section for more details.

Option 2 – String Auto-Configure: The gateway will automatically take the string data type from one protocol and map it into the other. See String Auto-Configure section for more details.

Option 3 – Manual Configure Mappings: If you don't want to use the Auto-Configure Mappings function, you must use the manual mapping feature to configure translations.

Option 4 – Manipulation/Scaling: You can customize your data by using math operations, scaling, or bit manipulation. See Data Mapping-Explanation section for more details.

Option 5 – Move Diagnostic Information: You can manually move diagnostic information from the gateway to either protocol. Diagnostic information is not mapped in Auto-Configure Mappings Mode. See Diagnostic Info section for more details.

Going from Manual Mapping to Auto-Mapping will delete ALL mappings and manipulations configured.



Display Mapping and Values

The Display Data and Display String pages are where you can view the actual data for each mapping that is set up.

Display Data

Click the **Display Data** button to view how the data is mapped and what the values of each mapping are.



Here you will see how each data point (excluding strings) is mapped. To view, select the device from the dropdown menu and click **View** to generate the information regarding that device. Then select either the **Protocol 1 to Protocol 2** or **Protocol 2 to Protocol 1** button, correlating to the direction you wish to see the data.

Display Data	Edit Mapping View as Text
Select a Device Modbus TCP Server IP Address: 0.0.0.0 View	
Protocol 1 to Protocol 2	Protocol 2 to Protocol 1



This page is very useful when verifying that all data is mapped somehow from one protocol to another. If a data point is not mapped, it will display on this page in a yellow highlighted box. The Display Data page will display up to 200 mappings per page, simply navigate to the next page for the additional mapping to display.

Mo	dbus RTU to BACn	et/IP			BACnet/IP to Modb	us RTU
			< 1 > Displaying 1-201 of 3	> 300		
	Modbus RTU	I	460MMBS →→		BACnet/IP	
Name	Valu	le (Hex)	Manipulation	Name	Value	e (Hex)
400001			> >	AI1		
400002			→→	AI2	Mapping Dis	abled for Point
400003			>>	AI3		

In the above example, we see the following:

- Modbus register 400001 from Slave 1 is being mapped to Al1 on BACnet
- Nothing is being moved from Modbus register 400002 to AI2 on BACnet because the mapping is disabled
- Modbus register 400003 from Slave 1 is being mapped to AI3 on BACnet

NOTE: If a data point is mapped twice, only the first instance of it will show here. EX: If Modbus 400001 & 400040 from Slave 1 are both mapped to Al1, only 400001 will show as being mapped to Al1.

If there are values of "--" on this page, it indicates that the source has not yet been validated and no data is being sent to the destination.

The example below reflects the Modbus to PLC flow of data. The Modbus (left side) is the source and the PLC (right side) is the destination.

- The 460 gateway has received valid responses from Modbus registers 400001- 400005 and therefore can pass the data on to the PLC tag called MC2PLC_INT.
- The 460 gateway has NOT received valid responses from Modbus register 400011 & 400012. As
 a result, the data cannot be passed to the PLC tag ETC01_GN0_INT2 and indicates so by using "- "in the value column of the table.



Display Data	a					Edit Mapping View as Text
Select a Devic	e Modbus T	CP Server IP Addres	s: 10.1.16.16	View		
	Modbus TCP/	P to PLC			PLC to Modbus	TCP/IP
			<< Displayin	1 >> ng 1-7 of 7		
	Modbus	TCP/IP	460E	тсмс	PLC	
Name		Value (Hex)	Manip	ulation Name	Valu	ie (Hex)
400001	15	0x000F	→→	ETC01 MC2PLC_INT[0]	15	0x000F
400002	1495	0x05D7	→ →	ETC01 MC2PLC_INT[1]	1495	0x05D7
400003	1	0x0001	→ →	ETC01 MC2PLC_INT[2]	1	0x0001
400004	23	0x0017	→ →	ETC01 MC2PLC_INT[3]	23	0x0017
400005	3	0x0003	→ →	ETC01 MC2PLC_INT[4]	3	0x0003
400011			→ →	ETC01 ETC01_G2N0_INT[0]		
400012			→ →	ETC01 ETC01_G2N0_INT[1]		

To view the actual data mappings, click the **Edit Mapping** button. For more details, see the Data Mapping-Explanation section.

To view the data mappings purely as text, click the **View as Text** button. For more details, see the View Data Mapping as Text section.



Display String

Click the **Display String** button to view what the values of each Parsing and/or Concatenating strings are, you can also click on the Edit Mapping to view the mapping of each string.

	Main Page
CON	FIGURATION
	Network Configuration
	Port Configuration
	ASCII
	Allen-Bradley PLC
_	Display Data
L F	Display String
	Restart Now
DIAG	NOSTICS
	-Select-
отн	ER -Select-

To view the source or destination groups from a string, click the dropdown menu to generate the information regarding that device. The string data will be displayed in both Hex and ASCII (only the ASCII data is sent). The example below shows data that is coming from the source device. A group will be displayed for each Parsing/Concatenating String field that is configured.

Dis	play S	tring)												Edit Mapping View as Text
Sele	ct a Gro	oup	Src:	: Lir	1e 1	Ba	rcoo	le S	car	ner		~	and a String Barcode Scanner ~	(11 bytes)	
	0000:	68	65	60	6C	6F	20	77	6F	72	6C	64	hello world		

In the Group drop down, "Line1" is defined on the ASCII Device configuration page and "Barcode Scanner" is defined in the ASCII Parsing configuration.

Enable	ASCII E				
Port [Port 1 (DB9) 🗸		Device Label Line1		
LED Inactivity	0 0-60000 s	Opera	ation Mode Mark Data New	on New Mess	age 🗸

Field	Start Location	Length	Data Type	Internal Tag Nan	ne
1:	1	0	String 🗸	Barcode Scanner	



If there are values of "Data Not Valid "on this page, it indicates that the source has not been validated yet and no data is being sent to the destination.

Display String	Edit Mapping
	View as Text
Select a Group Src: Line 1 Barcode Scanner and a String Barcode Scanner (0 bytes)	
Data Not Valid	

NOTE: You can view the whole string data by clicking on **Diagnostics Info** drop down and navigating to ASCII Diagnostics page. You will also have to select the port you want to view in the dropdown below ASCII.

Diagnostics						
ASCII	View					
Port 1 (DB9) V	View					

To view the string mappings, click the **Edit Mapping** button. For more details see the **String Mapping-Explanation** section.

Display String	Edit Mapping
	view as Text
Select a Group Src: Line 1 Barcode Scanner and a String Barcode Scanner (11 bytes)	\$)
0000: 68 65 6C 6C 6F 20 77 6F 72 6C 64 hello world	

NOTE: Only String data types can be mapped to another String data type.

String Mapping Configuration								
Manual Configure # of Mappings to Configure: 1 0-250 Set Max # of Mappings </th								
Enable	Mapping 1							
Source Destination								
Group: Line 1 Barcode Scanner	• • • • • •	Group: ETC01 ETC01_G2N0_STRIN String: ETC01_G2N0_STRING						

To view the string mappings purely as text, click the **View as Text** button. For more details see the **View String Mapping** as Text section.



Display String use case

Sending a message of "RTA,Support,Rocks" from an ASCII device to the RTA unit. The ASCII Parsing Configuration would look like my example below. There are more detailed examples of what all the fields represent in the ASCII Parsing section.

	ASCII Device 1 (Line1)											
Max	Number of Fields	: 3	1-50	1-50 Min Number of Fields: 1 1-								
	Parsing Delimiter: , 44 0x2c 🗸											
	Update Fields											
Field	Start Location	Length	Dat	ta Type	Internal Tag Name							
1:	1	0	String	~	Header 1							
2:	1	0	String	~	Header 2							
3:	1	0	String	~	Header 3							

The message is broken up into 3 "Groups" or Parsing fields.

Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 1 ~	and a String Header 1 V (3 bytes)	
0000: 52 54 41	RTA	
Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 2	and a String Header 2 V (7 bytes)	
0000: 53 75 70 70 6F 72 74	Support	
Display String		Edit Mapping View as Text
Select a Group Src: Line1 Header 3	and a String Header 3 V (5 bytes)	
0000: 52 6F 63 6B 73	Rocks	

To view the Entire message, click on the Diagnostic drop down, select Diagnostics Info. Select ASCII, click view, select your Port. Whole data will be in the Last Message Sent Diagnostic box.

Diagnostica	Last Message Sent (17 bytes)	
Diagnostics	0000: 52 54 41 2C 53 75 70 70	6F 72 74 2C 52 6F 63 6B RTA,Support,Rock
ASCII View Port 1 (DB9) View	0010; 75	5



Data and String Mapping – Auto-Configure

The Auto-Configure function looks at both protocols and will map the data between the two protocols as best as it can so that all data is mapped. Inputs of like data types will map to outputs of the other protocols like data types first. If a matching data type cannot be found, then the largest available data type will be used. Only when there is no other option is data truncated and mapped into a smaller data type.

If the Auto-Configure function does not map the data as you want or you want to add/modify the mappings, you may do so by going into Manual Configure mode.

The following are examples of the Auto-Configure function.

1) This example shows a common valid setup.



- a. Both Source values were able to be mapped to a corresponding Destination value.
- 2) This example shows how Auto-Configure will make its best guess.

Source	Destination
8-bit Sint	8-bit Sint
16-bit Int	16-bit Int
32-bit Uint	32-bit Uint
32-bit Float	32-bit Uint

 a. The 32-bit Float from the Source location could not find a matching Destination data-type. After all other like data types were mapped, the only data type available was the 2nd 32-bit Uint data type. Auto-Configure was completed even though the data in the Float will be truncated.



Data Mapping – Explanation

Below are the different parts that can be modified to make up a data mapping.



- 1) Enable (red box above): Check to enable mapping. If not checked, this mapping is skipped.
- 2) Source Field (yellow box above):
 - a) Group Select the data group you set up in the protocol config to use for this mapping.
 - b) Start This is the starting point for this mapping.
 - c) End This is the final point to be included for this mapping.
- 3) Manipulation Area (green box above):
 - a) Enable the Data Manipulation. This can be enabled for any mapping.
 - b) Click Add Math Operation for each operation needed. Up to 3 are allowed unless you are using the Scale, Set Bit, or Invert Bit functions. If using Scale, Set Bit, or Invert Bit, then only 1 operation is allowed.
 - c) Select the Operation(s) to perform.
 - i) Math Operations are performed in the order they are selected.
 - ii) If more than one point is selected on the source, the Math Operations will be performed on every point.
 - d) Enter the value(s) for the operation.



Example of Add (similar for Subtract, Multiple, Divide, and MOD). This will add a value of 10 to the source field before it is written to the destination field.

	Enable	Manip	ulation
	Scale		*
Src 🛛	1	to [10
Dst	1	to	100

Example of Scale. This will scale the source values from 1-10 into 1-100 for the destination.

Enable Manipulation		
	Set Bit	~
Src	[Dst
0		5
(0-	-15)	(0-15)

Example of Set Bit (similar to Invert Bit). This will take the value of the Oth source bit and copy it into the value of the 5th destination bit.

- 4) Destination Field (blue box above):
 - a) Group Select the data group you set up in the protocol config to use for this mapping.
 - b) Start This is the starting point for where the data is being stored.
 - c) End The End point is derived from the length of the source and cannot be modified.
 - Real Time Automation, Inc.

1-800-249-1612



Data Mapping – Adding Diagnostic Information

Data Mapping offers 5 different types of information in addition to any scan lines specified for each protocol.

IMPORTANT NOTE: Only add Diagnostic Information **AFTER** both sides of the gateway have been configured. If changes to either protocol are made after diagnostic information has been added to the mapping table, it is necessary to verify all mappings. Remapping may be necessary.

1) Temporary Ram (Int64)

- a) This offers five levels of 64bit Integer space to assist in multiple stages of math operations. For example, you may wish to scale and then add 5. You can set up a single translation to scale with the destination as the temporary ram. Then another translation to add 5 with the source as the temporary ram.
- b) The gateway will automatically convert the Source to fit the Destination, so there is no need for Int 8, 16, 32 since the 64 may be used for any case.

☑ Enable	Mapping 1		
Source	Enable Manipulation	Destination	
Group: Temporary Ram0 (Int64) Start: Ram0 End: Ram0	Scale Src 1 to 10 Dst 1 to 100	Group: Temporary Ram0 (Int64) 🔹 Start: Ram1 🔹 End: Ram1	
I Enable	Mapping 2		
Source	Enable Manipulation	Destination	

In this example, Ram0 is scaled into Ram1. Ram1 is then increased by 5 and stored into Ram2. Ram0 and Ram2 could be considered a source or destination group.

2) Temporary Ram (Double)

a) This is like the Temporary Ram (Int 64), except manipulations will be conducted against the 64bit floating point to allow for large data.

3) Ticks Per Second

a) The gateway operates at 200 ticks per second. This equates to one tick every 5ms. Thus, mapping this to a destination will give easy confirmation of data flow without involving one of the two protocols. If data stops on the destination end, then the RTA is offline.

Enable Mapping 1		
Source	Enable Manipulation	Destination
Group: Ticks Since Powerup (Uint32) Start: Since Powerup End: Since Powerup	• • -> • •	Group: BS01 Al1 (Float) Start: Al1 Contemporation Al1



4) Heartbeat 100ms Update

a) The Heartbeat 100ms Update variable can be used as a heartbeat that updates once every 100ms. The variable starts at 0 on gateway startup and increments by 1 every 100ms. This can be mapped into a destination on one of the available protocols to monitor the gateways connection status. If the value stops updating every 100ms the gateway is offline.

Enable Mapping 1		
Source	Enable Manipulation	Destination
Group: Heartbeat 100ms Update (Uir ~) Start: 100ms Update ~) End: 100ms Update ~)	• • • • •	Group: ETC01 Heartbeat (Int32) v Start: Heartbeat v End: Heartbeat

5) Heartbeat 1000ms Update

a) The Heartbeat 1000ms Update variable can be used as a heartbeat that updates once every 1000ms. The variable starts at 0 on gateway startup and increments by 1 every 1000ms. This can be mapped into a destination on one of the available protocols to monitor the gateways connection status. If the value stops updating every 1000ms the gateway is offline.

Enable Mapping 1			
Source		Enable Manipulation	Destination
Group: Heartbeat 1000ms Update (Ui 🗸			Group: ETC01 Heartbeat (Int32)
Start: 1000ms Update V	0	$\circ \longrightarrow \circ \circ$	Start: Heartbeat
End: 1000ms Update V			End: Heartbeat

6) XY_NetBmpStat

a) If a protocol is a Client/Master, there is a Network Bitmap Status that is provided on the Diagnostics Info page under the Variables section.

Modbus RTU Master	
Device Status Connected and Running	
LED Status Connection Status:	Connected
Variables	
Network Bitmap Status:	0x0000001f

- b) Since a Client/Master may be trying to communicate with multiple devices on the network, it may be beneficial to know if a Server/Slave device is down. By using this Network Bitmap Status, you can expose the connection statuses of individual devices. **Values shown are in HEX.**
 - i) 0x0000002 shows that only device 2 is connected
 - ii) 0x00000003 shows that only devices 1 and 2 are connected
 - iii) 0x0000001f shows that all 5 devices are connected (shown in image above)



c) There are multiple ways to map the NetBmpStat.

Option 1: Map the whole 32bit value to a destination. Example below shows the NetBmpStat is going to an Analog BACnet object. Using a connection of 5 Modbus Slave devices Al1 will show a value of 31.0000. Open a calculator with programmer mode and type in 31, this will represent bits 0 - 4 are on. This mean all 5 devices are connected and running.

If using an AB PLC with a Tag defined as a Dint, then expand the tag within your RSlogix software to expose the bit level and define each bit as a description such as device1, device2, etc.

Enable Mapping 1			
Source		Enable Manipulation	Destination
Group: MM NetBmpStat (Uint32) Start: NetBmpStat Contemp Stat Contemp	•	• • • •	Group: BS01 Al1 (Float) Start: Al1 Contemporation Al1

Option 2: You can extract individual bits from the NetBmpStat by using the Set Bit Manipulation and map those to a destination. You'll need a mapping for each device you want to monitor. Example below shows Modbus device 2 (out of 5) is being monitor to a BACnet Binary Object. You can define the object in the BACnet Name configuration.

Enable Mapping 1			
Source	Enable Manipulation	Destination	
Group: MM NetBmpStat (Uint32) Start: NetBmpStat End: NetBmpStat	Set Bit V Src Dst 1 0 (0-31) (0)	Group: BS01 BI1 (Bit1) Start: BI1 End: BI1	



7) Status_XY

a) There are two Statuses provided, one for each protocol. This gives access to the overall status of that Protocol. Each Bit has its own meaning as follows:

Commo	n Status:	0x000000FF	(bit 0-7)1 st byte
Hex:	Bit Position:	Decimal:	Explanation:
0x00	0	0	if we are a Slave/Server
0x01	0	1	if we are a Master/Client
0x02	1	2	connected (0 not connected)
0x04	2	4	first time scan
0x08	3	8	<pre>idle (usually added to connected) running (usually added to connected) bit not used recoverable fault nonrecoverable fault</pre>
0x10	4	16	
0x20	5	32	
0x40	6	64	
0x80	7	128	

For this example, the ETC Status is mapped to a PLC tag called PLC_Status

PLC to Modbus TCP/IP							Modbus	s TCP/IP to	PLC	
			PLC		4	460ETCMC €€		Mode	ous TCP/I	P
Na	me		Valu	e (Hex)		Manipulation	Name		Value	(Hex)
PLC_	Status		19	0x000	00013	**	ETC Status	19		0x00000013
Exam	ple: ET	C Sta	atus is Ox	000000	13 (19 de	cimal), here	e is the	break do	wn	
	Hex		Bit	Decima	al	Expla	nation			
	0x01	L	0(on)	1	i:	f we are	a Mas	ter/Cli	ent	
	0x02	2	1(on)	2	C	onnected	(0 no	t conne	ected)	
	<u>0x10</u>)	4(on)	16	rı	unning (u	suall	y addec	d to co	onnected)
	Tota	l:	0x13	19						
Exte	ernal	Fai	ults:		0.	x0000FF0	0 (bi	t 8-15	5)2 nd 1	oyte
Hex:	<u>Bit</u>	Pos	sition:	Dec	imal:	Expla	natio	n:		
0x00		8		0		loca	l con	trol		
0x01		8		2	56	remo	tely	idle		
0x02		9		5	12	remo	tely	faulted	ł	
0x04		10		1	,024	idle faul	e due '	to depe	endency	Y
0200		ΤŢ		Ζ.	,040	Laul	leu u	ue to t	repende	эпсу
Recoverable Faults: 0x00FF0000 (bit 16-23)3 rd byte										
Hex:	<u>Bit</u>	Pos	sition:	Dec	imal:	Expla	natio	n:		
0x01		-	L6	6	5,536	reco	verab	le faul	.t - t:	imed out
0x02		-	L7	1	31,072	reco	verab	le faul	.t - Si	lave err

Real Time Automation, Inc.

1-800-249-1612



Non-Recoverable Faults 0xFF000000 (bit 24-31)4th byte

Hex:	Bit Position:	Decimal:	Explanation:
0x01	24	16,777,216	nonrecoverable fault - task fatal err
0x02	25	33,554,432	nonrecoverable fault - config missing
0x04	26	67,108,864	nonrecoverable fault - bad hardware port
0x08	27	134,217,728	nonrecoverable fault - config err
0x10 0x20	28 29	268,435,456 536,870,912	Configuration Mode No Ethernet Cable Plugged In

For this example, the MC Status is mapped to a PLC tag called MC_Status

	PLC to Modbus TC	P/IP			Modbus TCP/IF	P to PLC
PLC			460ETCMC Modbus TCP/IP			P/IP
Name	Value (Hex)		Manipulation	Name	Val	ue (Hex)
MC_Status	65601	0x00010041	44	MC Status	65601	0x00010041

Example: MC Status is 0x00010041 (65601 decimal), here is the break down, we know that bytes 1 and 3 are being used, so here is the break down,

Commo	n Status	:	
Hex:	<u>Bit:</u>	Decimal:	Explanation:
0x01	0(on)	1	if we are a Master/Client
0x40	6(on)	64	recoverable fault
Recov <u>Hex:</u> 0x01	erable F <u>Bit:</u> 16	aults: Decimal: 65,536	<u>Explanation:</u> recoverable fault – timed
0x0100	41	65,601	

Total:



String Mapping – Explanation

Below are the different parts that can be modified to make up a string mapping.

String data types can only be mapped to other string data types. There is no manipulation that can be done on the string.

Enable	Mapping 1	3.	
Source		Destination	
Group: Line 1 Barcode Scanner	• • 🔶 • •	Group: ETC01 ETC01_G2N0_STRIN String: ETC01_G2N0_STRING	

- 1) Enable (red box above): Check to enable mapping. If not checked, this mapping is skipped.
- 2) Source Field (yellow box above):
 - a) Group Select the string data group you set up in the protocol config to use for this mapping.
 - b) String This is the string used for this mapping.
- 3) Destination Field (green box above):
 - a) Group Select the string data group you set up in the protocol config to use for this mapping.
 - b) String This is the string where the data is being stored.



Mapping - Auto-Configure Mode to Manual Configure Mode

To transition from Auto-Configure Mapping Mode to Manual Configure Mode, click the dropdown at the top of the Mapping Configuration page and select Manual Configure.

After you click this button, you will be prompted to confirm if this is really what you want to do.



Click **OK** to proceed to Manual Configure Mode or click **Cancel** to remain in Auto-Configure Mappings Mode.

Once OK is clicked, there are 2 options on how to proceed from here.

Message from webpage	x
Press OK to keep the current Mappings Press Cancel to Delete all Mappings.	
OK Canc	el

- 1) To keep the mappings that are already configured press **OK**.
 - a) You would want this option if you are adding additional mappings or you want to modify the mapping(s) that already exist.
- 2) To delete the mappings that are already there and start over press **Cancel**.

To modify the number of mappings, enter a number in the text field next to **# of Mappings to Configure** and click the **Set Max # of Mappings** button. You can always add more mappings if needed.


Mapping - Manual Configure Mode to Auto-Configure Mode

To transition from Manual Configure Mode to Auto-Configure Mapping Mode, click the dropdown menu at the top of the Mapping Configuration page and select Auto-Configure Mappings.

Message fi	rom webpage
?	Press OK to delete the current Mappings and go back to Auto-Configure Mappings mode. Press Cancel to keep Mappings and remain in current Mode.
	OK Cancel

Click **OK** to proceed to delete all current mappings and go back to Auto-Configure Mappings Mode. Click **Cancel** to keep all mappings and remain in Manual Configure Mode.

NOTE: Once you revert to Auto-Configure Mapping Mode there is no way to recover the mappings you lost. Any mappings you previously have added will be deleted as well.



View as Text

Data Mapping

The View as Text page displays the point to point mapping(s) you set up in the Data Mapping section. This will also display any manipulation(s) that are configured.

Each line on this page will read as follows:

Mapping *number*: *source point* **Len**: *Number of points mapped* -> *manipulation* (*if blank then no manipulation*) -> *destination point*

If you are looking for a specific point to see if it is mapped, you can do a find in this text box for your point in question. Example: you defined 20 Registers starting at register 1 and want to see if 400011 is mapped. If it is not in this text box, then it is not mapped, and no data will be transferred.

This is the text display for the example shown under the *Data Mapping- Adding Diagnostic Information* section.

				Da	ita I	Mapping					
Mapping 1: Mapping 2:	Temporary Temporary	Ram0 Ram1	Len: Len:	1 1	-> ->	1:10 Scale Add 5 ->	to	1:100 -> Temporary Ram2	Temporary	Ram1	

String Mapping

The View as Text page displays the string mapping(s) you set up in the String Mapping section.

Each line on this page will read as follows:

Mapping number: source point -> Copy -> destination point

If you are looking for a specific point to see if it is mapped, you can do a find in this text box for your point in question. Example: you defined 20 String Tags in the PLC and want to see if "Test_String" in the Logix PLC is mapped. If it is not in this text box, then it is not mapped, and no data will be transferred.

		String Mapping		
Mapping 1:	Logix Test_String	-> Copy ->	MCO2 400001	

Real Time Automation, Inc.



Base Triggering – Data Validiation Triggering

With Base Triggering, you will be marking data as "Invalid" and force RTA Master/Controller/Client protocols to read all the read data points sources until ALL source protocols data is valid. You will be able to utilize the Handshake to map over to Technology Trigger and/or back over to your source protocol for reference.

How does this work?

- 1) Map the Triggering Variable (Source) over to Trigger # (Dest).
- 2) If Trigger # value changes states mark all Trigger # protocols read data as "Invalid".
- 3) Read all source read data points until ALL source read data is valid.
- 4) Handshake # value is set equal to Trigger # value.
- 5) Map Handshake # to reference data point. Note: # is an internal reference to the Server/Slave number you are settings up. ex. RTA Server/Slave products can only be Trigger 1 and Handshake 1 since we are only 1 device. If RTA is a Master/Client, then you can have a Trigger# for each server/slave connected too.

How do you set this up?

In this example I'm using a 460MCBS. My Building Automation System wants to verify that all data read from Modbus TCP/IP Server is valid.

1) Add an extra Analog Output for your Trigger. This tells the RTA to mark all data invalid.

Nrite Data	Groups (BACn	et/IP to 460MCBS)		
	Data Group	Object Type	Starting Object	# of Objects
	1	Analog Output (32 Bit Float)	1	21
	2	Binary Output	1	0
	3	CharacterString Value	51	0

a) You can define AI21 as your validation name in the Setup BACnet Names Configuration.

		Setup BACn	et Names, Units, and	1 COV		
21	G01 🗸	Data Validation Trigger	Other 🗸	no-units	~	1.000000

2) Add another Analog Input as reference for when data has been validated. When you write from AO21 to validate data, the RTA will reply to AI40 saying "validation complete".

Data Group	Object Type	Starting Object	# of Objects
1	Analog Input (32 Bit Float)	1	40
2	Binary Input	1	0
3	CharacterString Value	1	0



40	G01 🗸	Data Validation Result	Other 🗸	no-units	✔ 1.000000

- 3) Within the Data Mapping page manually add 2 additional mappings.
- 4) The first mapping is going to be the Data Validation Triggering. AO21 will write to the RTA, MC Trigger 1 will mark data invalid.

Enable			Mapping	g 2		
Source			Enable Manipulat	tion	Destination	
Group: BS01 AO1 (Float)	~				Group: MC Trigger 0 (Uint16)	~
Start: A021	~	0	• <> •	•	Start: Trigger 1	~
End: AO21	~				End: Trigger 1	

5) The second mapping, the MC Handshake will increment that all data is validated and write to Al21 "all data is validated". The value of Al40 and AO21 should be the same.

C Enable				Мар	ping	j 3			
Source			Enab	ole Mani	pulat	ion		Destination	
Group: MC Handshake 0 (Uint16) 🗸							Group:	BS01 AI1 (Float)	~
Start: Handshake 1	~	0	0	\Rightarrow	0	•	Start:	AI40	~
End: Handshake 1	~			\sim			End:	AI40	



Security Configuration

To setup security on the 460 gateway, navigate to **Other->Security Configuration**. You can configure Security for 3 administrators, 5 users, and 1 guest.

THIS IS NOT A TOTAL SECURITY FEATURE

The security feature offers a way to password protect access to diagnostics and configuration on the network. The security feature does not protect against "Air Gap" threats. If the gateway can be physically accessed, security can be reset. All security can be disabled if physical contact can be made. From the login page, click the Reset Password button twice. You will be forced to do a hard reboot (power down) on the gateway within 15 minutes of clicking the button. This process should be used in the event a password is forgotten.

Note: Only Admins have configuration access to all web pages.

- Log Out Timer: The system will automatically log inactive users off after this period of time.
 NOTE: A time of 0 means that the user will not be automatically logged off. Instead, they must manually click the Logout button.
- 2) Username: Enter a username, max of 32 characters.
- 3) Password: Enter a password for the username, max of 32 characters, case sensitive.
 - a. Re-enter the Password
- 4) E-mail: In case the password was forgotten, a user can have their password e-mailed to them if e-mail was configured.
- 5) Hint: A helpful reminder of what the password is.

	nfiguration				
Admin	Username	Password	Re-enter Password	Email	Hint
1 [Not Configured	
2				Not Configured	
3				Not Configured	
ser Con	figuration	Admi	in Contact Information	on	
ser Con	figuration Username	Admi	in Contact Information Re-enter Password	Email	Hint
ser Con User	figuration Username	Adm	in Contact Information Re-enter Password	Email Not Configured	Hint
User	figuration Username	Adm Password	Re-enter Password	Email Not Configured Not Configured	Hint
Ser Con User 1 [2 [3 [liguration Username	Adm	Re-enter Password	Email Not Configured Not Configured Not Configured	Hint
ser Con User 1 [2 [3 [4 [figuration	Adm Password	Re-enter Password	Description Email Not Configured Not Configured Not Configured Not Configured	Hint

Real Time Automation, Inc.



Security Configuration-Security Levels

Each webpage in the gateway can have a separate security level associated with it for each user.

Security Levels:

- 1) **Full Access**: Capability to view and configure a web page.
- 2) View Access: Capability to view a web page, but cannot configure parameters.
- 3) **No Access**: No capability of viewing the web page and page will be removed from Navigation.

Web Page	Security
All Web Pages	No Access 🖌 Set
Wah Dawa	Co avusitar
Web Page	Security
	Full Access V
Device Configuration	Full Access
Port Configuration	Full Access ¥
BACnet/IP Server	Full Access 💙
Modbus RTU Master	Full Access 💙
View Mapping	Full Access 💙
Mapping	Full Access 💙
Setup LED's	Full Access 🗸
Diagnostic Info	Full Access 💌
Logging	Full Access 💙
Display Data	Full Access 💙
Export Configuration	Full Access 🛩
Import Configuration	Full Access 👻
Save As Template	Full Access 🛩
Load From Template	Full Access 🛩
Utilities	Full Access 🛩
Email Configuration	Full Access 💙
Alarm Configuration	Full Access 🗸
String Mapping	Full Access 🗸
View String Mapping	Full Access 🛩
Display String	Full Access 🗸



Security - Log In

Username: Name of the user to login.

Password: Password of the user to login.

Log In: If login is successful, the user will be redirected to the Main Page.

Send Password to Email: Sends the specified User's Password to the email configured for that user.

Display Hint: Displays the hint specified for the User if one was set up.

Reset Password: This is used to reset security settings. Confirm reset password must be selected to confirm this action. Once confirmed, there is a 15 minute window to do a hard reset of the gateway by physically removing and restoring power from the gateway. Once power is restored, you may navigate to the IP address of the gateway as normal.

Applic	ation Description
Username:	Admin
Password:	
Display Hint	Log In Reset Password

Security - Log Out

Once a user is done with a session they may click **logout** at the top of any page. The user may also be logged out for inactivity based off of the Log Out Timer specified during the configuration.



Closing the browser is not sufficient to log out.



Email Configuration

To setup e-mails on the 460 gateway, navigate to **Other->Email Configuration**.

You can configure up to 10 email addresses.

- 1) SMTP Mail Username: The email address that the SMTP server has set up to use.
- 2) SMTP Mail Password: If authentication is required, enter the SMTP Server's password (Optional).
- 3) SMTP Server: Enter the Name of the SMTP Server or the IP Address of the Server.
- 4) From E-mail: Enter the e-mail that will show up as the sender.
- 5) To E-mail: Enter the e-mail that is to receive the e-mail.
- 6) E-mail Group: Choose a group for the user. This is used in other web pages.

Click the **Save Parameters** button to commit the changes and reboot the gateway.

Email Configuration Help								
Number of Emails to Configure: 1 0-10 Setup Email(s)								
User	SMTP Mail Username	SMTP Mail Password	SMTP Server	From Email	To Email	Email Group		
1						Group A 👻		
			Save Paramet	ers				
			Send Test Ema	iil(s)				



Alarm Configuration

To setup alarms on the 460 gateway, navigate to **Other->Alarm Configuration**.

1) Alarm Delay upon Powerup: At Powerup, the gateway will have values of '0' stored for all data. This may cause alarms to trigger before these values are updated by the mating protocols. Set this field to provide needed time to update fields before considering values for alarms.

Alarm Delay upon Powerup: 0 0-3600 s
of Alarms to Configure: 1 0-100 Set Max # Alarms
Enable Alarm 1
Data Point Set Error Clear Error Alarm Name Email
Ticks Since Powerup (Uint32) >= None Gateway_test Group A Ticks Since Powerup 1000 0 Gateway_test Group A

- 2) Enter the number of alarms to configure and click **Set Max # Alarms** to generate those lines.
- 3) In the Data Point Section:
 - a. Top dropdown: select the Data Group. This dropdown menu will contain all groups that go from the gateway to the network.
 - b. Lower dropdown: select the Data Point's Specific Point. This is used to select which point in the group will be monitored for alarms.
- 4) In the Set Error Section:
 - a. Select the Set Error Operation in the top dropdown menu. Available options are <, >, <=, >=,
 !=, ==, and Change of State (COS). This is the operation that will be used to compare the
 Data Point value against the Error Value to determine if the alarm needs to be set.
 - Select the Set Error Value. This value is used as: 'Data Point's Value' 'Operation' 'Value.' Ex: Ticks Since Powerup >= 1000. This will set the alarm after 1000 ticks have elapsed since the unit powered up.



- 5) In the Clear Error Section:
 - a. Select the Clear Error Operation. Available options are <, >, <=, >=, !=, ==, and Change of State (COS). This is the operation that will be used to compare the Data Point value against the Error Value to determine if the alarm needs to be cleared.
 - b. Select the Clear Error Value.
 -Ex: Ticks Since Powerup >= 5000. This will clear the alarm after 5000 ticks have elapsed since the unit powered up.
- 6) Enter an Alarm Name. This will make the alarm unique and will be available in the Alarm Status page as well as in the email generated by the alarm.
- 7) Select an email to associate this alarm with. When an alarm is set, it sends an email. When an alarm is cleared, it will also send an email.

Click the **Save Parameters** button to commit the changes to memory and reboot the gateway.



Diagnostics – Alarm Status

Alarm Status will only display under the Diagnostic menu tab if at least 1 Alarm is enabled.

- 1) # Alarms Enabled: This is a count of enabled alarms.
- 2) # Alarms Active: This is how many alarms are presently active (set).
- 3) Last Active Alarm: This is the last alarm that the gateway detected.
- 4) Clear # of Times Active: This will reset all alarms '# of Times Active' to 0.
- 5) Alarm #: The reference number to the given alarm on the alarm setup page.
- 6) Name: The name of the alarm.
- 7) Status: The current status of the alarm, either OK or ALARM.
- 8) # of Times Active: This count represents the number of times this alarm has become active. If an alarm is triggered, this count will increment.

Alarm Statu	IS			
# Alarms Er	abled:	1		
# Alarms Ac	tive:	0		
Last Active Alarm:				
			Clea	ar # of Times Active
	Alarm#	Name	Status	# of Times Active
	1	Alarm Example	ОК	0

Alarms - Active

While one or more alarms are active, every page will display 'Alarms Active' at the top of the page. This will no longer be displayed if all active alarms have been cleared.



When an alarm is activated, the following will occur:

- 1) A one-time notification will be sent out to the email associated with the alarm.
- 2) For duplicate emails to occur, the alarm must be cleared and then become active again.
- 3) # Alarms Active and # of Times Active will be incremented.
- 4) Status of the Individual Alarm will be set to *Alarm*.
- 5) *Last Active Alarm* field will be populated with details on what triggered the alarm. Real Time Automation, Inc. 83 1-800-249-1612



d:	1		
	1		
n:	Alarm 1 is Set: Actual: () < Limit: 20	
		Cle	ear # of Times Active
Alarm#	Name	Status	# of Times Active
1	Alarm Example	Alarm	1
	d: n: Alarm# 1	d: 1 1 n: Alarm 1 is Set: Actual: (Alarm# Name 1 Alarm Example	d: 1 1 n: Alarm 1 is Set: Actual: 0 < Limit: 20 Ca Alarm# Name Status 1 Alarm Example Alarm

Alarms – Clear

When an alarm is cleared, the following will occur:

- 1) A one-time notification will be sent to the email associated with the alarm.
 - a. For duplicate emails to occur, the alarm must become active and then be cleared again.
- 2) Total # Alarms Active will decrement. Last Active Alarm will not be changed.
- 3) Status of the Individual Alarm will be reset to OK.



Change of State (COS) Configuration

To access the configuration files in the 460 gateway, navigate to dropdown **Other->COS Configuration**. The gateway, by default only writes when data has changed. The gateway also waits to write any data to the destination until the source protocol is successfully connected.

Default values should fit most applications. Change these values with caution as they affect performance.

1	1) Stale Data Timer: If the data has not changed within the time allocated in this Stale Data Timer,
	the data will be marked as stale within the gateway and will force a write request to occur. This
	timer is to be used to force cyclic updates in the gateway, since data will only be written if it has
	changed by default. There is a separate timer per data mapping.
	Gateway behavior:
	 If time = 0s => (DEFAULT) The gateway will write out new values on a Change of State basis.
	 If time > 0s => The gateway will write out new values whenever the timer expires to force cyclic updates (write every x seconds).
2	2) Production Inhibit Timer: Amount of time after a Change of State write request has occurred
	before allowing a new Change of State to be written. This is to be used to prevent jitter. Default
	value is 0ms. This timer takes priority over the Stale Data Timer. There is a separate timer per
	data mapping. This timer is active only after the first write goes out and the first COS event
	occurs.
3	3) Writes Before Reads: If multiple writes are queued, execute # of Writes Before Reads before th
	next read occurs. Default is 10 and should fit most applications.
	Warning: A value of 0 here may starve reads if a lot of writes are queued. This may be useful in
	applications where a burst of writes may occur and you want to guarantee they all go out befor
	the next set of reads begin.
2	4) Reads Before Writes: If multiple writes are queued, the # of Writes Before Reads will occur
	before starting the # of Reads Before Writes. Once the # of Reads Before Writes has occurred,
	the counter for both reads and write will be reset. Default is 1 and should fit most applications.
5	b) Enable Data Integrity: If enabled, do not execute any write requests to the destination until the
,	source data point is connected and communicating. This prevents writes of 0 upon power up.
t	data element within the scan line or data group to be new
ſ	Change of State Configuration
	Stale Data Timer: 0 0-3600 s
	Production Inhibit Timer: 0 0-60000 ms
	Writes Before Reads: 10 0-255
	Reads Before Writes: 1 1-255
	Enable Data Integrity: 🔽
	Enable Mark Whole Entry New:
	Save Parameters

Click the **Save Parameters** button to commit the changes to memory and reboot the gateway.



Diagnostics Info

The Diagnostics page is where you can view both protocols' diagnostics information, # of Data Mappings, # of String Mapping and # Alarm Mappings.

DIAG	GNOSTICS	
	-Select-	~
	-Select-	
OTH	Diagnostic Info	
	Logging	

For protocol specific diagnostic information, refer to the next few pages.

Diagnostics Mapping

This section displays the number of mappings that are enabled, Data Mapping and String Mapping will show the # of Errors and First Errors. Alarms will show # active and Last Alarm that was active.

Common Errors:

- Destination or Source Point does not exist

 a) Solution: Re-map the mapping
- 2) Source or Destination Pointer too small
 - a) There is not enough space on either the Source, or the Destination for the data you want to copy. This is typically seen when the Destination is smaller than the amount of data being transferred to it.
- 3) Range Discard, Min or Max Value
 - a) The actual data value is outside of the defined range
- 4) Math Error
 - a) Operation value cannot be 0
- 5) Scaling Error
 - a) Source Min must be smaller than Source Max
 - b) Destination Min must be smaller than Destination Max

Data Mapping # Enabled: # of Errors: First Error:	5 of 5 0
String Mapping # Enabled: # of Errors: First Error:	2 of 2 0
Alarms # Enabled: # Active: Last Active:	3 0

Note: you can also view this information on the Main Page.



Diagnostics – PROFINET IO Server

Select the **PROFINET IO Server** in the dropdown menu on the Diagnostics Page to view a breakdown of the diagnostics and common strings that are displayed on the page. Additional diagnostic information can be found by clicking the **Help** button.

Diagnostics					
Profinet IO Server View View	Clear All Values				
Device Status Configuration Mode Gateway Restart Needed	Help				

NOTE: This page will auto-refresh every five seconds with the latest data.

Clear All Values - This will only affect displayed values.

- 1) This will reset all displayed values back to zero.
- 2) If viewing PROFINET IO Server, this will only clear the values for the PROFINET IO Server section of the gateway.

Device Status:



- 1) Connected A PROFINET IO controller has a connection for the gateway.
- 2) Not Connected:
 - a) The PROFINET IO controller has not initiated communication to the gateway.
 - b) The PROFINET IO server has an invalid configuration or no parameters configured.

LED Status:

LED Status Connection Status: Configuration Mode

- 1) Solid Green (Connected and Running) Connected to a PROFINET IO controller and online.
- 2) Flashing Green (Connection not yet attempted) Valid Configuration but no communication from the IO controller yet.
- 3) Solid Red (Fatal Error)
 - a) Invalid Configuration due to no input/output slots configured within the gateway
- 4) Flashing Red (Connection Timeout)
 - a) PROFINET IO controller's slot configuration doesn't match the gateway's slot configuration
 - b) PROFINET IO controller was communicating to the gateway and is no longer communicating
- 5) Off (No Ethernet Cable Plugged In)



Variables:

Variables	
Application Ready Rcvd:	0
Release AR:	0
Parameters Written:	0
PN Ethernet Pkts Rcvd:	0
PN Ethernet Pkts Sent:	0
Connection Timeouts:	0
Speed Limit Increment:	0

- 1) Application Ready Rcvd:
 - a) The Application Ready Command has been received
 - b) The gateway has completed the PROFINET setup sequence and will start cyclic communication
- 2) Release AR:
 - a) A Release Application Relationship command has been received
 - b) PROFINET communication have been disconnected from the gateway
- 3) Parameters Written:
 - a) Rollover counter for the number of parameters written by the IO controller.
- 4) PN Ethernet Pkts Received:
 - a) Number of Layer 2 (Ethernet) Messages received
- 5) PN Ethernet Pkts Sent:
 - a) Number of Layer 2 (Ethernet) Messages transmitted
- 6) Connection Timeouts:
 - a) Number of Connection timeouts between the gateway and the IO controller
 - b) If this counter is incrementing, check your ethernet connection
 - c) If this counter is incrementing, verify the gateway is in the IO controller
- 7) Speed Limit Increments:
 - a) The gateway has received too much traffic to process all the data
 - b) The gateway will stop processing PROFINET data for a short time



Diagnostics – ASCII

Select ASCII in the top dropdown menu on the Diagnostics Page to view a breakdown of the diagnostics that are displayed on the page. You may also view individual ASCII device counters and messages by selecting the device in the *All ASCII* dropdown and clicking **View**. Additional diagnostic information can be found by clicking the **Help** button.

Diagnostics	
ASCII View All ASCII View	Clear All Values
Device Status Connected and Running	Help Clear Buffers

NOTE: This page will auto-refresh every five seconds with the latest data.

Clear All Values - This will only affect displayed values.

This will reset all displayed values back to zero and clear the Status Strings.
 Example: If viewing ASCII – Port #, this will only clear the values for Port #. This will reduce the *All ASCII* values indirectly.

Variables	
Network Bitmap Status:	0x00000000
Successful Transmit Count:	0
Successful Receive Count:	0
Received due to Length:	0
Received due to Delimiters:	0
Received due to Timeout:	0
Received but Discarded:	0
Successful Parsed Messages:	0
Failed Parsed Messages:	0
Status Strings	
Queued Messages:	0 of 5
Last Parsed Error:	
USB Port 0 Status:	

Clear Buffers - This will clear the Next Message to Send from Queue buffer and Current Message being received from ASCII buffer and any message stored in the Queue.

```
        Next Message to Send from Queue (17 bytes)

        0000:
        52 54 41 2C 53 75 70 70 6F 72 74 2C 52 6F 63 6B
        RTA,Support,Rock

        0016:
        73
        s
```



```
Current Message being Received from ASCII (17 bytes)

0000: 52 54 41 2C 53 75 70 70 6F 72 74 2C 52 6F 63 6B RTA,Support,Rock

0016: 73 s
```

Device Status - This will only display when viewing *All ASCII*.

- 1) Connected and Running– The gateway is connected to all the ASCII devices and data is being received/transmitted.
- 2) Not Connected There have been no messages received or transmitted.
 - a. Verify that the serial /TCP/IP/USB settings match your device.
- 3) Fatal Error: Hardware Port Not Configured The port selected on the ASCII Configuration page is not configured.
 - a. Verify the ASCII device is enabled and configured.
 - b. Verify the port configured matches the port enabled.

C Enable			ASCII E	Device 1		
		Port [-Select- 🗸		Device Label Line1	
	LED Ina	activity () 0-	60000 s	Operation Mode Mark Data New	on New Message 🛛 🖌

LED Status - This is the Status for All ASCII or the specific ASCII device selected.

- 1) Solid Green (Connected) The gateway is receiving/transmitting data within the inactivity period for all the ASCII devices that are configured and enabled.
- 2) Flashing Green (Not Connected/First Time Scan) Start up state. No messages have been received or transmitted, but port is connected.
- 3) Flashing Red (Connection Timeout) The only way to exit this state is with a valid received message.
 - a. Data has been discarded due to the queue being full.
 - b. Data has not been received/transmitted within the inactivity period.
 - c. Port not opened.
 - d. Message parsing has failed.

Diagnostics			
ASCII View All ASCII View			Clear All Values
Device Status		(Help
Connected and Running		(Clear Buffers
LED Status			
Connection Status:	Connected		



Variables - These are the values for All ASCII, or the ASCII device selected.

- 1) Network Bitmap Status (Displayed in Hex):
 - a) Each bit corresponds to an ASCII device.
 - b) For Serial ASCII, if the bit is set, then that means the gateway has transmitted or received data within the Timeout configured, otherwise the bit is 0.
 - c) For USB ASCII, if the bit is set, then that means the gateway has a USB device physically connected, otherwise the bit is 0.
 - d) For Ethernet TCP ASCII, if the bit is set, then that means the gateway has a TCP connection, otherwise the bit is 0.
 - e) For Ethernet UDP ASCII, if the bit is set, then that means the gateway has transmitted or received data within the Timeout configured, otherwise the bit is 0.
 - f) Bit 0 corresponds to ASCII device 1 and Bit 4 is for ASCII device 5 and so on.
- 2) Successful Transmit Count:
 - a) Number of messages that the gateway has transmitted to the ASCII device
- 3) Successful Receive Count:
 - a) Number of complete messages that the gateway has received from the ASCII device
- 4) Received due to Length:
 - a) Number of messages completed due to the Max Message Length being reached
- 5) Received due to Delimiters:
 - a) Number of messages completed due to the Start or End Delimiters being seen
- 6) Received due to Timeout:
 - a) Number of messages completed due to the Receive Character Timeout being reached
- 7) Received but Discarded:
 - a) Number of messages that are complete but discarded due to the queue being full
 - b) Change the Gateway Hold Msg Timeout to be less than what you currently have set
- 8) Successful Parsed Messages:
 - a) Number of messages that are complete and have been successfully parsed
- 9) Failed Parsed Messages:
 - a) Number of messages that are complete but have not been parsed successfully

Variables	
Network Bitmap Status:	0x00000000
Successful Transmit Count:	0
Successful Receive Count:	0
Received due to Length:	0
Received due to Delimiters:	0
Received due to Timeout:	0
Received but Discarded:	0
Successful Parsed Messages:	0
Failed Parsed Messages:	0
Status Strings	
Queued Messages:	0 of 5
Last Parsed Error:	
USB Port 0 Status:	



Status Strings - These are the values for All ASCII, or the ASCII device selected.

- 1) Queued Messages:
 - a) The gateway will hold up to 20 (configurable) complete messages to send to the other protocol
 - b) This will only increment if the Gateway Hold Msg Timeout is non-zero and messages are being received faster than we can send to the other protocol
- 2) Last Parsed Error:
 - a) Last parsed error the gateway encountered

Common Error Messages:

- 1) **Number of Fields Invalid:** The total number of parsed fields is greater than the number of fields the gateway was expecting
- 2) Discard: The Field has been discarded
- 3) Invalid Length for Field: Number of characters parsed is greater than the number of characters that the gateway is expecting
- 4) Calculated Length of Data exceeds 255 Characters: Number of characters parsed within a field exceeds 255 characters

USB Port 0/1 Status:

- Status of the two USB ports.
- Our gateway supports Class 3 (HID Devices) and Class 7 (Printers) only.

Common Messages:

- 1) Not Connected, No USB device detected
- 2) HID Device Connected
- 3) Unsupported HID Device
- 4) Error-Missing Device Info
- 5) Unknown HID Error
- 6) Unsupported USB Class XX
- 7) (Printer Devices Only) Printer: Error Check Printer, Not Selected, Paper Available/Paper Empty
- 8) (Printer Devices Only) Printer: No Error, Selected, Paper Available

NOTE: Some USB printers may not always be able to determine this information. In this case, they should return benign status of "Paper Not Empty", "Selected" and "No Error".

Buffers

0000:	54	68	69	73	20	69	73	20	61	20	74	65	73	74	20	6D	This is a test m	
0016:	65	73	73	61	67	65	20	77	69	74	68	20	76	61	72	69	essage with vari	
0032:	6F	75	73	20	63	68	61	72	61	63	74	65	72	73	40	23	ous characters@#	
0048:	24	25	5E	26	2A	28	29	7B	7D	3B	27	2C	2E	3C	3E	2F	\$%^&*() {};',.<>/	
0064:	3F	AC	00	OA	OD	21	21										?!!	

Each buffer text area is divided into three separate parts. Refer to screenshot above for labels.

- 1) Starting byte for that line
- 2) HEX character representation

Real Time Automation, Inc.



3) ASCII character representation (Unprintable ASCII characters (like <CR>) will be displayed as '.' on the right-hand side of the buffer area.)

Last Message Sent:

1) Last complete message the gateway received from the ASCII device, processed, and sent to the other protocol

```
Last Message Sent (17 bytes)

0000: 52 54 41 2C 53 75 70 70 6F 72 74 2C 52 6F 63 68 RTA,Support,Rock

0016: 73 s
```

Next Message to Send from Queue:

2) This is the next complete message that the gateway has already received and processed from the ASCII device, and will be sent next to the other protocol

Current Message being Received from ASCII:

- 1) The current data that the gateway is receiving. The data needs to hit one of the three end cases to call a message complete:
 - a) Max Message Length (max number of characters to receive)
 - b) Receive Character Timeout (max time to wait after a character to call the current message complete)
 - c) Delimiters (gateway has not received the delimiters that are specified)

```
Current Message being Received from ASCII (17 bytes)
```

```
0000: 52 54 41 2C 53 75 70 70 6F 72 74 2C 52 6F 63 6B RTA,Support,Rock
0016: 73 s
```

Last Message Sent to ASCII:

1) Last message that the gateway sent to the ASCII device

Note: The concatenated delimiters are not displayed in this message but will be transmitted with the message

Last Message Sent to ASCII (18 bytes)

```
0000: 52 54 41 20 53 75 70 70 6F 72 74 20 52 6F 63 6B RTA Support Rock
0016: 73 21 s!
```



Send Data from Gateway to ASCII: (Used for testing only, Character limit of 1024):

- 1) Enter a message to send to your ASCII device
- 2) Can be used to test communication and test formatting of messages

Send Data from Gateway to ASCII (Used for Testing Only)	
Enter Test Message Here	
	//
Send ASCII Message	



LED Configuration

To modify the behavior of the LEDs on the 460 gateway, navigate to **Other->Setup LEDs**.

OTH	ER	
	-Select-	~
	-Select-	
	Setup LED's	

Each LED may be set to Disabled, Protocol 1, or Protocol 2. If either protocol is a master/client, you may set the LED to represent either all slaves/servers configured in the gateway or a slave/server device.

To select a slave/server device:

- 1) Select the protocol in the left dropdown menu.
- 2) Click **Save Parameters** to generate the second dropdown menu.
- 3) Select the individual slave/server in the right dropdown menu.

Click the **Save Parameters** button to commit the changes and reboot the gateway.

LED Configuration	
	LED 1 Modbus RTU Master: Connection Status V All Slave's V LED 2 BACnet/IP Server: Connection Status V
	Save Parameters



Configuration Files

To access the configuration file in the 460 gateway, select the dropdown **Other->Export/Import Config**.

OTH	ER	
	-Select-	
	-Select-	
	Setup LED's	
	Export / Import Config 📐	
	Export / Import Template	
	Utilities	

Export Configuration

Export Configuration		
	Save Configuration to File	

The Export Configuration allows you to save your configuration file for backup or to be imported into another gateway. This file is named *rta_cfg.rtax* by default.

Upon clicking the **Save Configuration to File** button, you will be prompted to select a location to save the file. Different web browsers will yield different looks.

What do you want to do with rta_cfg.rtax?	Open	Save	~	Cancel	×
From: 10.1.16.106	Open	Save		Cancer	\sim

Import Configuration

You can import a previously exported configuration file or a configuration file from another device into the 460 gateway, whenever it is in Configuration Mode.

Upon clicking the **Choose File** button, you will be prompted to select a location from which to load the saved file. Once the location is selected, you can choose the **Import Network Settings** checkbox if you want to load the network settings of the configuration file or just load the configuration without the network setting.

If you choose to Import Network Settings, this will override your current gateway's network setting with the settings in the configuration file. After you click on the Load Configuration button, a banner will display your gateway's new IP address.

Network Settings have changed. Manually enter IP Address of X.X.X.X in the URL.

If the configuration has successfully loaded, the gateway will indicate that it was successful, and a message will appear under the Load Configuration button indicating Restart Needed.

Real Time Automation, Inc.



Import Configuration		
	Choose File No file chosen	
	Import Network Settings	
	Load Configuration	

If it encountered an error while trying to load the saved configuration, the gateway will indicate the first error it found and a brief description about it under the Load Configuration button. Contact RTA Support with a screenshot of this error to further troubleshoot.



Save and Replace Configuration Using SD Card

Saving Configuration Using SD Card

This function saves the gateway's configuration automatically to an SD Card each time the gateway is rebooted via the **Restart Now** button on the web page. If this unit should fail in the future, the last configuration stored on the SD card and can be used for a new gateway to get the application back up and running quickly.

This SD Card replaces every configurable field in the gateway, **EXCEPT** for IP Address, Subnet Mask, and Default Gateway.

Replacing Configuration Using SD Card

To replace a configuration in a gateway using the SD Card, a specific sequence of events must be followed for the replacement to happen correctly:

- 1) Extract SD Card from gateway you wish to copy the configuration from.
- 2) Power up the gateway you wish to copy the configuration to. DO NOT INSERT SD CARD YET.
- 3) Navigate to the webpage inside the unit.
- 4) Navigate to the dropdown **Other->Utilities**.
- 5) If you are not currently in *Mode: Configuration*, go into Configuration Mode by clicking the **Configuration Mode** button at the top left-hand side of the screen.
- 6) Press the **Revert to Manufacturing Defaults** button on the Utilities Page. The Configuration will ONLY be replaced by the SD Card if the gateway does not have a configuration already in it.
- 7) When the unit comes back in *Mode: Running,* insert the SD Card.
- 8) Do a hard power cycle to the unit by unplugging power. DO NOT RESET POWER VIA WEB PAGES.
 - a. It will take an additional 30 seconds for the unit to power up while it is transferring the configuration. During this time, the gateway cannot be accessed via the web page.
- 9) When the unit comes back up, the configuration should be exactly what was on the SD Card.



Utilities

To access the Utilities page in the 460 gateway, navigate to **Other->Utilities**. The Utilities screen displays information about the gateway including Operation Time, File System Usage, Memory Usage, and Memory Block Usage.

OTHER

-Select-
-Select-
Setup LED's
Export / Import Config
Export / Import Template
Utilities
Time Configuration
Email Configuration
Security Configuration
Alarm Configuration
COS Configuration

Here you can also:

- View the full revision of the software.
- View all the files stored in the Flash File System within the gateway.
- Identify your device by clicking the **Start Flashing LEDs** button. By clicking this button, the two diagnostic LEDs will flash red and green. Once you have identified which device you are working with, click the button again to put the LEDs back into running mode.
- Configure the size of the log through the Log Configuration.
- Bring the device back to its last power up settings.
- Bring the device back to its original manufacturing defaults.
- Remove the Configuration File and Flash Files within the gateway.

Revisions	
	Listing of Revisions
File List	
The List	File List
Identify Device	
	Start Flashing LED's
Set Un Log	
out op Log	Log Configuration
Revert To Last Powerup	
	Revert to Last Powerup
Revert All	
	Revert to Manufacturing Defaults
Reformat Flash	
	Reformat Flash

Real Time Automation, Inc.